ADJ

Encore Profile Pro WW



Manufacturer	**ADJ**
Type	**Profile spot**
DMX modes	**4**
DMX footprint	**1, 2, 3, 6 channels**
Beam angle	**15°**
Size (W × H × D)	**42 × 323 × 200 mm**
GDTF fixture type	**0E905D68-4723-4BE0-BAD0-F6…**

Controls

Strobe · Dimmer

DMX modes

1CH	1 ch
2CH	2 ch
3CH	3 ch
6CH	6 ch

1CH

1 channel

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open

2CH

2 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Dimmer Fine	0	Fine byte of Dimmer

3CH

3 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Dimmer Fine	0	Fine byte of Dimmer
3	Shutter / Strobe	50	0–31 Shutter Closed 32–63 Shutter Open 64–95 Strobe Slow to Fast 96–127 Shutter Open 128–159 Pulse Slow to Fast 160–191 Shutter Open 192–223 Random Strobe Slow to Fast 224–255 Shutter Open

6CH

6 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Dimmer Fine	0	Fine byte of Dimmer
3	Shutter / Strobe	50	0–31 Shutter Closed 32–63 Shutter Open 64–95 Strobe Slow to Fast 96–127 Shutter Open 128–159 Pulse Slow to Fast 160–191 Shutter Open 192–223 Random Strobe Slow to Fast 224–255 Shutter Open

6CH (continued)

Ch	Function	Default	DMX values
4	Dimmer Mode	0	0–20 Default to Unit Setting 21–40 Standard 41–60 Stage 61–80 TV 81–100 Architectural 101–120 Theatre 121–140 Stage 2 141–141 0/1sec 142–142 0/2sec 143–143 0/3sec 144–144 0/4sec 145–145 0/5sec 146–146 0/6sec 147–147 0/7sec 148–148 0/8sec 149–149 0/9sec 150–150 1sec 151–151 1/5sec 152–152 2sec 153–153 3sec 154–154 4sec 155–155 5sec 156–156 6sec 157–157 7sec 158–158 8sec 159–159 9sec 160–160 10sec 161–255 Default to Unit Setting
5	Dimmer Curve	0	0–20 Square 21–40 Linear 41–60 Inverted Square 61–80 S Curve 81–255 No function
6	L EDFrequency	0	