ADJ

Fantasy FX



Manufacturer	**ADJ**
Type	**Strobe**
DMX modes	**3**
DMX footprint	**7, 16, 152 channels**
Beam angle	**140°**
Heads / cells	**2**
Size (W × H × D)	**400 × 110 × 350 mm**
GDTF fixture type	**275ABB3A-CE59-48CA-970E-24…**

Controls

Colour wheel · Effect speed · Strobe · Dimmer · Pixel control

Safety-relevant functions

Built-in effect programmes

DMX modes

7CH	7 ch
16CH	16 ch
152CH	152 ch

7CH

7 channels

Ch	Function	Default	DMX values
1	Red	0	0–62 0 % Main Center 63–126 25 % Main Center 127–190 50 % Main Center 191–254 75 % Main Center 255–255 100 % Main Center
2	Green	0	0–62 0 % Main Center 63–126 25 % Main Center 127–190 50 % Main Center 191–254 75 % Main Center 255–255 100 % Main Center
3	Blue	0	0–62 0 % Main Center 63–126 25 % Main Center 127–190 50 % Main Center 191–254 75 % Main Center 255–255 100 % Main Center
4	White	0	0–62 0 % Main Center 63–126 25 % Main Center 127–190 50 % Main Center 191–254 75 % Main Center 255–255 100 % Main Center
5	Red	0	0–62 0 % Background All 63–126 25 % Background All 127–190 50 % Background All 191–254 75 % Background All 255–255 100 % Background All
6	Green	0	0–62 0 % Background All 63–126 25 % Background All 127–190 50 % Background All 191–254 75 % Background All 255–255 100 % Background All
7	Blue	0	0–62 0 % Background All 63–126 25 % Background All 127–190 50 % Background All 191–254 75 % Background All 255–255 100 % Background All

16CH

16 channels

Ch	Function	Default	DMX values
1	Red	255	0–62 0 % Main Center 63–126 25 % Main Center 127–190 50 % Main Center 191–254 75 % Main Center 255–255 100 % Main Center
2	Green	255	0–62 0 % Main Center 63–126 25 % Main Center 127–190 50 % Main Center 191–254 75 % Main Center 255–255 100 % Main Center
3	Blue	255	0–62 0 % Main Center 63–126 25 % Main Center 127–190 50 % Main Center 191–254 75 % Main Center 255–255 100 % Main Center

16CH (continued)

Ch	Function	Default	DMX values
4	White	255	0–62 0 % Main Center 63–126 25 % Main Center 127–190 50 % Main Center 191–254 75 % Main Center 255–255 100 % Main Center
5	Shutter / Strobe	32	0–31 LEDs Off Main RGBW 32–63 LEDs ON Main RGBW 64–95 Strobe Fast to Slow Main RGBW 96–127 LEDs ON Main RGBW 128–159 Pulse Slow to Fast Main RGBW 160–191 LEDs ON Main RGBW 192–223 Rnd Strobe Slow to Fast Main RGBW 224–255 LEDs ON Main RGBW
6	Dimmer	0	0–62 0 % Main RGBW 63–126 25 % Main RGBW 127–190 50 % Main RGBW 191–254 75 % Main RGBW 255–255 100 % Main RGBW
7	Red	255	0–62 0 % Background All 63–126 25 % Background All 127–190 50 % Background All 191–254 75 % Background All 255–255 100 % Background All
8	Green	255	0–62 0 % Background All 63–126 25 % Background All 127–190 50 % Background All 191–254 75 % Background All 255–255 100 % Background All
9	Blue	255	0–62 0 % Background All 63–126 25 % Background All 127–190 50 % Background All 191–254 75 % Background All 255–255 100 % Background All
10	Shutter / Strobe	32	0–31 LEDs Off RGB 32–63 LEDs ON RGB 64–95 Strobe Slow to Fast RGB 96–127 LEDs ON RGB 128–159 Pulse Slow to Fast RGB 160–191 LEDs ON RGB 192–223 Rnd Strobe Slow to Fast RGB 224–255 LEDs ON RGB
11	Dimmer	0	0–62 0 % Background RGB 63–126 25 % Background RGB 127–190 50 % Background RGB 191–254 75 % Background RGB 255–255 100 % Background RGB

16CH (continued)

Ch	Function	Default	DMX values
12	Color Wheel	0	0–0 Off (wheel slot 1) 1–4 Color Macro 1 (wheel slot 2) 5–8 Color Macro 2 (wheel slot 3) 9–12 Color Macro 3 (wheel slot 4) 13–16 Color Macro 4 (wheel slot 5) 17–20 Color Macro 5 (wheel slot 6) 21–24 Color Macro 6 (wheel slot 7) 25–28 Color Macro 7 (wheel slot 8) 29–32 Color Macro 8 (wheel slot 9) 33–36 Color Macro 9 (wheel slot 10) 37–40 Color Macro 10 (wheel slot 11) 41–44 Color Macro 11 (wheel slot 12) 45–48 Color Macro 12 (wheel slot 13) 49–52 Color Macro 13 (wheel slot 14) 53–56 Color Macro 14 (wheel slot 15) 57–60 Color Macro 15 (wheel slot 16) 61–64 Color Macro 16 (wheel slot 17) 65–68 Color Macro 17 (wheel slot 18) 69–72 Color Macro 18 (wheel slot 19) 73–76 Color Macro 19 (wheel slot 20) 77–80 Color Macro 20 (wheel slot 21) 81–84 Color Macro 21 (wheel slot 22) 85–88 Color Macro 22 (wheel slot 23) 89–92 Color Macro 23 (wheel slot 24) 93–96 Color Macro 24 (wheel slot 25) 97–100 Color Macro 25 (wheel slot 26) 101–104 Color Macro 26 (wheel slot 27) 105–108 Color Macro 27 (wheel slot 28) 109–112 Color Macro 28 (wheel slot 29) 113–116 Color Macro 29 (wheel slot 30) 117–120 Color Macro 30 (wheel slot 31) 121–124 Color Macro 31 (wheel slot 32) 125–128 Color Macro 32 (wheel slot 33) 129–132 Color Macro 33 (wheel slot 34) 133–136 Color Macro 34 (wheel slot 35) 137–140 Color Macro 35 (wheel slot 36) 141–144 Color Macro 36 (wheel slot 37) 145–148 Color Macro 37 (wheel slot 38) 149–152 Color Macro 38 (wheel slot 39) 153–156 Color Macro 39 (wheel slot 40) 157–160 Color Macro 40 (wheel slot 41) 161–164 Color Macro 41 (wheel slot 42) 165–168 Color Macro 42 (wheel slot 43) 169–172 Color Macro 43 (wheel slot 44) 173–176 Color Macro 44 (wheel slot 45) 177–180 Color Macro 45 (wheel slot 46) 181–184 Color Macro 46 (wheel slot 47) 185–188 Color Macro 47 (wheel slot 48) 189–192 Color Macro 48 (wheel slot 49) 193–196 Color Macro 49 (wheel slot 50) 197–200 Color Macro 50 (wheel slot 51) 201–204 Color Macro 51 (wheel slot 52) 205–208 Color Macro 52 (wheel slot 53) 209–212 Color Macro 53 (wheel slot 54) 213–216 Color Macro 54 (wheel slot 55) 217–220 Color Macro 55 (wheel slot 56) 221–224 Color Macro 56 (wheel slot 57) 225–228 Color Macro 57 (wheel slot 58) 229–232 Color Macro 58 (wheel slot 59) 233–236 Color Macro 59 (wheel slot 60) 237–240 Color Macro 60 (wheel slot 61) 241–244 Color Macro 61 (wheel slot 62) 245–248 Color Macro 62 (wheel slot 63) 249–252 Color Macro 63 (wheel slot 64)

16CH (continued)

Ch	Function	Default	DMX values
13	Effect	0	0–5 Auto Program 0 6–10 Auto Program 1 11–15 Auto Program 2 16–21 Auto Program 3 22–26 Auto Program 4 27–31 Auto Program 5 32–37 Auto Program 6 38–42 Auto Program 7 43–47 Auto Program 8 48–53 Auto Program 9 54–58 Auto Program 10 59–63 Auto Program 11 64–69 Auto Program 12 70–74 Auto Program 13 75–79 Auto Program 14 80–85 Auto Program 15 86–90 Auto Program 16 91–95 Auto Program 17 96–101 Auto Program 18 102–106 Auto Program 19 107–111 Auto Program 20 112–117 Auto Program 21 118–122 Auto Program 22 123–127 Auto Program 23 128–132 Auto Program 24 133–138 Auto Program 25 139–143 Auto Program 26 144–148 Auto Program 27 149–154 Auto Program 28 155–159 Auto Program 29 160–164 Auto Program 30 165–170 Auto Program 31 171–175 Auto Program 32 176–180 Auto Program 33 181–186 Auto Program 34 187–191 Auto Program 35 192–196 Auto Program 36 197–202 Auto Program 37 203–207 Auto Program 38 208–212 Auto Program 39 213–218 Auto Program 40 219–223 Auto Program 41 224–228 Auto Program 42 229–234 Auto Program 43 235–239 Auto Program 44 240–244 Auto Program 45 245–250 Auto Program 46 251–255 Auto Program 47
14	Effect Speed	0	

16CH (continued)

Ch	Function	Default	DMX values
15	Effect	0	0–19 Empty Channel Set 20–29 Auto Program 2 RGB 30–39 Auto Program 3 RGB 40–49 Auto Program 4 RGB 50–59 Auto Program 5 RGB 60–69 Auto Program 6 RGB 70–79 Auto Program 7 RGB 80–89 Auto Program 8 RGB 90–99 Auto Program 9 RGB 100–109 Auto Program 10 RGB 110–119 Auto Program 11 RGB 120–129 Auto Program 12 RGB 130–139 Auto Program 13 RGB 140–149 Auto Program 14 RGB 150–159 Auto Program 15 RGB 160–169 Auto Program 16 RGB 170–179 Auto Program 17 RGB 180–189 Auto Program 18 RGB 190–199 Auto Program 19 RGB 200–255 Auto Program 20 RGB
16	Effect Speed	0	

152CH

152 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	Shutter / Strobe	32	0–31 LEDs Off Main RGBW 32–63 LEDs ON Main RGBW 64–95 Strobe Fast to Slow Main RGBW 96–127 LEDs ON Main RGBW 128–159 Pulse Slow to Fast Main RGBW 160–191 LEDs ON Main RGBW 192–223 Rnd Strobe Slow to Fast Main RGBW 224–255 LEDs ON Main RGBW
6	Dimmer	0	
7	Red	255	
8	Green	255	
9	Blue	255	
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	
21	Reserved 21	0	

152CH (continued)

Ch	Function	Default	DMX values
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	
29	Reserved 29	0	
30	Reserved 30	0	
31	Reserved 31	0	
32	Reserved 32	0	
33	Reserved 33	0	
34	Reserved 34	0	
35	Reserved 35	0	
36	Reserved 36	0	
37	Reserved 37	0	
38	Reserved 38	0	
39	Reserved 39	0	
40	Reserved 40	0	
41	Reserved 41	0	
42	Reserved 42	0	
43	Reserved 43	0	
44	Reserved 44	0	
45	Reserved 45	0	
46	Reserved 46	0	
47	Reserved 47	0	
48	Reserved 48	0	
49	Reserved 49	0	
50	Reserved 50	0	
51	Reserved 51	0	
52	Reserved 52	0	
53	Reserved 53	0	
54	Reserved 54	0	
55	Reserved 55	0	
56	Reserved 56	0	
57	Reserved 57	0	
58	Reserved 58	0	
59	Reserved 59	0	
60	Reserved 60	0	
61	Reserved 61	0	
62	Reserved 62	0	
63	Reserved 63	0	
64	Reserved 64	0	
65	Reserved 65	0	
66	Reserved 66	0	

152CH (continued)

Ch	Function	Default	DMX values
67	Reserved 67	0	
68	Reserved 68	0	
69	Reserved 69	0	
70	Reserved 70	0	
71	Reserved 71	0	
72	Reserved 72	0	
73	Reserved 73	0	
74	Reserved 74	0	
75	Reserved 75	0	
76	Reserved 76	0	
77	Reserved 77	0	
78	Reserved 78	0	
79	Reserved 79	0	
80	Reserved 80	0	
81	Reserved 81	0	
82	Reserved 82	0	
83	Reserved 83	0	
84	Reserved 84	0	
85	Reserved 85	0	
86	Reserved 86	0	
87	Reserved 87	0	
88	Reserved 88	0	
89	Reserved 89	0	
90	Reserved 90	0	
91	Reserved 91	0	
92	Reserved 92	0	
93	Reserved 93	0	
94	Reserved 94	0	
95	Reserved 95	0	
96	Reserved 96	0	
97	Reserved 97	0	
98	Reserved 98	0	
99	Reserved 99	0	
100	Reserved 100	0	
101	Reserved 101	0	
102	Reserved 102	0	
103	Reserved 103	0	
104	Reserved 104	0	
105	Reserved 105	0	
106	Reserved 106	0	
107	Reserved 107	0	
108	Reserved 108	0	
109	Reserved 109	0	
110	Reserved 110	0	
111	Reserved 111	0	

152CH (continued)

Ch	Function	Default	DMX values
112	Reserved 112	0	
113	Reserved 113	0	
114	Reserved 114	0	
115	Reserved 115	0	
116	Reserved 116	0	
117	Reserved 117	0	
118	Reserved 118	0	
119	Reserved 119	0	
120	Reserved 120	0	
121	Reserved 121	0	
122	Reserved 122	0	
123	Reserved 123	0	
124	Reserved 124	0	
125	Reserved 125	0	
126	Reserved 126	0	
127	Reserved 127	0	
128	Reserved 128	0	
129	Reserved 129	0	
130	Reserved 130	0	
131	Reserved 131	0	
132	Reserved 132	0	
133	Reserved 133	0	
134	Reserved 134	0	
135	Reserved 135	0	
136	Reserved 136	0	
137	Reserved 137	0	
138	Reserved 138	0	
139	Reserved 139	0	
140	Reserved 140	0	
141	Reserved 141	0	
142	Reserved 142	0	
143	Reserved 143	0	
144	Reserved 144	0	
145	Reserved 145	0	
146	Reserved 146	0	
147	Reserved 147	0	
148	Reserved 148	0	
149	Reserved 149	0	
150	Reserved 150	0	
151	Shutter / Strobe	32	0–31 LEDs Off RGB 32–63 LEDs ON RGB 64–95 Strobe Slow to Fast RGB 96–127 LEDs ON RGB 128–159 Pulse Slow to Fast RGB 160–191 LEDs ON RGB 192–223 Rnd Strobe Slow to Fast RGB 224–255 LEDs ON RGB

152CH (continued)

Ch	Function	Default	DMX values
152	Dimmer	0	