ADJ

Frost FX Bar RGBW



Manufacturer	**ADJ**
Type	**Effect light**
DMX modes	**7**
DMX footprint	**3, 7, 11, 18, 102, 107, 111 channels**
Beam angle	**22-25°**
Heads / cells	**2**
Size (W × H × D)	**800 × 100 × 40 mm**
GDTF fixture type	**2FB905EE-4C59-4E94-A647-EF6…**

Controls

Colour temperature · Colour wheel · Effect speed · Strobe · Dimmer · Pixel control

Safety-relevant functions

Built-in effect programmes

DMX modes

3ch	3 ch
7ch	7 ch
11ch	11 ch
18ch	18 ch
102ch	102 ch
107ch	107 ch
111ch	111 ch

3ch

3 channels

Ch	Function	Default	DMX values
1	Effect	0	0–10 Normal 11–15 Internal Program 1 16–20 Internal Program 2 21–25 Internal Program 3 26–30 Internal Program 4 31–35 Internal Program 5 36–40 Internal Program 6 41–45 Internal Program 7 46–50 Internal Program 8 51–55 Internal Program 9 56–60 Internal Program 10 61–65 Internal Program 11 66–70 Internal Program 12 71–75 Internal Program 13 76–80 Internal Program 14 81–85 Internal Program 15 86–90 Internal Program 16 91–95 Internal Program 17 96–100 Internal Program 18 101–105 Internal Program 19 106–110 Internal Program 20 111–115 Internal Program 21 116–120 Internal Program 22 121–125 Internal Program 23 126–130 Internal Program 24 131–135 Internal Program 25 136–140 Internal Program 26 141–145 Internal Program 27 146–150 Internal Program 28 151–155 Internal Program 29 156–160 Internal Program 30 161–165 Internal Program 31 166–170 Internal Program 32 171–175 Internal Program 33 176–180 Internal Program 34 181–185 Internal Program 35 186–190 Internal Program 36 191–195 Internal Program 37 196–200 Internal Program 38 201–205 Internal Program 39 206–210 Internal Program 40 211–215 Internal Program 41 216–220 Internal Program 42 221–225 Internal Program 43 226–230 Internal Program 44 231–235 Internal Program 45 236–245 Sound Control 1 246–255 Sound Control 2
2	Effect Speed	0	
3	Effects1Fade	0	

7ch

7 channels

Ch	Function	Default	DMX values
1	Red	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %

7ch (continued)

Ch	Function	Default	DMX values
2	Green	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
3	Blue	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
4	White	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
5	Red	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
6	Green	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
7	Blue	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %

11ch

11 channels

Ch	Function	Default	DMX values
1	Red	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
2	Green	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
3	Blue	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
4	White	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %

11ch (continued)

Ch	Function	Default	DMX values
5	Red	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
6	Green	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
7	Blue	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
8	Shutter / Strobe	32	0–31 LEDs Off Bkgrnd 32–63 LEDs ON Bkgrnd 64–95 Strobe Slow to Fast Bkgrnd 96–127 LEDs ON Bkgrnd 128–159 Pulse Slow to Fast Bkgrnd 160–191 Shutter Open Bkgrnd 192–223 Rnd Strobe Slow to Fast Bkgrnd 224–255 LEDs ON Bkgrnd
9	Dimmer	0	0–62 0 % Dim Main 63–126 25 % Dim Main 127–190 50 % Dim Main 191–255 0 % Dim Main
10	Shutter / Strobe	32	0–31 LEDs Off 32–63 LEDs ON 64–95 Strobe Slow to Fast 96–127 LEDs ON 128–159 Pulse Slow to Fast 160–191 Shutter Open 192–223 Rnd Strobe Slow to Fast 224–255 LEDs ON
11	Dimmer	0	0–62 0 % Dim Bkgrnd 63–126 25 % Dim Bkgrnd 127–190 50 % Dim Bkgrnd 191–254 75 % Dim Bkgrnd 255–255 100 % Dim Bkgrnd

18ch

18 channels

Ch	Function	Default	DMX values
1	Red	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
2	Green	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %

18ch (continued)

Ch	Function	Default	DMX values
3	Blue	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
4	White	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
5	Red	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
6	Green	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
7	Blue	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
8	Color Wheel	0	0–31 Open (wheel slot 1) 32–76 2700K (wheel slot 6) 77–121 3200K (wheel slot 11) 122–166 4000K (wheel slot 19) 167–211 5600K (wheel slot 35) 212–255 6000K (wheel slot 39)
9	Color Wheel 2	0	0–31 Open (wheel slot 1) 32–76 2700K (wheel slot 6) 77–121 3200K (wheel slot 11) 122–166 4000K (wheel slot 19) 167–211 5600K (wheel slot 35) 212–255 6000K (wheel slot 39)
10	Color3	0	

18ch (continued)

Ch	Function	Default	DMX values
11	Color4	0	0–0 Open OFF (wheel slot 1) 1–7 Color Macro 1 (wheel slot 2) 8–15 Color Macro 2 (wheel slot 3) 16–23 Color Macro 3 (wheel slot 4) 24–31 Color Macro 4 (wheel slot 5) 32–39 Color Macro 5 (wheel slot 6) 40–47 Color Macro 6 (wheel slot 7) 48–55 Color Macro 7 (wheel slot 8) 56–63 Color Macro 8 (wheel slot 9) 64–71 Color Macro 9 (wheel slot 10) 72–79 Color Macro 10 (wheel slot 11) 80–87 Color Macro 11 (wheel slot 12) 88–95 Color Macro 12 (wheel slot 13) 96–103 Color Macro 13 (wheel slot 14) 104–111 Color Macro 14 (wheel slot 15) 112–119 Color Macro 15 (wheel slot 16) 120–127 Color Macro 16 (wheel slot 17) 128–135 Color Macro 17 (wheel slot 18) 136–143 Color Macro 18 (wheel slot 19) 144–151 Color Macro 19 (wheel slot 20) 152–159 Color Macro 20 (wheel slot 21) 160–167 Color Macro 21 (wheel slot 22) 168–175 Color Macro 22 (wheel slot 23) 176–183 Color Macro 23 (wheel slot 24) 184–191 Color Macro 24 (wheel slot 25) 192–199 Color Macro 25 (wheel slot 26) 200–207 Color Macro 26 (wheel slot 27) 208–215 Color Macro 27 (wheel slot 28) 216–223 Color Macro 28 (wheel slot 29) 224–231 Color Macro 29 (wheel slot 30) 232–239 Color Macro 30 (wheel slot 31) 240–247 Color Macro 31 (wheel slot 32) 248–255 Color Macro 32 (wheel slot 33)
12	Shutter / Strobe	32	0–31 LEDs Off 32–63 LEDs ON 64–95 Strobe Slow to Fast 96–127 LEDs ON 128–159 Pulse Slow to Fast 160–191 Shutter Open 192–223 Rnd Strobe Slow to Fast 224–255 LEDs ON
13	Dimmer	0	0–62 0 % Dim Main 63–126 25 % Dim Main 127–190 50 % Dim Main 191–255 0 % Dim Main
14	Shutter / Strobe	32	0–31 LEDs Off Bkgrnd 32–63 LEDs ON Bkgrnd 64–95 Strobe Slow to Fast Bkgrnd 96–127 LEDs ON Bkgrnd 128–159 Pulse Slow to Fast Bkgrnd 160–191 Shutter Open Bkgrnd 192–223 Rnd Strobe Slow to Fast Bkgrnd 224–255 LEDs ON Bkgrnd
15	Dimmer	0	0–62 0 % Dim Bkgrnd 63–126 25 % Dim Bkgrnd 127–190 50 % Dim Bkgrnd 191–254 75 % Dim Bkgrnd 255–255 100 % Dim Bkgrnd

18ch (continued)

Ch	Function	Default	DMX values
16	Effect	0	0–10 Normal 11–15 Internal Program 1 16–20 Internal Program 2 21–25 Internal Program 3 26–30 Internal Program 4 31–35 Internal Program 5 36–40 Internal Program 6 41–45 Internal Program 7 46–50 Internal Program 8 51–55 Internal Program 9 56–60 Internal Program 10 61–65 Internal Program 11 66–70 Internal Program 12 71–75 Internal Program 13 76–80 Internal Program 14 81–85 Internal Program 15 86–90 Internal Program 16 91–95 Internal Program 17 96–100 Internal Program 18 101–105 Internal Program 19 106–110 Internal Program 20 111–115 Internal Program 21 116–120 Internal Program 22 121–125 Internal Program 23 126–130 Internal Program 24 131–135 Internal Program 25 136–140 Internal Program 26 141–145 Internal Program 27 146–150 Internal Program 28 151–155 Internal Program 29 156–160 Internal Program 30 161–165 Internal Program 31 166–170 Internal Program 32 171–175 Internal Program 33 176–180 Internal Program 34 181–185 Internal Program 35 186–190 Internal Program 36 191–195 Internal Program 37 196–200 Internal Program 38 201–205 Internal Program 39 206–210 Internal Program 40 211–215 Internal Program 41 216–220 Internal Program 42 221–225 Internal Program 43 226–230 Internal Program 44 231–235 Internal Program 45 236–245 Sound Control 1 246–255 Sound Control 2
17	Effect Speed	0	
18	Effects1Fade	0	

102ch

102 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Green	0	
3	Blue	0	
4	White	0	
5	Reserved 5	0	

102ch (continued)

Ch	Function	Default	DMX values
6	Reserved 6	0	
7	Reserved 7	0	
8	Reserved 8	0	
9	Reserved 9	0	
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	
21	Reserved 21	0	
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	
29	Reserved 29	0	
30	Reserved 30	0	
31	Reserved 31	0	
32	Reserved 32	0	
33	Reserved 33	0	
34	Reserved 34	0	
35	Reserved 35	0	
36	Reserved 36	0	
37	Reserved 37	0	
38	Reserved 38	0	
39	Reserved 39	0	
40	Reserved 40	0	
41	Reserved 41	0	
42	Reserved 42	0	
43	Reserved 43	0	
44	Reserved 44	0	
45	Reserved 45	0	
46	Reserved 46	0	
47	Reserved 47	0	
48	Reserved 48	0	
49	Reserved 49	0	
50	Reserved 50	0	

102ch (continued)

Ch	Function	Default	DMX values
51	Reserved 51	0	
52	Reserved 52	0	
53	Reserved 53	0	
54	Reserved 54	0	
55	Reserved 55	0	
56	Reserved 56	0	
57	Reserved 57	0	
58	Reserved 58	0	
59	Reserved 59	0	
60	Reserved 60	0	
61	Reserved 61	0	
62	Reserved 62	0	
63	Reserved 63	0	
64	Reserved 64	0	
65	Reserved 65	0	
66	Reserved 66	0	
67	Reserved 67	0	
68	Reserved 68	0	
69	Reserved 69	0	
70	Reserved 70	0	
71	Reserved 71	0	
72	Reserved 72	0	
73	Reserved 73	0	
74	Reserved 74	0	
75	Reserved 75	0	
76	Reserved 76	0	
77	Reserved 77	0	
78	Reserved 78	0	
79	Reserved 79	0	
80	Reserved 80	0	
81	Reserved 81	0	
82	Reserved 82	0	
83	Reserved 83	0	
84	Reserved 84	0	
85	Reserved 85	0	
86	Reserved 86	0	
87	Reserved 87	0	
88	Reserved 88	0	
89	Reserved 89	0	
90	Reserved 90	0	
91	Reserved 91	0	
92	Reserved 92	0	
93	Reserved 93	0	
94	Reserved 94	0	
95	Reserved 95	0	

102ch (continued)

Ch	Function	Default	DMX values
96	Reserved 96	0	
97	Reserved 97	0	
98	Reserved 98	0	
99	Shutter / Strobe	32	0–31 LEDs Off 32–63 LEDs ON 64–95 Strobe Slow to Fast 96–127 LEDs ON 128–159 Pulse Slow to Fast 160–191 Shutter Open 192–223 Rnd Strobe Slow to Fast 224–255 LEDs ON
100	Dimmer	0	
101	Shutter / Strobe	32	0–31 LEDs Off Bkgrnd 32–63 LEDs ON Bkgrnd 64–95 Strobe Slow to Fast Bkgrnd 96–127 LEDs ON Bkgrnd 128–159 Pulse Slow to Fast Bkgrnd 160–191 Shutter Open Bkgrnd 192–223 Rnd Strobe Slow to Fast Bkgrnd 224–255 LEDs ON Bkgrnd
102	Dimmer	0	

107ch

107 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Green	0	
3	Blue	0	
4	White	0	
5	Reserved 5	0	
6	Reserved 6	0	
7	Reserved 7	0	
8	Reserved 8	0	
9	Reserved 9	0	
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	
21	Reserved 21	0	
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	

107ch (continued)

Ch	Function	Default	DMX values
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	
29	Reserved 29	0	
30	Reserved 30	0	
31	Reserved 31	0	
32	Reserved 32	0	
33	Reserved 33	0	
34	Reserved 34	0	
35	Reserved 35	0	
36	Reserved 36	0	
37	Reserved 37	0	
38	Reserved 38	0	
39	Reserved 39	0	
40	Reserved 40	0	
41	Reserved 41	0	
42	Reserved 42	0	
43	Reserved 43	0	
44	Reserved 44	0	
45	Reserved 45	0	
46	Reserved 46	0	
47	Reserved 47	0	
48	Reserved 48	0	
49	Reserved 49	0	
50	Reserved 50	0	
51	Reserved 51	0	
52	Reserved 52	0	
53	Reserved 53	0	
54	Reserved 54	0	
55	Reserved 55	0	
56	Reserved 56	0	
57	Reserved 57	0	
58	Reserved 58	0	
59	Reserved 59	0	
60	Reserved 60	0	
61	Reserved 61	0	
62	Reserved 62	0	
63	Reserved 63	0	
64	Reserved 64	0	
65	Reserved 65	0	
66	Reserved 66	0	
67	Reserved 67	0	
68	Reserved 68	0	
69	Reserved 69	0	

107ch (continued)

Ch	Function	Default	DMX values
70	Reserved 70	0	
71	Reserved 71	0	
72	Reserved 72	0	
73	Reserved 73	0	
74	Reserved 74	0	
75	Reserved 75	0	
76	Reserved 76	0	
77	Reserved 77	0	
78	Reserved 78	0	
79	Reserved 79	0	
80	Reserved 80	0	
81	Reserved 81	0	
82	Reserved 82	0	
83	Reserved 83	0	
84	Reserved 84	0	
85	Reserved 85	0	
86	Reserved 86	0	
87	Reserved 87	0	
88	Reserved 88	0	
89	Reserved 89	0	
90	Reserved 90	0	
91	Reserved 91	0	
92	Reserved 92	0	
93	Reserved 93	0	
94	Reserved 94	0	
95	Reserved 95	0	
96	Reserved 96	0	
97	Reserved 97	0	
98	Reserved 98	0	
99	Color3	0	
100	Color4	0	
101	Shutter / Strobe	32	0–31 LEDs Off 32–63 LEDs ON 64–95 Strobe Slow to Fast 96–127 LEDs ON 128–159 Pulse Slow to Fast 160–191 Shutter Open 192–223 Rnd Strobe Slow to Fast 224–255 LEDs ON
102	Dimmer	0	
103	Shutter / Strobe	32	0–31 LEDs Off Bkgrnd 32–63 LEDs ON Bkgrnd 64–95 Strobe Slow to Fast Bkgrnd 96–127 LEDs ON Bkgrnd 128–159 Pulse Slow to Fast Bkgrnd 160–191 Shutter Open Bkgrnd 192–223 Rnd Strobe Slow to Fast Bkgrnd 224–255 LEDs ON Bkgrnd
104	Dimmer	0	

107ch (continued)

Ch	Function	Default	DMX values
105	Effect	0	0–10 Normal 11–15 Internal Program 1 16–20 Internal Program 2 21–25 Internal Program 3 26–30 Internal Program 4 31–35 Internal Program 5 36–40 Internal Program 6 41–45 Internal Program 7 46–50 Internal Program 8 51–55 Internal Program 9 56–60 Internal Program 10 61–65 Internal Program 11 66–70 Internal Program 12 71–75 Internal Program 13 76–80 Internal Program 14 81–85 Internal Program 15 86–90 Internal Program 16 91–95 Internal Program 17 96–100 Internal Program 18 101–105 Internal Program 19 106–110 Internal Program 20 111–115 Internal Program 21 116–120 Internal Program 22 121–125 Internal Program 23 126–130 Internal Program 24 131–135 Internal Program 25 136–140 Internal Program 26 141–145 Internal Program 27 146–150 Internal Program 28 151–155 Internal Program 29 156–160 Internal Program 30 161–165 Internal Program 31 166–170 Internal Program 32 171–175 Internal Program 33 176–180 Internal Program 34 181–185 Internal Program 35 186–190 Internal Program 36 191–195 Internal Program 37 196–200 Internal Program 38 201–205 Internal Program 39 206–210 Internal Program 40 211–215 Internal Program 41 216–220 Internal Program 42 221–225 Internal Program 43 226–230 Internal Program 44 231–235 Internal Program 45 236–245 Sound Control 1 246–255 Sound Control 2
106	Effect Speed	0	
107	Effects1Fade	0	

111ch

111 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Green	0	
3	Blue	0	
4	White	0	
5	Reserved 5	0	

111ch (continued)

Ch	Function	Default	DMX values
6	Reserved 6	0	
7	Reserved 7	0	
8	Reserved 8	0	
9	Reserved 9	0	
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	
21	Reserved 21	0	
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	
29	Reserved 29	0	
30	Reserved 30	0	
31	Reserved 31	0	
32	Reserved 32	0	
33	Reserved 33	0	
34	Reserved 34	0	
35	Reserved 35	0	
36	Reserved 36	0	
37	Reserved 37	0	
38	Reserved 38	0	
39	Reserved 39	0	
40	Reserved 40	0	
41	Reserved 41	0	
42	Reserved 42	0	
43	Reserved 43	0	
44	Reserved 44	0	
45	Reserved 45	0	
46	Reserved 46	0	
47	Reserved 47	0	
48	Reserved 48	0	
49	Reserved 49	0	
50	Reserved 50	0	

111ch (continued)

Ch	Function	Default	DMX values
51	Reserved 51	0	
52	Reserved 52	0	
53	Reserved 53	0	
54	Reserved 54	0	
55	Reserved 55	0	
56	Reserved 56	0	
57	Reserved 57	0	
58	Reserved 58	0	
59	Reserved 59	0	
60	Reserved 60	0	
61	Reserved 61	0	
62	Reserved 62	0	
63	Reserved 63	0	
64	Reserved 64	0	
65	Reserved 65	0	
66	Reserved 66	0	
67	Reserved 67	0	
68	Reserved 68	0	
69	Reserved 69	0	
70	Reserved 70	0	
71	Reserved 71	0	
72	Reserved 72	0	
73	Reserved 73	0	
74	Reserved 74	0	
75	Reserved 75	0	
76	Reserved 76	0	
77	Reserved 77	0	
78	Reserved 78	0	
79	Reserved 79	0	
80	Reserved 80	0	
81	Reserved 81	0	
82	Reserved 82	0	
83	Reserved 83	0	
84	Reserved 84	0	
85	Reserved 85	0	
86	Reserved 86	0	
87	Reserved 87	0	
88	Reserved 88	0	
89	Reserved 89	0	
90	Reserved 90	0	
91	Reserved 91	0	
92	Reserved 92	0	
93	Reserved 93	0	
94	Reserved 94	0	
95	Reserved 95	0	

111ch (continued)

Ch	Function	Default	DMX values
96	Reserved 96	0	
97	Reserved 97	0	
98	Reserved 98	0	
99	C TO	0	
100	Color Wheel	0	0–31 Open (wheel slot 1) 32–76 2700K (wheel slot 6) 77–121 3200K (wheel slot 11) 122–166 4000K (wheel slot 19) 167–211 5600K (wheel slot 35) 212–255 6000K (wheel slot 39)
101	C TO	0	
102	Color Wheel 2	0	0–31 Open (wheel slot 1) 32–76 2700K (wheel slot 6) 77–121 3200K (wheel slot 11) 122–166 4000K (wheel slot 19) 167–211 5600K (wheel slot 35) 212–255 6000K (wheel slot 39)
103	Color3	0	
104	Color4	0	
105	Shutter / Strobe	32	0–31 LEDs Off 32–63 LEDs ON 64–95 Strobe Slow to Fast 96–127 LEDs ON 128–159 Pulse Slow to Fast 160–191 Shutter Open 192–223 Rnd Strobe Slow to Fast 224–255 LEDs ON
106	Dimmer	0	
107	Shutter / Strobe	32	0–31 LEDs Off Bkgrnd 32–63 LEDs ON Bkgrnd 64–95 Strobe Slow to Fast Bkgrnd 96–127 LEDs ON Bkgrnd 128–159 Pulse Slow to Fast Bkgrnd 160–191 Shutter Open Bkgrnd 192–223 Rnd Strobe Slow to Fast Bkgrnd 224–255 LEDs ON Bkgrnd
108	Dimmer	0	

111ch (continued)

Ch	Function	Default	DMX values
109	Effect	0	0–10 Normal 11–15 Internal Program 1 16–20 Internal Program 2 21–25 Internal Program 3 26–30 Internal Program 4 31–35 Internal Program 5 36–40 Internal Program 6 41–45 Internal Program 7 46–50 Internal Program 8 51–55 Internal Program 9 56–60 Internal Program 10 61–65 Internal Program 11 66–70 Internal Program 12 71–75 Internal Program 13 76–80 Internal Program 14 81–85 Internal Program 15 86–90 Internal Program 16 91–95 Internal Program 17 96–100 Internal Program 18 101–105 Internal Program 19 106–110 Internal Program 20 111–115 Internal Program 21 116–120 Internal Program 22 121–125 Internal Program 23 126–130 Internal Program 24 131–135 Internal Program 25 136–140 Internal Program 26 141–145 Internal Program 27 146–150 Internal Program 28 151–155 Internal Program 29 156–160 Internal Program 30 161–165 Internal Program 31 166–170 Internal Program 32 171–175 Internal Program 33 176–180 Internal Program 34 181–185 Internal Program 35 186–190 Internal Program 36 191–195 Internal Program 37 196–200 Internal Program 38 201–205 Internal Program 39 206–210 Internal Program 40 211–215 Internal Program 41 216–220 Internal Program 42 221–225 Internal Program 43 226–230 Internal Program 44 231–235 Internal Program 45 236–245 Sound Control 1 246–255 Sound Control 2
110	Effect Speed	0	
111	Effects1Fade	0	