Artfox

Sky Beam LED 300W



Manufacturer	**Artfox**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**25 channels**
Beam angle	**5-45°**
Pan range	**540°**
Tilt range	**270°**
Size (W × H × D)	**240 × 450 × 220 mm**
GDTF fixture type	**904B8FF6-969E-454F-8B70-E94…**

Controls

Focus · Frost · Prism · Prism rotation · Extra LED colours · RGB colour mixing · Colour wheel · Strobe · Dimmer · Pan and tilt · Movement speed · Gobos

Safety-relevant functions

Fixture reset

DMX modes

25 Channel — 25 ch

25 Channel

25 channels

Ch	Function	Default	DMX values
1	Pan	0	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	0	
4	Tilt Fine	0	Fine byte of Tilt
5	Position MSpeed	0	
6	Dimmer	0	
7	Shutter / Strobe	0	0–7 Open 8–250 Strobe Speed 251–255 Open
8	Color Wheel	0	0–0 Open (wheel slot 1) 1–31 Red (wheel slot 2) 32–47 Green (wheel slot 3) 48–63 Yellow (wheel slot 4) 64–79 Blue (wheel slot 5) 80–95 Magenta (wheel slot 6) 96–111 Orange (wheel slot 7) 112–127 Cyan (wheel slot 8) 128–191 Color CW 192–255 Color CCW
9	Color Wheel Fine	0	Fine byte of Color Wheel
10	Gobo	0	0–6 Open (wheel slot 1) 7–13 Wheel Slot 2 (wheel slot 2) 14–20 Wheel Slot 3 (wheel slot 3) 21–27 Wheel Slot 4 (wheel slot 4) 28–34 Wheel Slot 5 (wheel slot 5) 35–41 Wheel Slot 6 (wheel slot 6) 42–48 Wheel Slot 7 (wheel slot 7) 49–55 Wheel Slot 8 (wheel slot 8) 56–70 Wheel Slot 9 (wheel slot 9) 71–77 Wheel Slot 8 (wheel slot 8) 78–84 Wheel Slot 7 (wheel slot 7) 85–91 Wheel Slot 6 (wheel slot 6) 92–98 Wheel Slot 5 (wheel slot 5) 99–105 Wheel Slot 4 (wheel slot 4) 106–112 Wheel Slot 3 (wheel slot 3) 113–119 Wheel Slot 2 (wheel slot 2) 120–127 Open (wheel slot 1) 128–191 Gobo 1 CW 192–255 Gobo 1 CCW
11	Gobo 2	0	0–15 Open (wheel slot 1) 16–31 Wheel Slot 2 (wheel slot 2) 32–47 Wheel Slot 3 (wheel slot 3) 48–63 Wheel Slot 4 (wheel slot 4) 64–79 Wheel Slot 5 (wheel slot 5) 80–95 Wheel Slot 6 (wheel slot 6) 96–111 Wheel Slot 7 (wheel slot 7) 112–127 Wheel Slot 8 (wheel slot 8) 128–191 Gobo 2 CW 192–255 Gobo 2 CCW
12	No Feature	0	0–14 Gobo 2 Rotate 15–255 Gobo2 Pos 2
13	Focus	0	
14	Prism	0	0–63 No Prism (wheel slot 1) 64–255 8 Facet Prism (wheel slot 2)
15	Prism	0	0–63 Open (wheel slot 1) 64–255 Wheel Slot 2 (wheel slot 2)
16	Prism Rotation	0	

25 Channel (continued)

Ch	Function	Default	DMX values
17	Frost1	0	
18	Dimmer	0	
19	Shutter / Strobe	0	0–24 Shutter1 1 25–255 Shutter1Strobe 2
20	Color RGBRed	0	
21	Color RGBGreen	0	
22	Color RGBBlue	0	
23	White	0	
24	Color Effects1	0	0–10 NoFeature 1 11–20 Wheel Slot 1 (wheel slot 1) 21–30 Wheel Slot 2 (wheel slot 2) 31–40 Wheel Slot 3 (wheel slot 3) 41–50 Wheel Slot 4 (wheel slot 4) 51–60 Wheel Slot 5 (wheel slot 5) 61–70 Wheel Slot 6 (wheel slot 6) 71–80 Wheel Slot 7 (wheel slot 7) 81–90 Wheel Slot 8 (wheel slot 8) 91–100 Wheel Slot 9 (wheel slot 9) 101–110 Wheel Slot 10 (wheel slot 10) 111–120 Wheel Slot 11 (wheel slot 11) 121–130 Wheel Slot 12 (wheel slot 12) 131–140 Wheel Slot 13 (wheel slot 13) 141–150 Wheel Slot 14 (wheel slot 14) 151–160 Wheel Slot 15 (wheel slot 15) 161–255 Wheel Slot 16 (wheel slot 16)
25	Fixture Global Reset	0	