Atomic Pro

Rudy Wash MKII RGBW



Manufacturer	**Atomic Pro**
Type	**Profile spot**
DMX modes	**3**
DMX footprint	**25, 26, 58 channels**
Beam angle	**5°**
Pan range	**1°**
Tilt range	**1°**
Heads / cells	**9**
Size (W × H × D)	**210 × 300 × 210 mm**
GDTF fixture type	**484177D0-36FE-47EA-918E-B1…**

Controls

Zoom · Extra LED colours · RGB colour mixing · Colour wheel · Strobe · Dimmer · Pixel control · Pan and tilt · Movement speed

Safety-relevant functions

Fixture reset · Service functions · Strobe

DMX modes

25ch	25 ch
26ch	26 ch
58ch	58 ch

25ch

25 channels

Ch	Function	Default	DMX values
1	Pan	0	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	0	
4	Tilt Fine	0	Fine byte of Tilt
5	Position MSpeed	0	
6	Zoom	0	
7	Beam Shaper Pos Rotate	0	
8	Dimmer	0	
9	Shutter / Strobe	0	0–0 Closed 1–254 Strobe 255–255 Open
10	Red	0	
11	Green	0	
12	Blue	0	
13	White	0	
14	Custom Color	0	
15	Color Macro1	0	
16	Shaper Macros Speed	0	
17	Color Sub R	0	
18	Color Sub G	0	
19	Color Sub B	0	
20	Color Add CW	0	
21	Fixture Global Reset	0	0–249 FixtureGlobalReset 1 250–255 FixtureGlobalReset 2
22	Dimmer	0	
23	Strobe Rate	0	
24	Shaper Macros Speed	0	
25	Color Macro1	0	

26ch

26 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Green	0	
3	Blue	0	
4	White	0	
5	Color Calibration Mode	0	
6	Color Macro1	0	
7	Strobe Rate	0	0–0 Closed 1–254 StrobeRate 2 255–255 Open
8	Dimmer	0	
9	Dimmer Fine	0	Fine byte of Dimmer
10	Pan	0	
11	Pan Fine	0	Fine byte of Pan
12	Tilt	0	
13	Tilt Fine	0	Fine byte of Tilt

26ch (continued)

Ch	Function	Default	DMX values
14	Zoom	0	
15	Beam Shaper Pos Rotate	0	
16	No Feature	0	
17	Fixture Global Reset	0	0–249 FixtureGlobalReset 1 250–255 FixtureGlobalReset 2
18	Dimmer	0	
19	Strobe Rate	0	
20	Red	0	
21	Green	0	
22	Blue	0	
23	Color Macro1	0	
24	Shaper Macros Speed	0	
25	Color Mix Mode	0	
26	Dimmer Mode	0	

58ch

58 channels

Ch	Function	Default	DMX values
1	Pan	0	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	0	
4	Tilt Fine	0	Fine byte of Tilt
5	Position MSpeed	0	
6	Zoom	0	
7	Beam Shaper Pos Rotate	0	
8	Dimmer	0	
9	Strobe Rate	0	0–0 StrobeRate 1 1–254 StrobeRate 2 255–255 Dimmer 3
10	Red	0	
11	Green	0	
12	Blue	0	
13	White	0	
14	Color Effects1	0	
15	Color Macro1	0	
16	Shaper Macros Speed	0	
17	Color Sub R	0	
18	Color Sub G	0	
19	Color Sub B	0	
20	Color Add CW	0	
21	Fixture Global Reset	0	0–248 No function 249–255 reset
22	Red	0	
23	Green	0	
24	Blue	0	
25	White	0	
26	Red	0	

58ch (continued)

Ch	Function	Default	DMX values
27	Green	0	
28	Blue	0	
29	White	0	
30	Red	0	
31	Green	0	
32	Blue	0	
33	White	0	
34	Red	0	
35	Green	0	
36	Blue	0	
37	White	0	
38	Red	0	
39	Green	0	
40	Blue	0	
41	White	0	
42	Red	0	
43	Green	0	
44	Blue	0	
45	White	0	
46	Red	0	
47	Green	0	
48	Blue	0	
49	White	0	
50	Dimmer	0	
51	Strobe Rate	0	
52	Red	0	
53	Green	0	
54	Blue	0	
55	Color Macro1	0	
56	Shaper Macros Speed	0	
57	Color Control	0	
58	Dimmer	0	