BeamZ

BS 1200 Combi Strobe



Manufacturer	**BeamZ**
Type	**Strobe**
DMX modes	**7**
DMX footprint	**7, 14, 21, 72 channels**
Beam angle	**70°**
Heads / cells	**3**
Size (W × H × D)	**525 × 195 × 45 mm**
GDTF fixture type	**DF7A4BBF-43AA-46D5-AF85-B…**

Controls

Extra LED colours · Colour temperature · Effect speed · Strobe · Dimmer · Pixel control

Safety-relevant functions

Built-in effect programmes

DMX modes

7 Ch	7 ch
7 Ch + Virtual Dimmer	7 ch
14 Ch	14 ch
21 Ch	21 ch
150 Ch Pixel Control + Virtual Dimmer	72 ch
150 Ch Pixel Control + Virtual Dimmer EXTENDED	72 ch
150 Ch Pixel Control Basic	72 ch

7 Ch

7 channels

Ch	Function	Default	DMX values
1	Red	255	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
2	Green	255	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
3	Blue	255	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
4	Dimmer	0	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
5	Color Add CW	0	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
6	Color Add WW	255	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
7	Shutter / Strobe	0	0–0 000 1–63 Shutter 1 Strobe · 001 1–5.64 Hz 64–127 Shutter 1 Strobe · 025 5.71–10.4 Hz 128–191 Shutter 1 Strobe · 050 10.5–15.2 Hz 192–254 Shutter 1 Strobe · 075 15.3–19.9 Hz 255–255 Shutter 1 Strobe · 100 20 Hz

7 Ch + Virtual Dimmer

7 channels

Ch	Function	Default	DMX values
1	Red	255	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
2	Green	255	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
3	Blue	255	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100

7 Ch + Virtual Dimmer (continued)

Ch	Function	Default	DMX values
4	Dimmer	0	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
5	Color Add CW	0	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
6	Color Add WW	255	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
7	Shutter / Strobe	0	0–0 000 1–63 Shutter 1 Strobe · 001 1–5.64 Hz 64–127 Shutter 1 Strobe · 025 5.71–10.4 Hz 128–191 Shutter 1 Strobe · 050 10.5–15.2 Hz 192–254 Shutter 1 Strobe · 075 15.3–19.9 Hz 255–255 Shutter 1 Strobe · 100 20 Hz

14 Ch

14 channels

Ch	Function	Default	DMX values
1	Red	255	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
2	Green	255	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
3	Blue	255	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
4	Dimmer	0	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
5	Color Add CW	0	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
6	Color Add WW	255	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100

14 Ch (continued)

Ch	Function	Default	DMX values
7	C TC	0	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
8	Shutter / Strobe	0	0–0 000 1–63 Shutter 1 Strobe · 001 1–5.64 Hz 64–127 Shutter 1 Strobe · 025 5.71–10.4 Hz 128–191 Shutter 1 Strobe · 050 10.5–15.2 Hz 192–254 Shutter 1 Strobe · 075 15.3–19.9 Hz 255–255 Shutter 1 Strobe · 100 20 Hz
9	Effect	0	0–7 Wheel Slot 0 Open (wheel slot 1) 8–15 Wheel Slot 1 (wheel slot 2) 16–23 Wheel Slot 2 (wheel slot 3) 24–31 Wheel Slot 3 (wheel slot 4) 32–39 Wheel Slot 4 (wheel slot 5) 40–47 Wheel Slot 5 (wheel slot 6) 48–55 Wheel Slot 6 (wheel slot 7) 56–63 Wheel Slot 7 (wheel slot 8) 64–71 Wheel Slot 8 (wheel slot 9) 72–79 Wheel Slot 9 (wheel slot 10) 80–87 Wheel Slot 10 (wheel slot 11) 88–95 Wheel Slot 11 (wheel slot 12) 96–103 Wheel Slot 12 (wheel slot 13) 104–111 Wheel Slot 13 (wheel slot 14) 112–119 Wheel Slot 14 (wheel slot 15) 120–127 Wheel Slot 15 (wheel slot 16) 128–135 Wheel Slot 16 (wheel slot 17) 136–143 Wheel Slot 17 (wheel slot 18) 144–151 Wheel Slot 18 (wheel slot 19) 152–159 Wheel Slot 19 (wheel slot 20) 160–167 Wheel Slot 20 (wheel slot 21) 168–175 Wheel Slot 21 (wheel slot 22) 176–183 Wheel Slot 22 (wheel slot 23) 184–191 Wheel Slot 23 (wheel slot 24) 192–199 Wheel Slot 24 (wheel slot 25) 200–207 Wheel Slot 25 (wheel slot 26) 208–215 Wheel Slot 26 (wheel slot 27) 216–223 Wheel Slot 27 (wheel slot 28) 224–231 Wheel Slot 28 (wheel slot 29) 232–239 Wheel Slot 29 (wheel slot 30) 240–247 Wheel Slot 30 (wheel slot 31) 248–255 Wheel Slot 31 (wheel slot 32)
10	Effect Speed	0	0–0 000 1–63 001 64–127 025 128–191 050 192–254 075 255–255 100

14 Ch (continued)

Ch	Function	Default	DMX values
11	Effect	0	0–7 Wheel Slot 0 Open (wheel slot 1) 8–15 Wheel Slot 1 (wheel slot 2) 16–23 Wheel Slot 2 (wheel slot 3) 24–31 Wheel Slot 3 (wheel slot 4) 32–39 Wheel Slot 4 (wheel slot 5) 40–47 Wheel Slot 5 (wheel slot 6) 48–55 Wheel Slot 6 (wheel slot 7) 56–63 Wheel Slot 7 (wheel slot 8) 64–71 Wheel Slot 8 (wheel slot 9) 72–79 Wheel Slot 9 (wheel slot 10) 80–87 Wheel Slot 10 (wheel slot 11) 88–95 Wheel Slot 11 (wheel slot 12) 96–103 Wheel Slot 12 (wheel slot 13) 104–111 Wheel Slot 13 (wheel slot 14) 112–119 Wheel Slot 14 (wheel slot 15) 120–127 Wheel Slot 15 (wheel slot 16) 128–135 Wheel Slot 16 (wheel slot 17) 136–143 Wheel Slot 17 (wheel slot 18) 144–151 Wheel Slot 18 (wheel slot 19) 152–159 Wheel Slot 19 (wheel slot 20) 160–167 Wheel Slot 20 (wheel slot 21) 168–175 Wheel Slot 21 (wheel slot 22) 176–183 Wheel Slot 22 (wheel slot 23) 184–191 Wheel Slot 23 (wheel slot 24) 192–199 Wheel Slot 24 (wheel slot 25) 200–207 Wheel Slot 25 (wheel slot 26) 208–215 Wheel Slot 26 (wheel slot 27) 216–223 Wheel Slot 27 (wheel slot 28) 224–231 Wheel Slot 28 (wheel slot 29) 232–239 Wheel Slot 29 (wheel slot 30) 240–247 Wheel Slot 30 (wheel slot 31) 248–255 Wheel Slot 31 (wheel slot 32)
12	Effect Speed	0	0–0 000 1–63 001 64–127 025 128–191 050 192–254 075 255–255 100

14 Ch (continued)

Ch	Function	Default	DMX values
13	Effect	0	0–7 Wheel Slot 0 Open (wheel slot 1) 8–15 Wheel Slot 1 (wheel slot 2) 16–23 Wheel Slot 2 (wheel slot 3) 24–31 Wheel Slot 3 (wheel slot 4) 32–39 Wheel Slot 4 (wheel slot 5) 40–47 Wheel Slot 5 (wheel slot 6) 48–55 Wheel Slot 6 (wheel slot 7) 56–63 Wheel Slot 7 (wheel slot 8) 64–71 Wheel Slot 8 (wheel slot 9) 72–79 Wheel Slot 9 (wheel slot 10) 80–87 Wheel Slot 10 (wheel slot 11) 88–95 Wheel Slot 11 (wheel slot 12) 96–103 Wheel Slot 12 (wheel slot 13) 104–111 Wheel Slot 13 (wheel slot 14) 112–119 Wheel Slot 14 (wheel slot 15) 120–127 Wheel Slot 15 (wheel slot 16) 128–135 Wheel Slot 16 (wheel slot 17) 136–143 Wheel Slot 17 (wheel slot 18) 144–151 Wheel Slot 18 (wheel slot 19) 152–159 Wheel Slot 19 (wheel slot 20) 160–167 Wheel Slot 20 (wheel slot 21) 168–175 Wheel Slot 21 (wheel slot 22) 176–183 Wheel Slot 22 (wheel slot 23) 184–191 Wheel Slot 23 (wheel slot 24) 192–199 Wheel Slot 24 (wheel slot 25) 200–207 Wheel Slot 25 (wheel slot 26) 208–215 Wheel Slot 26 (wheel slot 27) 216–223 Wheel Slot 27 (wheel slot 28) 224–231 Wheel Slot 28 (wheel slot 29) 232–239 Wheel Slot 29 (wheel slot 30) 240–247 Wheel Slot 30 (wheel slot 31) 248–255 Wheel Slot 31 (wheel slot 32)
14	Effect Speed	0	0–0 000 1–63 001 64–127 025 128–191 050 192–254 075 255–255 100

21 Ch

21 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
2	Red	255	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
3	Green	255	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100

21 Ch (continued)

Ch	Function	Default	DMX values
4	Blue	255	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
5	Dimmer	0	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
6	Color Add CW	0	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
7	Color Add WW	255	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
8	C TC	0	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
9	Effect	0	0–7 Wheel Slot 0 Open (wheel slot 1) 8–15 Wheel Slot 1 (wheel slot 2) 16–23 Wheel Slot 2 (wheel slot 3) 24–31 Wheel Slot 3 (wheel slot 4) 32–39 Wheel Slot 4 (wheel slot 5) 40–47 Wheel Slot 5 (wheel slot 6) 48–55 Wheel Slot 6 (wheel slot 7) 56–63 Wheel Slot 7 (wheel slot 8) 64–71 Wheel Slot 8 (wheel slot 9) 72–79 Wheel Slot 9 (wheel slot 10) 80–87 Wheel Slot 10 (wheel slot 11) 88–95 Wheel Slot 11 (wheel slot 12) 96–103 Wheel Slot 12 (wheel slot 13) 104–111 Wheel Slot 13 (wheel slot 14) 112–119 Wheel Slot 14 (wheel slot 15) 120–127 Wheel Slot 15 (wheel slot 16) 128–135 Wheel Slot 16 (wheel slot 17) 136–143 Wheel Slot 17 (wheel slot 18) 144–151 Wheel Slot 18 (wheel slot 19) 152–159 Wheel Slot 19 (wheel slot 20) 160–167 Wheel Slot 20 (wheel slot 21) 168–175 Wheel Slot 21 (wheel slot 22) 176–183 Wheel Slot 22 (wheel slot 23) 184–191 Wheel Slot 23 (wheel slot 24) 192–199 Wheel Slot 24 (wheel slot 25) 200–207 Wheel Slot 25 (wheel slot 26) 208–215 Wheel Slot 26 (wheel slot 27) 216–223 Wheel Slot 27 (wheel slot 28) 224–231 Wheel Slot 28 (wheel slot 29) 232–239 Wheel Slot 29 (wheel slot 30) 240–247 Wheel Slot 30 (wheel slot 31) 248–255 Wheel Slot 31 (wheel slot 32)

21 Ch (continued)

Ch	Function	Default	DMX values
10	Effect Speed	0	0–0 000 1–63 001 64–127 025 128–191 050 192–254 075 255–255 100
11	Shutter / Strobe	0	0–0 000 1–63 Shutter 1 Strobe · 001 1–5.64 Hz 64–127 Shutter 1 Strobe · 025 5.71–10.4 Hz 128–191 Shutter 1 Strobe · 050 10.5–15.2 Hz 192–254 Shutter 1 Strobe · 075 15.3–19.9 Hz 255–255 Shutter 1 Strobe · 100 20 Hz
12	Effect	0	0–7 Wheel Slot 0 Open (wheel slot 1) 8–15 Wheel Slot 1 (wheel slot 2) 16–23 Wheel Slot 2 (wheel slot 3) 24–31 Wheel Slot 3 (wheel slot 4) 32–39 Wheel Slot 4 (wheel slot 5) 40–47 Wheel Slot 5 (wheel slot 6) 48–55 Wheel Slot 6 (wheel slot 7) 56–63 Wheel Slot 7 (wheel slot 8) 64–71 Wheel Slot 8 (wheel slot 9) 72–79 Wheel Slot 9 (wheel slot 10) 80–87 Wheel Slot 10 (wheel slot 11) 88–95 Wheel Slot 11 (wheel slot 12) 96–103 Wheel Slot 12 (wheel slot 13) 104–111 Wheel Slot 13 (wheel slot 14) 112–119 Wheel Slot 14 (wheel slot 15) 120–127 Wheel Slot 15 (wheel slot 16) 128–135 Wheel Slot 16 (wheel slot 17) 136–143 Wheel Slot 17 (wheel slot 18) 144–151 Wheel Slot 18 (wheel slot 19) 152–159 Wheel Slot 19 (wheel slot 20) 160–167 Wheel Slot 20 (wheel slot 21) 168–175 Wheel Slot 21 (wheel slot 22) 176–183 Wheel Slot 22 (wheel slot 23) 184–191 Wheel Slot 23 (wheel slot 24) 192–199 Wheel Slot 24 (wheel slot 25) 200–207 Wheel Slot 25 (wheel slot 26) 208–215 Wheel Slot 26 (wheel slot 27) 216–223 Wheel Slot 27 (wheel slot 28) 224–231 Wheel Slot 28 (wheel slot 29) 232–239 Wheel Slot 29 (wheel slot 30) 240–247 Wheel Slot 30 (wheel slot 31) 248–255 Wheel Slot 31 (wheel slot 32)
13	Effect Speed	0	0–0 000 1–63 001 64–127 025 128–191 050 192–254 075 255–255 100
14	Shutter / Strobe	0	0–8 000 9–70 Shutter 1 Strobe · 001 1–5.71 Hz 71–132 Shutter 1 Strobe · 025 5.79–10.5 Hz 133–194 Shutter 1 Strobe · 050 10.6–15.3 Hz 195–254 Shutter 1 Strobe · 075 15.4–19.9 Hz 255–255 Shutter 1 Strobe · 100 20 Hz

21 Ch (continued)

Ch	Function	Default	DMX values
15	Effect	0	0–7 Wheel Slot 0 Open (wheel slot 1) 8–15 Wheel Slot 1 (wheel slot 2) 16–23 Wheel Slot 2 (wheel slot 3) 24–31 Wheel Slot 3 (wheel slot 4) 32–39 Wheel Slot 4 (wheel slot 5) 40–47 Wheel Slot 5 (wheel slot 6) 48–55 Wheel Slot 6 (wheel slot 7) 56–63 Wheel Slot 7 (wheel slot 8) 64–71 Wheel Slot 8 (wheel slot 9) 72–79 Wheel Slot 9 (wheel slot 10) 80–87 Wheel Slot 10 (wheel slot 11) 88–95 Wheel Slot 11 (wheel slot 12) 96–103 Wheel Slot 12 (wheel slot 13) 104–111 Wheel Slot 13 (wheel slot 14) 112–119 Wheel Slot 14 (wheel slot 15) 120–127 Wheel Slot 15 (wheel slot 16) 128–135 Wheel Slot 16 (wheel slot 17) 136–143 Wheel Slot 17 (wheel slot 18) 144–151 Wheel Slot 18 (wheel slot 19) 152–159 Wheel Slot 19 (wheel slot 20) 160–167 Wheel Slot 20 (wheel slot 21) 168–175 Wheel Slot 21 (wheel slot 22) 176–183 Wheel Slot 22 (wheel slot 23) 184–191 Wheel Slot 23 (wheel slot 24) 192–199 Wheel Slot 24 (wheel slot 25) 200–207 Wheel Slot 25 (wheel slot 26) 208–215 Wheel Slot 26 (wheel slot 27) 216–223 Wheel Slot 27 (wheel slot 28) 224–231 Wheel Slot 28 (wheel slot 29) 232–239 Wheel Slot 29 (wheel slot 30) 240–247 Wheel Slot 30 (wheel slot 31) 248–255 Wheel Slot 31 (wheel slot 32)
16	Effect Speed	0	0–0 000 1–63 001 64–127 025 128–191 050 192–254 075 255–255 100
17	Shutter / Strobe	0	0–8 000 9–70 Shutter 1 Strobe · 001 1–5.71 Hz 71–132 Shutter 1 Strobe · 025 5.79–10.5 Hz 133–194 Shutter 1 Strobe · 050 10.6–15.3 Hz 195–254 Shutter 1 Strobe · 075 15.4–19.9 Hz 255–255 Shutter 1 Strobe · 100 20 Hz
18	Red	0	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
19	Green	0	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
20	Blue	0	0–63 000 64–127 025 128–191 050 192–254 075 255–255 100
21	Effects1Adjust1	0	0–128 CW 129–255 CCW

150 Ch Pixel Control + Virtual Dimmer

72 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	Reserved 4	0	
5	Reserved 5	0	
6	Reserved 6	0	
7	Reserved 7	0	
8	Reserved 8	0	
9	Reserved 9	0	
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	
21	Reserved 21	0	
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	
29	Reserved 29	0	
30	Reserved 30	0	
31	Reserved 31	0	
32	Reserved 32	0	
33	Reserved 33	0	
34	Reserved 34	0	
35	Reserved 35	0	
36	Reserved 36	0	
37	Reserved 37	0	
38	Reserved 38	0	
39	Reserved 39	0	
40	Reserved 40	0	
41	Reserved 41	0	
42	Reserved 42	0	
43	Reserved 43	0	
44	Reserved 44	0	
45	Reserved 45	0	

150 Ch Pixel Control + Virtual Dimmer (continued)

Ch	Function	Default	DMX values
46	Reserved 46	0	
47	Reserved 47	0	
48	Reserved 48	0	
49	Reserved 49	0	
50	Reserved 50	0	
51	Reserved 51	0	
52	Reserved 52	0	
53	Reserved 53	0	
54	Reserved 54	0	
55	Reserved 55	0	
56	Reserved 56	0	
57	Reserved 57	0	
58	Reserved 58	0	
59	Reserved 59	0	
60	Reserved 60	0	
61	Dimmer	0	
62	Reserved 62	0	
63	Reserved 63	0	
64	Reserved 64	0	
65	Reserved 65	0	
66	Reserved 66	0	
67	Reserved 67	0	
68	Reserved 68	0	
69	Reserved 69	0	
70	Reserved 70	0	
71	Color Add CW	0	
72	Color Add WW	0	

150 Ch Pixel Control + Virtual Dimmer EXTENDED

72 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	Reserved 4	0	
5	Reserved 5	0	
6	Reserved 6	0	
7	Reserved 7	0	
8	Reserved 8	0	
9	Reserved 9	0	
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	

150 Ch Pixel Control + Virtual Dimmer EXTENDED (continued)

Ch	Function	Default	DMX values
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	
21	Reserved 21	0	
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	
29	Reserved 29	0	
30	Reserved 30	0	
31	Reserved 31	0	
32	Reserved 32	0	
33	Reserved 33	0	
34	Reserved 34	0	
35	Reserved 35	0	
36	Reserved 36	0	
37	Reserved 37	0	
38	Reserved 38	0	
39	Reserved 39	0	
40	Reserved 40	0	
41	Reserved 41	0	
42	Reserved 42	0	
43	Reserved 43	0	
44	Reserved 44	0	
45	Reserved 45	0	
46	Reserved 46	0	
47	Reserved 47	0	
48	Reserved 48	0	
49	Reserved 49	0	
50	Reserved 50	0	
51	Reserved 51	0	
52	Reserved 52	0	
53	Reserved 53	0	
54	Reserved 54	0	
55	Reserved 55	0	
56	Reserved 56	0	
57	Reserved 57	0	
58	Reserved 58	0	
59	Reserved 59	0	

150 Ch Pixel Control + Virtual Dimmer EXTENDED (continued)

Ch	Function	Default	DMX values
60	Reserved 60	0	
61	Dimmer	0	
62	Reserved 62	0	
63	Reserved 63	0	
64	Reserved 64	0	
65	Reserved 65	0	
66	Reserved 66	0	
67	Reserved 67	0	
68	Reserved 68	0	
69	Reserved 69	0	
70	Reserved 70	0	
71	Color Add CW	255	
72	Color Add WW	255	

150 Ch Pixel Control Basic

72 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	Reserved 4	0	
5	Reserved 5	0	
6	Reserved 6	0	
7	Reserved 7	0	
8	Reserved 8	0	
9	Reserved 9	0	
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	
21	Reserved 21	0	
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	

150 Ch Pixel Control Basic (continued)

Ch	Function	Default	DMX values
29	Reserved 29	0	
30	Reserved 30	0	
31	Reserved 31	0	
32	Reserved 32	0	
33	Reserved 33	0	
34	Reserved 34	0	
35	Reserved 35	0	
36	Reserved 36	0	
37	Reserved 37	0	
38	Reserved 38	0	
39	Reserved 39	0	
40	Reserved 40	0	
41	Reserved 41	0	
42	Reserved 42	0	
43	Reserved 43	0	
44	Reserved 44	0	
45	Reserved 45	0	
46	Reserved 46	0	
47	Reserved 47	0	
48	Reserved 48	0	
49	Reserved 49	0	
50	Reserved 50	0	
51	Reserved 51	0	
52	Reserved 52	0	
53	Reserved 53	0	
54	Reserved 54	0	
55	Reserved 55	0	
56	Reserved 56	0	
57	Reserved 57	0	
58	Reserved 58	0	
59	Reserved 59	0	
60	Reserved 60	0	
61	White	0	
62	Reserved 62	0	
63	Reserved 63	0	
64	Reserved 64	0	
65	Reserved 65	0	
66	Reserved 66	0	
67	Reserved 67	0	
68	Reserved 68	0	
69	Reserved 69	0	
70	Reserved 70	0	
71	Color Add CW	0	
72	Color Add WW	0	