BeamZ

StarColor360 Wash Light



Manufacturer	**BeamZ**
Type	**Effect light**
DMX modes	**8**
DMX footprint	**3, 4, 5, 6, 7, 12 channels**
Beam angle	**20°**
Size (W × H × D)	**400 × 50 × 200 mm**
GDTF fixture type	**61D47631-D7FB-4099-A059-15…**

Controls

Extra LED colours · RGB colour mixing · Colour wheel · Effect speed · Strobe · Dimmer

Safety-relevant functions

Strobe · Built-in effect programmes

DMX modes

ARC1 3 Channels	3 ch
HVS 3 Channels	3 ch
ARC1D 4 Channels	4 ch
ARC2 4 Channels	4 ch
ARC2D 5 Channels	5 ch
ARC2S 6 Channels	6 ch
ARC2S 7 Channels	7 ch
12 Channels	12 ch

ARC1 3 Channels

3 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Green	0	
3	Blue	0	

HVS 3 Channels

3 channels

Ch	Function	Default	DMX values
1	H SBHue	0	
2	H SBSaturation	0	
3	Dimmer	0	

ARC1D 4 Channels

4 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Red	0	
3	Green	0	
4	Blue	0	

ARC2 4 Channels

4 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Green	0	
3	Blue	0	
4	Color Add RY	0	

ARC2D 5 Channels

5 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Red	0	
3	Green	0	
4	Blue	0	
5	Color Add RY	0	

ARC2S 6 Channels

6 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Red	0	
3	Green	0	
4	Blue	0	
5	White	0	
6	Color Add RY	0	

ARC2S 7 Channels

7 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Red	0	
3	Green	0	
4	Blue	0	
5	White	0	
6	Color Add RY	0	
7	Shutter / Strobe	0	

12 Channels

12 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Red	0	
3	Green	0	
4	Blue	0	
5	White	0	
6	Color Add RY	0	
7	Color Macro1	0	0–10 No Function 11–20 Color 1 21–30 Color 2 31–40 Color 3 41–50 Color 4 51–60 Color 5 61–70 Color 6 71–80 Color 7 81–90 Color 8 91–100 Color transition 1 101–110 Color transition 2 111–120 Color transition 3 121–130 Color transition 4 131–140 Color transition 5 141–150 Color transition 6 151–160 Color transition 7 161–170 Color transition 8 171–180 Color transition 9 181–190 Color transition 10 191–200 ALL LED 201–205 White 1 206–210 White 2 211–215 White 3 216–220 White 4 221–225 White 5 226–230 White 6 231–235 White 7 236–240 White 8 241–245 White 9 246–250 White 10 251–255 White 11
8	Shutter / Strobe	0	0–15 No Function 16–255 Strobe

12 Channels (continued)

Ch	Function	Default	DMX values
9	Effect	0	0–9 No Function 10–19 Effect 1 20–29 Effect 2 30–39 Effect 3 40–49 Effect 4 50–59 Effect 5 60–69 Effect 6 70–79 Effect 7 80–89 Effect 8 90–99 Effect 9 100–109 Effect 10 110–255 No Function
10	Effect Speed	0	
11	Dimmer Mode	0	0–49 No Function 50–99 Dimmer speed 1 100–149 Dimmer speed 2 150–199 Dimmer speed 3 200–255 Dimmer speed 4
12	Function	0	