Bright

XLED FX



Manufacturer	**Bright**
Type	**Effect light**
DMX modes	**3**
DMX footprint	**2, 4, 14 channels**
Beam angle	**90°**
Size (W × H × D)	**219 × 273 × 83 mm**
GDTF fixture type	**1E0553C2-7F5D-8019-51BC-65…**

Controls

Strobe · Dimmer

Safety-relevant functions

Built-in effect programmes

DMX modes

2 channel	2 ch
4 channel	4 ch
14 channel	14 ch

2 channel

2 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Shutter / Strobe	0	0–254 Min Strobe 255–255 Max Strobe

4 channel

4 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Strobe Duration	0	0–254 Min Duration 255–255 Max Duration
3	Shutter / Strobe	0	0–254 Min Strobe 255–255 Max Strobe
4	Strobe Mode	0	0–5 Normal 6–42 Pulse Open 43–85 Pulse Close 86–128 Pulse 129–171 Rnd 172–214 Lightning 215–255 Rnd (2)

14 channel

14 channels

Ch	Function	Default	DMX values
1	Dimmer	255	0–254 Closed 255–255 Open
2	Dimmer	255	0–254 Closed 255–255 Open
3	Dimmer	255	0–254 Closed 255–255 Open
4	Dimmer	255	0–254 Closed 255–255 Open
5	Dimmer	255	0–254 Closed 255–255 Open
6	Dimmer	255	0–254 Closed 255–255 Open
7	Dimmer	255	0–254 Closed 255–255 Open
8	Dimmer	255	0–254 Closed 255–255 Open
9	Dimmer	255	0–254 Closed 255–255 Open
10	Dimmer	0	0–254 Closed 255–255 Open

14 channel (continued)

Ch	Function	Default	DMX values
11	Shutter / Strobe	12	0–7 Closed 8–15 Open 16–118 Min Strobe 119–119 Max Strobe 120–127 Open (2) 128–182 StrobeRandom · Min Rnd 0.1–9.82 Hz 183–183 StrobeRandom · Max Rnd 10 Hz 184–190 Open (3) 192–246 Min Audio 247–247 Max Audio 248–255 Open (4)
12	Effect Macros	0	0–9 No Effect 10–28 Effect 1 29–48 Effect 2 49–68 Effect 3 69–88 Effect 4 89–108 Effect 5 109–128 Effect 6 129–148 Effect 7 149–168 Effect 8 169–188 Effect 9 189–208 Effect 10 209–228 Effect 11 229–247 Effect 12 249–255 Audio trig
13	Effect Macro Rate	0	0–254 Min Rate 255–255 Max Rate
14	Dimmer Curve	0	0–31 Instant 32–63 Short rise time 64–95 Medium rise time 96–127 Long rise time 128–158 Extra long rise time 159–255 NoFeature