Briteq

BT - ULTRAZOOM



Manufacturer	**Briteq**
Type	**Effect light**
DMX modes	**6**
DMX footprint	**5, 6, 7, 9, 12, 17 channels**
Beam angle	**4.5-45°**
Size (W × H × D)	**288 × 294 × 188 mm**
GDTF fixture type	**FFEE7FB2-7C5D-4038-B72E-86…**

Controls

Zoom · Extra LED colours · RGB colour mixing · Colour temperature · Colour wheel · Effect speed · Strobe · Dimmer

Safety-relevant functions

Fixture reset · Strobe · Built-in effect programmes

DMX modes

AR2 D	5 ch
AR2 S	6 ch
SSP	7 ch
HSIC	9 ch
TOUR	12 ch
TR16	17 ch

AR2 D

5 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max
2	Red	0	0–0 Min 1–254 Min > Max 255–255 Max
3	Green	0	0–0 Min 1–254 Min > Max 255–255 Max
4	Blue	0	0–0 Min 1–254 Min > Max 255–255 Max
5	White	255	0–0 Min 1–254 Min > Max 255–255 Max

AR2 S

6 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max
2	Red	0	0–0 Min 1–254 Min > Max 255–255 Max
3	Green	0	0–0 Min 1–254 Min > Max 255–255 Max
4	Blue	0	0–0 Min 1–254 Min > Max 255–255 Max
5	White	255	0–0 Min 1–254 Min > Max 255–255 Max
6	Shutter / Strobe	0	0–9 Open - Shutter Open 10–99 Strobe S > F - Strobe 100–109 Open - Shutter Open 110–179 Lightning Strobe S > F - Strobe 180–189 Open - Shutter Open 190–255 Strobe Random S > F - Strobe Random

SSP

7 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max
2	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
3	Green	255	0–0 Min 1–254 Min > Max 255–255 Max

SSP (continued)

Ch	Function	Default	DMX values
4	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
5	White	255	0–0 Min 1–254 Min > Max 255–255 Max
6	Shutter / Strobe	0	0–9 Open - Shutter Open 10–99 Strobe S > F - Strobe 100–109 Open - Shutter Open 110–179 Lightning Strobe S > F - Strobe 180–189 Open - Shutter Open 190–255 Strobe Random S > F - Strobe Random
7	Dimmer Curve	0	0–9 Preset Dim Spd Fr Disp Menu - Speed 10–29 Linear Dimmer - Speed 30–69 Nonlinear Dim Curve 1 (Fastest) - Speed 70–129 Nonlinear Dim Curve 2 - Speed 130–189 Nonlinear Dim Curve 3 - Speed 190–255 Nonlinear Dim Curve 4 (Slowest) - Speed

HSIC

9 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 closed 255–255 open
2	H UE	0	
3	H UE Fine	0	Fine byte of H UE
4	S ATURATION	0	
5	C TC	0	
6	Shutter / Strobe	0	0–9 open 10–254 min Strobe 255–255 max Strobe
7	Zoom	128	0–127 Narrow 128–254 Normal 255–255 Wide
8	Zoom Reset	0	0–199 NoFeature 1 201–219 ZoomReset 220–255 NoFeature
9	Dimmer Curve	0	0–9 From menu 10–29 OFF 30–69 DimCurve 1 70–129 DimCurve 2 130–189 DimCurve 3 190–255 DimCurve 4

TOUR

12 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max
2	Red	0	0–0 Min 1–254 Min > Max 255–255 Max

TOUR (continued)

Ch	Function	Default	DMX values
3	Green	0	0–0 Min 1–254 Min > Max 255–255 Max
4	Blue	0	0–0 Min 1–254 Min > Max 255–255 Max
5	White	255	0–0 Min 1–254 Min > Max 255–255 Max
6	Color Macro1	0	0–10 No Func - Custom 11–30 R:100% G:0-100% B:0 - Color (wheel slot 1) 31–50 R:100%-0 G:100% B:0 - Color (wheel slot 2) 51–70 R:0 G:100% B:0-100% - Color (wheel slot 3) 71–90 R:0 G:100%-0 B:100% - Color (wheel slot 4) 91–110 R:0-100% G:0 B:100% - Color (wheel slot 5) 111–130 R:100% G:0 B:100%-0 - Color (wheel slot 6) 131–150 R:100% G:0-100% B:0-100% - Color (wheel slot 7) 151–170 R:100%-0 G:0-100%-0 B:100% - Color (wheel slot 8) 171–200 RGBW:100% - Color (wheel slot 9) 201–205 White 1 - Color (wheel slot 10) 206–210 White 2 - Color (wheel slot 11) 211–215 White 3 - Color (wheel slot 12) 216–220 White 4 - Color (wheel slot 13) 221–225 White 5 - Color (wheel slot 14) 226–230 White 6 - Color (wheel slot 15) 231–235 White 7 - Color (wheel slot 16) 236–240 White 8 - Color (wheel slot 17) 241–245 White 9 - Color (wheel slot 18) 246–250 White 10 - Color (wheel slot 19) 251–255 White 11 - Color (wheel slot 20)
7	Shutter / Strobe	0	0–9 Open - Shutter Open 10–99 Strobe S > F - Strobe 100–109 Open - Shutter Open 110–179 Lightning Strobe S > F - Strobe 180–189 Open - Shutter Open 190–255 Strobe Random S > F - Strobe Random
8	Effect	0	0–20 No Func - Custom 21–30 Auto 1 - Macro 31–40 Auto 2 - Macro 41–50 Auto 3 - Macro 51–60 Auto 4 - Macro 61–70 Auto 5 - Macro 71–80 Auto 6 - Macro 81–90 Auto 7 - Macro 91–100 Auto 8 - Macro 101–110 Auto 9 - Macro 111–120 Auto 10 - Macro 121–130 Custom 1 - Macro 131–140 Custom 2 - Macro 141–150 Custom 3 - Macro 151–160 Custom 4 - Macro 161–170 Custom 5 - Macro 171–180 Custom 6 - Macro 181–190 Custom 7 - Macro 191–200 Custom 8 - Macro 201–210 Custom 9 - Macro 211–220 Custom 10 - Macro 221–255 No Function - Custom
9	Effect Speed	0	0–0 Min 1–254 Min > Max 255–255 Max

TOUR (continued)

Ch	Function	Default	DMX values
10	Zoom	128	0–127 Narrow 128–254 Normal 255–255 Wide
11	Zoom Reset	0	0–199 NoFeature 1 201–219 ZoomReset 220–255 NoFeature
12	Dimmer Curve	0	0–9 Preset Dim Spd Fr Disp Menu - Speed 10–29 Linear Dimmer - Speed 30–69 Nonlinear Dim Curve 1 (Fastest) - Speed 70–129 Nonlinear Dim Curve 2 - Speed 130–189 Nonlinear Dim Curve 3 - Speed 190–255 Nonlinear Dim Curve 4 (Slowest) - Speed

TR16

17 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	Red	0	
4	Red Fine	0	Fine byte of Red
5	Green	0	
6	Green Fine	0	Fine byte of Green
7	Blue	0	
8	Blue Fine	0	Fine byte of Blue
9	White	255	0–0 Min 1–254 Min > Max 255–255 Max
10	White Fine	255	Fine byte of White
11	Color Macro1	0	0–10 No Func - Custom 11–30 R:100% G:0-100% B:0 - Color (wheel slot 1) 31–50 R:100%-0 G:100% B:0 - Color (wheel slot 2) 51–70 R:0 G:100% B:0-100% - Color (wheel slot 3) 71–90 R:0 G:100%-0 B:100% - Color (wheel slot 4) 91–110 R:0-100% G:0 B:100% - Color (wheel slot 5) 111–130 R:100% G:0 B:100%-0 - Color (wheel slot 6) 131–150 R:100% G:0-100% B:0-100% - Color (wheel slot 7) 151–170 R:100%-0 G:0-100%-0 B:100% - Color (wheel slot 8) 171–200 RGBW:100% - Color (wheel slot 9) 201–205 White 1 - Color (wheel slot 10) 206–210 White 2 - Color (wheel slot 11) 211–215 White 3 - Color (wheel slot 12) 216–220 White 4 - Color (wheel slot 13) 221–225 White 5 - Color (wheel slot 14) 226–230 White 6 - Color (wheel slot 15) 231–235 White 7 - Color (wheel slot 16) 236–240 White 8 - Color (wheel slot 17) 241–245 White 9 - Color (wheel slot 18) 246–250 White 10 - Color (wheel slot 19) 251–255 White 11 - Color (wheel slot 20)
12	Shutter / Strobe	0	0–9 Open - Shutter Open 10–99 Strobe S > F - Strobe 100–109 Open - Shutter Open 110–179 Lightning Strobe S > F - Strobe 180–189 Open - Shutter Open 190–255 Strobe Random S > F - Strobe Random

TR16 (continued)

Ch	Function	Default	DMX values
13	Effect	0	0–20 No Func - Custom 21–30 Auto 1 - Macro 31–40 Auto 2 - Macro 41–50 Auto 3 - Macro 51–60 Auto 4 - Macro 61–70 Auto 5 - Macro 71–80 Auto 6 - Macro 81–90 Auto 7 - Macro 91–100 Auto 8 - Macro 101–110 Auto 9 - Macro 111–120 Auto 10 - Macro 121–130 Custom 1 - Macro 131–140 Custom 2 - Macro 141–150 Custom 3 - Macro 151–160 Custom 4 - Macro 161–170 Custom 5 - Macro 171–180 Custom 6 - Macro 181–190 Custom 7 - Macro 191–200 Custom 8 - Macro 201–210 Custom 9 - Macro 211–220 Custom 10 - Macro 221–255 No Function - Custom
14	Effect Speed	0	0–0 Min 1–254 Min > Max 255–255 Max
15	Zoom	128	0–127 Narrow 128–254 Normal 255–255 Wide
16	Zoom Reset	0	0–199 NoFeature 1 201–219 ZoomReset 220–255 NoFeature
17	Dimmer Curve	0	0–9 Preset Dim Spd Fr Disp Menu - Speed 10–29 Linear Dimmer - Speed 30–69 Nonlinear Dim Curve 1 (Fastest) - Speed 70–129 Nonlinear Dim Curve 2 - Speed 130–189 Nonlinear Dim Curve 3 - Speed 190–255 Nonlinear Dim Curve 4 (Slowest) - Speed