Chauvet Professional

Strike 1



Manufacturer	**Chauvet Professional**
Type	**Blinder**
DMX modes	**6**
DMX footprint	**1, 3, 4, 5, 6, 7 channels**
Beam angle	**30°**
Size (W × H × D)	**379 × 248 × 172 mm**
GDTF fixture type	**89289B34-53A7-11E6-BF2E-F07…**

Controls

Extra LED colours · Colour wheel · Strobe · Dimmer

Safety-relevant functions

Built-in effect programmes

DMX modes

1Ch Mode	1 ch
3Ch Mode	3 ch
4Ch Mode	4 ch
5Ch Mode	5 ch
6Ch Mode	6 ch
7Ch Mode	7 ch

1Ch Mode

1 channel

Ch	Function	Default	DMX values
1	Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max

3Ch Mode

3 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max
2	Color Effects1	0	0–0 ON (Red Shift) 1–255 OFF (Red Shift)
3	Intensity MSpeed	0	0–51 Current Dimmer Spd Mode 52–101 Dim Spd Mode Off 102–152 Dim Spd Mode 1 (Fastest) 153–203 Dim Spd Mode 2 204–255 Dim Spd Mode 3 (Slowest)

4Ch Mode

4 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	Color Effects1	0	0–0 ON (Red Shift) 1–255 OFF (Red Shit)
4	Intensity MSpeed	0	0–51 Current Dimmer Spd Mode 52–101 Dim Spd Mode Off 102–152 Dim Spd Mode 1 (Fastest) 153–203 Dim Spd Mode 2 204–255 Dim Spd Mode 3 (Slowest)

5Ch Mode

5 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max
2	Color Effects1	0	0–0 ON (Red Shift) 1–255 OFF (Red Shift)
3	Shutter / Strobe	0	0–10 Open 11–11 STROBE · Slow 0.1 Hz 12–254 Strobe S > F 255–255 STROBE · Fast 25 Hz
4	Effect	0	0–10 No Funcion 11–80 Auto 1 - S > F 81–160 Auto 2 - S > F 161–240 Auto 3 - S > F 241–255 No Function
5	Intensity MSpeed	0	0–51 Current Dimmer Spd Mode 52–101 Dim Spd Mode Off 102–152 Dim Spd Mode 1 (Fastest) 153–203 Dim Spd Mode 2 204–255 Dim Spd Mode 3 (Slowest)

6Ch Mode

6 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	Color Effects1	0	0–0 ON (Red Shift) 1–255 OFF (Red Shift)
4	Shutter / Strobe	0	0–10 Open 11–11 STROBE · Slow 0.1 Hz 12–254 Strobe S > F 255–255 STROBE · Fast 25 Hz
5	Effect	0	0–10 No Function 11–80 Auto 1 S > F 81–160 Auto 2 S > F 161–240 Auto 3 S > F 241–255 No Function
6	Intensity MSpeed	0	0–51 Current Dimmer Spd Mode 52–101 Dim Spd Mode Off 102–152 Dim Spd Mode 1 (Fastest) 153–203 Dim Spd Mode 2 204–255 Dim Spd Mode 3 (Slowest)

7Ch Mode

7 channels

Ch	Function	Default	DMX values
1	White	255	
2	White Fine	255	Fine byte of White
3	Color Add RY	255	
4	Color Add RY Fine	255	Fine byte of Color Add RY
5	Shutter / Strobe	0	0–10 Open 11–11 STROBE · Slow 0.1 Hz 12–254 Strobe S > F 255–255 STROBE · Fast 25 Hz
6	Effect	0	0–10 No Function 11–80 Auto 1 S > F 81–160 Auto 2 S > F 161–240 Auto 3 S > F 241–255 No Function
7	Intensity MSpeed	0	0–51 Current Dimmer Spd Mode 52–101 Dim Spd Mode Off 102–152 Dim Spd Mode 1 (Fastest) 153–203 Dim Spd Mode 2 204–255 Dim Spd Mode 3 (Slowest)