China

100W Mini LED Beam



Manufacturer	**China**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**12 channels**
Beam angle	**2°**
Pan range	**540°**
Tilt range	**200°**
Size (W × H × D)	**100 × 150 × 110 mm**
GDTF fixture type	**AE5B9D92-DC4A-461F-B736-61…**

Controls

Prism · Colour wheel · Strobe · Dimmer · Pan and tilt · Movement speed · Gobos

Safety-relevant functions

Fixture reset · Strobe

DMX modes

Default	12 ch

Default

12 channels

Ch	Function	Default	DMX values
1	Pan	128	0–127 Min CCW 128–254 Center 255–255 Max CW
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Position MSpeed	0	0–0 Off 1–126 PT Speed Faster 127–127 PT Speed Center 128–255 PT Speed Slower
6	Dimmer	0	0–126 Closed 127–254 50% 255–255 Max
7	Shutter / Strobe	0	0–0 Off 1–126 Strobe Slow 127–200 Strobe Medium 201–255 Strobe Fast
8	Color Wheel	0	0–15 White (wheel slot 1) 16–31 Red (wheel slot 2) 32–47 Yellow (wheel slot 3) 48–63 Blue (wheel slot 4) 64–79 Green (wheel slot 5) 80–95 Magenta (wheel slot 6) 96–111 Orange (wheel slot 7) 112–127 Cyan (wheel slot 8) 128–191 Color Scroll 1-7 Slow to Fast 192–255 Color Scroll 7-1 Slow to Fast
9	Gobo	0	0–7 Open (wheel slot 1) 8–15 Circle (wheel slot 2) 16–23 Wave (wheel slot 3) 24–31 Cross (wheel slot 4) 32–39 Daisy (wheel slot 5) 40–47 Star (wheel slot 6) 48–55 Spin (wheel slot 7) 56–73 Phone (wheel slot 8) 74–82 Spin (wheel slot 7) 83–91 Star (wheel slot 6) 92–100 Daisy (wheel slot 5) 101–109 Cross (wheel slot 4) 110–118 Wave (wheel slot 3) 119–127 Circle (wheel slot 2) 128–191 Gobo Scroll 1-7 Fast to Slow 192–255 Gobo Scroll 7-1 Slow to Fast
10	Prism	0	0–7 Prism Off (wheel slot 1) 8–127 Prism On (wheel slot 2) 128–255 Prism Spin Slow to Fast (wheel slot 2)
11	Function	0	0–49 Off 50–200 Auto 201–255 Sound Activated
12	Fixture Global Reset	0	0–240 Off 241–255 Reset - MUST HOLD FOR 5 SECONDS