CKC Lighting

FlatPar 712



Manufacturer	**CKC Lighting**
Type	**PAR**
DMX modes	**4**
DMX footprint	**6, 7, 8, 12 channels**
Beam angle	**22°**
Size (W × H × D)	**230 × 200 × 203 mm**
GDTF fixture type	**A5D9279C-550C-4BF8-A1DC-F2…**

Controls

Extra LED colours · RGB colour mixing · Colour wheel · Strobe · Dimmer

DMX modes

6CH	6 ch
7CH	7 ch
8CH	8 ch
12CH	12 ch

6CH

6 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Green	0	
3	Blue	0	
4	White	0	
5	Color Add RY	0	
6	UV	0	

7CH

7 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	Color Add RY	255	
6	UV	0	
7	Dimmer	0	0–62 0% 63–127 25% 128–191 50% 192–254 75% 255–255 100%

8CH

8 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	Color Add RY	255	
6	UV	0	
7	Dimmer	0	0–62 0% 63–127 25% 128–191 50% 192–254 75% 255–255 100%
8	Shutter / Strobe	50	0–31 Shutter closed 32–63 Shutter open 64–94 Min strobe 95–95 Strobe · Max stobe 10 Hz 96–127 Shutter open2 128–158 Min pulse 159–159 Max pulse 160–191 Shutter open3 192–222 Min random 223–223 Max random 224–255 Shutter open4

12CH

12 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	Color Add RY	255	
6	UV	0	
7	Dimmer	0	0–62 0% 63–127 25% 128–191 50% 192–254 75% 255–255 100%
8	Shutter / Strobe	50	0–31 Shutter closed 32–63 Shutter open 64–94 Min strobe 95–95 Strobe · Max stobe 10 Hz 96–127 Shutter open2 128–158 Min pulse 159–159 Max pulse 160–191 Shutter open3 192–222 Min random 223–223 Max random 224–255 Shutter open4
9	Color Macro1	0	
10	Color Mix Mode	0	0–20 No function 21–40 Jumping 30 color 41–60 Jumping 6 color 61–80 Dreamy 15 color 81–255 Blackout
11	Color Mix MSpeed	0	
12	Dimmer Mode	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theatre 101–255 According to setting