CKC Lighting

# IP PixBar 200



| | |
|---|---|
| Manufacturer | **CKC Lighting** |
| Type | **PAR** |
| DMX modes | **12** |
| DMX footprint | **3, 4, 5, 7, 9, 10, 12, 37 channels** |
| Beam angle | **25-33°** |
| Size (W × H × D) | **877 × 123 × 178 mm** |
| GDTF fixture type | **46D99336-788D-4F21-8D4C-DB…** |

## Controls

Extra LED colours · RGB colour mixing · Colour temperature · Colour wheel · Strobe · Dimmer

## Safety-relevant functions

Strobe

## DMX modes

| | |
|---|---|
| RGB 3CH | 3 ch |
| RGB Five 3CH | 3 ch |
| HSI 4CH | 4 ch |
| 8Bit 5CH | 5 ch |
| Cells 50CH | 5 ch |
| Cells+Dim 52CH | 5 ch |
| Extended+Cells 57CH | 7 ch |
| HSI Extended 9CH | 9 ch |
| 16Bit 10CH | 10 ch |
| 16Bit+Dim 12CH | 12 ch |
| Extended 12CH | 12 ch |
| HSI+Cells 37CH | 37 ch |

## RGB 3CH

3 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Red | 255 | |
| 2 | Green | 255 | |
| 3 | Blue | 255 | |

## RGB Five 3CH

3 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Red | 255 | |
| 2 | Green | 255 | |
| 3 | Blue | 255 | |

## HSI 4CH

4 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Dimmer | 0 | 0–254 closed<br>255–255 open |
| 2 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 3 | H SBHue | 0 | 0–254 0%<br>255–255 100% |
| 4 | H SBSaturation | 0 | 0–254 0%<br>255–255 100% |

## 8Bit 5CH

5 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Red | 255 | |
| 2 | Green | 255 | |
| 3 | Blue | 255 | |
| 4 | Color Add GY | 255 | |
| 5 | Color Add RY | 255 | |

## Cells 50CH

5 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Red | 255 | |
| 2 | Green | 255 | |
| 3 | Blue | 255 | |
| 4 | Color Add GY | 255 | |
| 5 | Color Add RY | 255 | |

## Cells+Dim 52CH

5 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Dimmer | 0 | 0–254 closed<br>255–255 open |
| 2 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 3 | Blue | 255 | |
| 4 | Color Add GY | 255 | |

### Cells+Dim 52CH (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 5 | Color Add RY | 255 | |

## Extended+Cells 57CH

7 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Shutter / Strobe | 50 | 0–31 Shutter Closed<br>32–63 Shutter Open1<br>64–94 Min Strobe<br>95–95 Max Strobe<br>96–127 Shutter Open2<br>128–158 Min Pulse<br>159–159 Max Pulse<br>160–191 Shutter Open3<br>192–222 Min Random<br>223–223 Max Random<br>224–255 Shutter Open4 |
| 2 | Dimmer | 0 | 0–254 closed<br>255–255 open |
| 3 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 4 | Dimmer Mode | 0 | 0–20 Standard<br>21–40 Stage<br>41–60 TV<br>61–80 Architectural<br>81–100 Theatre<br>101–120 Stage 2<br>121–255 Idle |
| 5 | C TO | 0 | |

## Extended+Cells 57CH (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **6** | Color Wheel | 0 | 0–0 Open1 (wheel slot 54)<br>1–1 Pale Yellow (wheel slot 1)<br>2–2 Straw (wheel slot 2)<br>3–3 Gold Tint (wheel slot 3)<br>4–4 Spring Yellow (wheel slot 4)<br>5–5 Medium Yellow (wheel slot 5)<br>6–6 Yellow (wheel slot 6)<br>7–7 Deep Amber (wheel slot 7)<br>8–8 Deep Straw (wheel slot 8)<br>9–9 Loving Amber (wheel slot 9)<br>10–10 Gold Amber (wheel slot 10)<br>11–11 Orange (wheel slot 11)<br>12–12 Deep Orange (wheel slot 12)<br>13–13 Dark Amber (wheel slot 13)<br>14–14 Millennium Gold (wheel slot 14)<br>15–15 Deep Golden Amber (wheel slot 15)<br>16–16 Scarlet (wheel slot 16)<br>17–17 Primary Red (wheel slot 17)<br>18–18 Bright Red (wheel slot 18)<br>19–19 Medium Red (wheel slot 19)<br>20–20 Fire (wheel slot 20)<br>21–21 Pink (wheel slot 21)<br>22–22 Medium Pink (wheel slot 22)<br>23–23 Dark Pink (wheel slot 23)<br>24–24 Bright Pink (wheel slot 24)<br>25–25 Bright Rose (wheel slot 25)<br>26–26 Special Rose Pink (wheel slot 26)<br>27–27 Vanity Fair (wheel slot 27)<br>28–28 Magenta (wheel slot 28)<br>29–29 Dark Magenta (wheel slot 29)<br>30–30 Rose Purple (wheel slot 30)<br>31–31 Mauve (wheel slot 31)<br>32–32 Medium Purple (wheel slot 32)<br>33–33 Lavender (wheel slot 33)<br>34–34 Palace blue (wheel slot 34)<br>35–35 Dark Blue (wheel slot 35)<br>36–36 Medium Blue (wheel slot 36)<br>37–37 Deep Blue (wheel slot 37)<br>38–38 Daylight Blue (wheel slot 38)<br>39–39 Slate Blue (wheel slot 39)<br>40–40 Light Blue (wheel slot 40)<br>41–41 Sky Blue (wheel slot 41)<br>42–42 Pale Navy Blue (wheel slot 42)<br>43–43 Marine Blue (wheel slot 43)<br>44–44 Peacock Blue (wheel slot 44)<br>45–45 Lagoon Blue (wheel slot 45)<br>46–46 Medium Blue Green (wheel slot 46)<br>47–47 Dark Yellow Green (wheel slot 47)<br>48–48 Primary Green (wheel slot 48)<br>49–49 Fern Green (wheel slot 49)<br>50–50 Moss Green (wheel slot 50)<br>51–51 Dark Green (wheel slot 51)<br>52–52 Lime Green (wheel slot 52)<br>53–53 Pale Green (wheel slot 53)<br>54–179 Open2<br>180–200 Clockwise fast<br>201–201 Clockwise slow<br>202–207 Stop<br>208–228 Counter-clockwise slow<br>229–229 Counter-clockwise fast<br>230–234 Open3<br>235–239 Fast<br>240–244 Medium<br>245–249 Slow |

### Extended+Cells 57CH (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **7** | Control1 | 0 | 0–100 Idle<br>101–105 900<br>106–110 1000<br>111–115 1100<br>116–120 1200<br>121–125 1300<br>126–130 1400<br>131–135 1500<br>136–140 2500<br>141–145 4000<br>146–150 5000<br>151–155 10000<br>156–160 15000<br>161–165 20000<br>166–170 25000<br>171–200 Idle<br>201–210 Dimmer Curve Linear (default)<br>211–220 Dimmer Curve Square<br>221–230 Dimmer Curve Inverse Square<br>231–240 Dimmer Curve S-Curve<br>241–255 Idle |

## HSI Extended 9CH

9 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **1** | Shutter / Strobe | 50 | 0–31 Shutter Closed<br>32–63 Shutter Open1<br>64–94 Min Strobe<br>95–95 Max Strobe<br>96–127 Shutter Open2<br>128–158 Min Pulse<br>159–159 Max Pulse<br>160–191 Shutter Open3<br>192–222 Min Random<br>223–223 Max Random<br>224–255 Shutter Open4 |
| **2** | Dimmer | 0 | 0–254 closed<br>255–255 open |
| **3** | Dimmer Fine | 0 | Fine byte of Dimmer |
| **4** | Dimmer Mode | 0 | 0–20 Standard<br>21–40 Stage<br>41–60 TV<br>61–80 Architectural<br>81–100 Theatre<br>101–120 Stage 2<br>121–255 Idle |
| **5** | C TO | 0 | |

## HSI Extended 9CH (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **6** | Color Wheel | 0 | 0–0 Open1 (wheel slot 54)<br>1–1 Pale Yellow (wheel slot 1)<br>2–2 Straw (wheel slot 2)<br>3–3 Gold Tint (wheel slot 3)<br>4–4 Spring Yellow (wheel slot 4)<br>5–5 Medium Yellow (wheel slot 5)<br>6–6 Yellow (wheel slot 6)<br>7–7 Deep Amber (wheel slot 7)<br>8–8 Deep Straw (wheel slot 8)<br>9–9 Loving Amber (wheel slot 9)<br>10–10 Gold Amber (wheel slot 10)<br>11–11 Orange (wheel slot 11)<br>12–12 Deep Orange (wheel slot 12)<br>13–13 Dark Amber (wheel slot 13)<br>14–14 Millennium Gold (wheel slot 14)<br>15–15 Deep Golden Amber (wheel slot 15)<br>16–16 Scarlet (wheel slot 16)<br>17–17 Primary Red (wheel slot 17)<br>18–18 Bright Red (wheel slot 18)<br>19–19 Medium Red (wheel slot 19)<br>20–20 Fire (wheel slot 20)<br>21–21 Pink (wheel slot 21)<br>22–22 Medium Pink (wheel slot 22)<br>23–23 Dark Pink (wheel slot 23)<br>24–24 Bright Pink (wheel slot 24)<br>25–25 Bright Rose (wheel slot 25)<br>26–26 Special Rose Pink (wheel slot 26)<br>27–27 Vanity Fair (wheel slot 27)<br>28–28 Magenta (wheel slot 28)<br>29–29 Dark Magenta (wheel slot 29)<br>30–30 Rose Purple (wheel slot 30)<br>31–31 Mauve (wheel slot 31)<br>32–32 Medium Purple (wheel slot 32)<br>33–33 Lavender (wheel slot 33)<br>34–34 Palace blue (wheel slot 34)<br>35–35 Dark Blue (wheel slot 35)<br>36–36 Medium Blue (wheel slot 36)<br>37–37 Deep Blue (wheel slot 37)<br>38–38 Daylight Blue (wheel slot 38)<br>39–39 Slate Blue (wheel slot 39)<br>40–40 Light Blue (wheel slot 40)<br>41–41 Sky Blue (wheel slot 41)<br>42–42 Pale Navy Blue (wheel slot 42)<br>43–43 Marine Blue (wheel slot 43)<br>44–44 Peacock Blue (wheel slot 44)<br>45–45 Lagoon Blue (wheel slot 45)<br>46–46 Medium Blue Green (wheel slot 46)<br>47–47 Dark Yellow Green (wheel slot 47)<br>48–48 Primary Green (wheel slot 48)<br>49–49 Fern Green (wheel slot 49)<br>50–50 Moss Green (wheel slot 50)<br>51–51 Dark Green (wheel slot 51)<br>52–52 Lime Green (wheel slot 52)<br>53–53 Pale Green (wheel slot 53)<br>54–179 Open2<br>180–200 Clockwise fast<br>201–201 Clockwise slow<br>202–207 Stop<br>208–228 Counter-clockwise slow<br>229–229 Counter-clockwise fast<br>230–234 Open3<br>235–239 Fast<br>240–244 Medium<br>245–249 Slow |

### HSI Extended 9CH (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 7 | Control1 | 0 | 0–100 Idle<br>101–105 900<br>106–110 1000<br>111–115 1100<br>116–120 1200<br>121–125 1300<br>126–130 1400<br>131–135 1500<br>136–140 2500<br>141–145 4000<br>146–150 5000<br>151–155 10000<br>156–160 15000<br>161–165 20000<br>166–170 25000<br>171–200 Idle<br>201–210 Dimmer Curve Linear (default)<br>211–220 Dimmer Curve Square<br>221–230 Dimmer Curve Inverse Square<br>231–240 Dimmer Curve S-Curve<br>241–255 Idle |
| 8 | H SBHue | 0 | 0–254 0%<br>255–255 100% |
| 9 | H SBSaturation | 0 | 0–254 0%<br>255–255 100% |

## 16Bit 10CH

10 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Red | 255 | |
| 2 | Red Fine | 255 | Fine byte of Red |
| 3 | Green | 255 | |
| 4 | Green Fine | 255 | Fine byte of Green |
| 5 | Blue | 255 | |
| 6 | Blue Fine | 255 | Fine byte of Blue |
| 7 | Color Add GY | 255 | |
| 8 | Color Add GY Fine | 255 | Fine byte of Color Add GY |
| 9 | Color Add RY | 255 | |
| 10 | Color Add RY Fine | 255 | Fine byte of Color Add RY |

## 16Bit+Dim 12CH

12 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Dimmer | 0 | 0–254 closed<br>255–255 open |
| 2 | Dimmer Fine | 0 | Fine byte of Dimmer |
| 3 | Red | 255 | |
| 4 | Red Fine | 255 | Fine byte of Red |
| 5 | Green | 255 | |
| 6 | Green Fine | 255 | Fine byte of Green |
| 7 | Blue | 255 | |
| 8 | Blue Fine | 255 | Fine byte of Blue |

### 16Bit+Dim 12CH (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **9** | Color Add GY | 255 | |
| **10** | Color Add GY Fine | 255 | Fine byte of Color Add GY |
| **11** | Color Add RY | 255 | |
| **12** | Color Add RY Fine | 255 | Fine byte of Color Add RY |

## Extended 12CH

12 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **1** | Shutter / Strobe | 50 | 0–31 Shutter Closed<br>32–63 Shutter Open1<br>64–94 Min Strobe<br>95–95 Max Strobe<br>96–127 Shutter Open2<br>128–158 Min Pulse<br>159–159 Max Pulse<br>160–191 Shutter Open3<br>192–222 Min Random<br>223–223 Max Random<br>224–255 Shutter Open4 |
| **2** | Dimmer | 0 | 0–254 closed<br>255–255 open |
| **3** | Dimmer Fine | 0 | Fine byte of Dimmer |
| **4** | Dimmer Mode | 0 | 0–20 Standard<br>21–40 Stage<br>41–60 TV<br>61–80 Architectural<br>81–100 Theatre<br>101–120 Stage 2<br>121–255 Idle |
| **5** | C TO | 0 | |

## Extended 12CH (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **6** | Color Wheel | 0 | 0–0 Open1 (wheel slot 54)<br>1–1 Pale Yellow (wheel slot 1)<br>2–2 Straw (wheel slot 2)<br>3–3 Gold Tint (wheel slot 3)<br>4–4 Spring Yellow (wheel slot 4)<br>5–5 Medium Yellow (wheel slot 5)<br>6–6 Yellow (wheel slot 6)<br>7–7 Deep Amber (wheel slot 7)<br>8–8 Deep Straw (wheel slot 8)<br>9–9 Loving Amber (wheel slot 9)<br>10–10 Gold Amber (wheel slot 10)<br>11–11 Orange (wheel slot 11)<br>12–12 Deep Orange (wheel slot 12)<br>13–13 Dark Amber (wheel slot 13)<br>14–14 Millennium Gold (wheel slot 14)<br>15–15 Deep Golden Amber (wheel slot 15)<br>16–16 Scarlet (wheel slot 16)<br>17–17 Primary Red (wheel slot 17)<br>18–18 Bright Red (wheel slot 18)<br>19–19 Medium Red (wheel slot 19)<br>20–20 Fire (wheel slot 20)<br>21–21 Pink (wheel slot 21)<br>22–22 Medium Pink (wheel slot 22)<br>23–23 Dark Pink (wheel slot 23)<br>24–24 Bright Pink (wheel slot 24)<br>25–25 Bright Rose (wheel slot 25)<br>26–26 Special Rose Pink (wheel slot 26)<br>27–27 Vanity Fair (wheel slot 27)<br>28–28 Magenta (wheel slot 28)<br>29–29 Dark Magenta (wheel slot 29)<br>30–30 Rose Purple (wheel slot 30)<br>31–31 Mauve (wheel slot 31)<br>32–32 Medium Purple (wheel slot 32)<br>33–33 Lavender (wheel slot 33)<br>34–34 Palace blue (wheel slot 34)<br>35–35 Dark Blue (wheel slot 35)<br>36–36 Medium Blue (wheel slot 36)<br>37–37 Deep Blue (wheel slot 37)<br>38–38 Daylight Blue (wheel slot 38)<br>39–39 Slate Blue (wheel slot 39)<br>40–40 Light Blue (wheel slot 40)<br>41–41 Sky Blue (wheel slot 41)<br>42–42 Pale Navy Blue (wheel slot 42)<br>43–43 Marine Blue (wheel slot 43)<br>44–44 Peacock Blue (wheel slot 44)<br>45–45 Lagoon Blue (wheel slot 45)<br>46–46 Medium Blue Green (wheel slot 46)<br>47–47 Dark Yellow Green (wheel slot 47)<br>48–48 Primary Green (wheel slot 48)<br>49–49 Fern Green (wheel slot 49)<br>50–50 Moss Green (wheel slot 50)<br>51–51 Dark Green (wheel slot 51)<br>52–52 Lime Green (wheel slot 52)<br>53–53 Pale Green (wheel slot 53)<br>54–179 Open2<br>180–200 Clockwise fast<br>201–201 Clockwise slow<br>202–207 Stop<br>208–228 Counter-clockwise slow<br>229–229 Counter-clockwise fast<br>230–234 Open3<br>235–239 Fast<br>240–244 Medium<br>245–249 Slow |

### Extended 12CH (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **7** | Control1 | 0 | 0–100 Idle<br>101–105 900<br>106–110 1000<br>111–115 1100<br>116–120 1200<br>121–125 1300<br>126–130 1400<br>131–135 1500<br>136–140 2500<br>141–145 4000<br>146–150 5000<br>151–155 10000<br>156–160 15000<br>161–165 20000<br>166–170 25000<br>171–200 Idle<br>201–210 Dimmer Curve Linear (default)<br>211–220 Dimmer Curve Square<br>221–230 Dimmer Curve Inverse Square<br>231–240 Dimmer Curve S-Curve<br>241–255 Idle |
| **8** | Red | 255 | |
| **9** | Green | 255 | |
| **10** | Blue | 255 | |
| **11** | Color Add GY | 255 | |
| **12** | Color Add RY | 255 | |

## HSI+Cells 37CH

37 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **1** | Shutter / Strobe | 50 | 0–31 Shutter Closed<br>32–63 Shutter Open1<br>64–94 Min Strobe<br>95–95 Max Strobe<br>96–127 Shutter Open2<br>128–158 Min Pulse<br>159–159 Max Pulse<br>160–191 Shutter Open3<br>192–222 Min Random<br>223–223 Max Random<br>224–255 Shutter Open4 |
| **2** | Dimmer | 0 | 0–254 closed<br>255–255 open |
| **3** | Dimmer Fine | 0 | Fine byte of Dimmer |
| **4** | Dimmer Mode | 0 | 0–20 Standard<br>21–40 Stage<br>41–60 TV<br>61–80 Architectural<br>81–100 Theatre<br>101–120 Stage 2<br>121–255 Idle |
| **5** | C TO | 0 | |

## HSI+Cells 37CH (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **6** | Color Wheel | 0 | 0–0 Open1 (wheel slot 54)<br>1–1 Pale Yellow (wheel slot 1)<br>2–2 Straw (wheel slot 2)<br>3–3 Gold Tint (wheel slot 3)<br>4–4 Spring Yellow (wheel slot 4)<br>5–5 Medium Yellow (wheel slot 5)<br>6–6 Yellow (wheel slot 6)<br>7–7 Deep Amber (wheel slot 7)<br>8–8 Deep Straw (wheel slot 8)<br>9–9 Loving Amber (wheel slot 9)<br>10–10 Gold Amber (wheel slot 10)<br>11–11 Orange (wheel slot 11)<br>12–12 Deep Orange (wheel slot 12)<br>13–13 Dark Amber (wheel slot 13)<br>14–14 Millennium Gold (wheel slot 14)<br>15–15 Deep Golden Amber (wheel slot 15)<br>16–16 Scarlet (wheel slot 16)<br>17–17 Primary Red (wheel slot 17)<br>18–18 Bright Red (wheel slot 18)<br>19–19 Medium Red (wheel slot 19)<br>20–20 Fire (wheel slot 20)<br>21–21 Pink (wheel slot 21)<br>22–22 Medium Pink (wheel slot 22)<br>23–23 Dark Pink (wheel slot 23)<br>24–24 Bright Pink (wheel slot 24)<br>25–25 Bright Rose (wheel slot 25)<br>26–26 Special Rose Pink (wheel slot 26)<br>27–27 Vanity Fair (wheel slot 27)<br>28–28 Magenta (wheel slot 28)<br>29–29 Dark Magenta (wheel slot 29)<br>30–30 Rose Purple (wheel slot 30)<br>31–31 Mauve (wheel slot 31)<br>32–32 Medium Purple (wheel slot 32)<br>33–33 Lavender (wheel slot 33)<br>34–34 Palace blue (wheel slot 34)<br>35–35 Dark Blue (wheel slot 35)<br>36–36 Medium Blue (wheel slot 36)<br>37–37 Deep Blue (wheel slot 37)<br>38–38 Daylight Blue (wheel slot 38)<br>39–39 Slate Blue (wheel slot 39)<br>40–40 Light Blue (wheel slot 40)<br>41–41 Sky Blue (wheel slot 41)<br>42–42 Pale Navy Blue (wheel slot 42)<br>43–43 Marine Blue (wheel slot 43)<br>44–44 Peacock Blue (wheel slot 44)<br>45–45 Lagoon Blue (wheel slot 45)<br>46–46 Medium Blue Green (wheel slot 46)<br>47–47 Dark Yellow Green (wheel slot 47)<br>48–48 Primary Green (wheel slot 48)<br>49–49 Fern Green (wheel slot 49)<br>50–50 Moss Green (wheel slot 50)<br>51–51 Dark Green (wheel slot 51)<br>52–52 Lime Green (wheel slot 52)<br>53–53 Pale Green (wheel slot 53)<br>54–179 Open2<br>180–200 Clockwise fast<br>201–201 Clockwise slow<br>202–207 Stop<br>208–228 Counter-clockwise slow<br>229–229 Counter-clockwise fast<br>230–234 Open3<br>235–239 Fast<br>240–244 Medium<br>245–249 Slow |

## HSI+Cells 37CH (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 7 | Control1 | 0 | 0–100 Idle<br>101–105 900<br>106–110 1000<br>111–115 1100<br>116–120 1200<br>121–125 1300<br>126–130 1400<br>131–135 1500<br>136–140 2500<br>141–145 4000<br>146–150 5000<br>151–155 10000<br>156–160 15000<br>161–165 20000<br>166–170 25000<br>171–200 Idle<br>201–210 Dimmer Curve Linear (default)<br>211–220 Dimmer Curve Square<br>221–230 Dimmer Curve Inverse Square<br>231–240 Dimmer Curve S-Curve<br>241–255 Idle |
| 8 | H SBHue | 0 | |
| 9 | H SBSaturation | 0 | |
| 10 | Dimmer | 0 | |
| 11 | H SBHue | 0 | |
| 12 | H SBSaturation | 0 | |
| 13 | Dimmer | 0 | |
| 14 | H SBHue | 0 | |
| 15 | H SBSaturation | 0 | |
| 16 | Dimmer | 0 | |
| 17 | H SBHue | 0 | |
| 18 | H SBSaturation | 0 | |
| 19 | Dimmer | 0 | |
| 20 | H SBHue | 0 | |
| 21 | H SBSaturation | 0 | |
| 22 | Dimmer | 0 | |
| 23 | H SBHue | 0 | |
| 24 | H SBSaturation | 0 | |
| 25 | Dimmer | 0 | |
| 26 | H SBHue | 0 | |
| 27 | H SBSaturation | 0 | |
| 28 | Dimmer | 0 | |
| 29 | H SBHue | 0 | |
| 30 | H SBSaturation | 0 | |
| 31 | Dimmer | 0 | |
| 32 | H SBHue | 0 | |
| 33 | H SBSaturation | 0 | |
| 34 | Dimmer | 0 | |
| 35 | H SBHue | 0 | |
| 36 | H SBSaturation | 0 | |
| 37 | Dimmer | 0 | |