CKC Lighting

Mini Profile 50



Manufacturer	**CKC Lighting**
Type	**Profile spot**
DMX modes	**3**
DMX footprint	**2, 3, 6 channels**
Beam angle	**30°**
Size (W × H × D)	**140 × 210 × 50 mm**
GDTF fixture type	**470B828B-A25B-4B22-A9DF-1A…**

Controls

Strobe · Dimmer

Safety-relevant functions

Strobe

DMX modes

2CH	2 ch
3CH	3 ch
6CH	6 ch

2CH

2 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–62 0 percent 63–126 25 percent 127–190 50 percent 191–254 75 percent 255–255 100 percent
2	Dimmer Fine	0	Fine byte of Dimmer

3CH

3 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–62 0 percent 63–126 25 percent 127–190 50 percent 191–254 75 percent 255–255 100 percent
2	Dimmer Fine	0	Fine byte of Dimmer
3	Shutter / Strobe	50	0–31 Shutter Closed 32–63 No Function (Shutter Open) 64–94 Min Strobe 95–95 Max Strobe 96–127 No Function (Shutter Open) 128–158 Min Pulse 159–159 Max Pulse 160–191 No Function (Shutter Open) 192–222 Min Random 223–223 Max Random 224–255 No Function (Shutter Open)

6CH

6 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–62 0 percent 63–126 25 percent 127–190 50 percent 191–254 75 percent 255–255 100 percent
2	Dimmer Fine	0	Fine byte of Dimmer
3	Shutter / Strobe	50	0–31 Shutter Closed 32–63 No Function (Shutter Open) 64–94 Min Strobe 95–95 Max Strobe 96–127 No Function (Shutter Open) 128–158 Min Pulse 159–159 Max Pulse 160–191 No Function (Shutter Open) 192–222 Min Random 223–223 Max Random 224–255 No Function (Shutter Open)
4	Dimmer Mode	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theatre 101–255 Default to Unit Setting

6CH (continued)

Ch	Function	Default	DMX values
5	Dimmer Curve	0	0–20 Default Dimmer Curve Square 21–40 Dimmer Curve Linear 41–60 Dimmer Curve Inverse Square 61–80 Dimmer Curve S-Curve 81–255 No Function
6	Control1	0	28–28 1200Hz 29–29 900Hz 30–30 1000Hz 31–31 1100Hz 32–32 1300Hz 33–33 1400Hz 34–34 1500Hz 35–35 2500Hz 36–36 4000Hz 37–37 5000Hz 38–38 6000Hz 39–39 10KHz 40–40 15KHz 41–41 20KHz 42–42 25KHz 43–255 Default