COH

AX3



Manufacturer	**COH**
Type	**PAR**
DMX modes	**5**
DMX footprint	**3, 4, 5, 8 channels**
Beam angle	**13°**
Size (W × H × D)	**61 × 58 × 48 mm**
GDTF fixture type	**C8306D67-7BFB-4DF5-8A80-2D…**

Controls

Extra LED colours · RGB colour mixing · Colour temperature · Colour wheel · Strobe · Dimmer

Safety-relevant functions

Strobe

DMX modes

Mode 1 - 1Pix RGB Strob OFF	3 ch
Mode 2 - 1Pix RGBW Strob OFF	4 ch
Mode 8 - 1Pix RGBS	4 ch
Mode 9 - 1Pix RGBWS	5 ch
Mode 94 - 1Pix D CCT GM CRO RGB S	8 ch

Mode 1 - 1Pix RGB Strob OFF

3 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	

Mode 2 - 1Pix RGBW Strob OFF

4 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	

Mode 8 - 1Pix RGBS

4 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	Shutter / Strobe	0	0–3 open 4–4 Random Fast 5–5 Random Medium 6–6 Random Slow 7–127 Min Strobe 128–254 Medium Strobe 255–255 Max Strobe

Mode 9 - 1Pix RGBWS

5 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	Shutter / Strobe	0	0–3 open 4–4 Random Fast 5–5 Random Medium 6–6 Random Slow 7–127 Min Strobe 128–254 Medium Strobe 255–255 Max Strobe

Mode 94 - 1Pix D CCT GM CRO RGB S

8 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	C TC	45	0–44 1750 K 45–119 3200 K 120–254 5600K 255–255 9910 K

Mode 94 - 1Pix D CCT GM CRO RGB S (continued)

Ch	Function	Default	DMX values
3	Tint	128	0–4 No Effect 5–5 Full Minus G 6–127 Minus G 128–128 Neutral 129–254 Plus G 255–255 Full Plus G
4	Color XF	0	0–254 White Mode 255–255 Color Mode
5	Red	255	
6	Green	255	
7	Blue	255	
8	Shutter / Strobe	0	0–3 open 4–4 Random Fast 5–5 Random Medium 6–6 Random Slow 7–127 Min Strobe 128–254 Medium Strobe 255–255 Max Strobe