DTS Lighting

Hi-Line 30 EVO



Manufacturer	**DTS Lighting**
Type	**PAR**
DMX modes	**3**
DMX footprint	**4, 11, 16 channels**
Beam angle	**25°**
Heads / cells	**4**
Size (W × H × D)	**319 × 177 × 76 mm**
GDTF fixture type	**A45BCD7B-390A-432F-94F0-93…**

Controls

Extra LED colours · RGB colour mixing · Dimmer · Pixel control

DMX modes

RGBW	4 ch
PROM 11 CH	11 ch
16 CH	16 ch

RGBW

4 channels

Ch	Function	Default	DMX values
1	Color RGBRed	0	
2	Color RGBGreen	0	
3	Color RGBBlue	0	
4	White	0	

PROM 11 CH

11 channels

Ch	Function	Default	DMX values
1	Color RGBRed	0	
2	Color RGBRed Fine	0	Fine byte of Color RGBRed
3	Color RGBGreen	0	
4	Color RGBGreen Fine	0	Fine byte of Color RGBGreen
5	Color RGBBlue	0	
6	Color RGBBlue Fine	0	Fine byte of Color RGBBlue
7	White	0	
8	White Fine	0	Fine byte of White
9	Dimmer	0	
10	Dimmer Fine	0	Fine byte of Dimmer
11	Control1	40	0–9 No Function 10–19 NO DMX ACTION KEEP LAST DMX 20–29 NO DMX ACTION BLACK OUT 30–39 NO DMX ACTION WH 1 2 3 100% 40–49 NO DMX ACTION WH 1 2 3 60% DEFAULT 50–69 RESERVED 70–109 NO DMX ACTION CUSTOM 110–129 RESERVED 130–149 VIEW CUSTOM 1 150–169 VIEW CUSTOM 2 170–189 VIEW CUSTOM 3 190–209 VIEW CUSTOM 4 210–229 RESERVED 230–230 CREATE AND STORE CUSTOM 231–231 CREATE AND STORE CUSTOM 2 232–232 CREATE AND STORE CUSTOM 3 233–233 CREATE AND STORE CUSTOM 4 234–253 RESERVED 254–255 NO FUNCTION

16 CH

16 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Green	0	
3	Blue	0	
4	White	0	
5	Red	0	
6	Green	0	
7	Blue	0	
8	White	0	
9	Red	0	
10	Green	0	

16 CH (continued)

Ch	Function	Default	DMX values
11	Blue	0	
12	White	0	
13	Red	0	
14	Green	0	
15	Blue	0	
16	White	0	