
Eagle Lite

IPBAR1420 PRO



Manufacturer	**Eagle Lite**
Type	**LED bar**
DMX modes	**4**
DMX footprint	**5, 11, 70, 76 channels**
Beam angle	**25°**
Heads / cells	**14**
Size (W × H × D)	**901 × 102 × 141 mm**
GDTF fixture type	**F5BEA042-89D4-4185-BDDC-19…**

Controls

Extra LED colours · RGB colour mixing · Colour wheel · Effect speed · Strobe · Dimmer · Pixel control

DMX modes

Small Mode 5ch	5 ch
Simple Mode 11ch	11 ch
70 Channel	70 ch
76 Channel	76 ch

Small Mode 5ch

5 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Green	0	
3	Blue	0	
4	White	0	
5	Color Add Y	0	

Simple Mode 11ch

11 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–63 0% Dimmer 64–127 25% Dimmer 128–254 50% Dimmer 255–255 100% Dimmer
2	Shutter / Strobe	4	0–1 Shutter Closed 2–4 Shutter Open 5–64 0% Min Strobe Speed 65–129 50% Strobe Speed 130–130 100% Strobe Speed 131–174 0% Pulse 175–228 50% Pulse 229–229 100% Pulse 230–238 0% Random Strobe 239–248 50% Random Strobe 249–249 Random Strobe Slow To fast · Empty Channel Set 2... 250–250 Shutter Closed 251–255 Shutter Open
3	Color Macro1	0	
4	Color Macro1Rate	0	
5	Color Effects1	0	
6	Effect Speed	0	
7	Green	0	
8	Red	0	
9	Blue	0	
10	White	0	
11	Color Add Y	0	

70 Channel

70 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Green	0	
3	Blue	0	
4	White	0	
5	Color Add Y	0	
6	Red	0	
7	Green	0	
8	Blue	0	
9	White	0	
10	Color Add Y	0	
11	Red	0	

70 Channel (continued)

Ch	Function	Default	DMX values
12	Green	0	
13	Blue	0	
14	White	0	
15	Color Add Y	0	
16	Red	0	
17	Green	0	
18	Blue	0	
19	White	0	
20	Color Add Y	0	
21	Red	0	
22	Green	0	
23	Blue	0	
24	White	0	
25	Color Add Y	0	
26	Red	0	
27	Green	0	
28	Blue	0	
29	White	0	
30	Color Add Y	0	
31	Red	0	
32	Green	0	
33	Blue	0	
34	White	0	
35	Color Add Y	0	
36	Red	0	
37	Green	0	
38	Blue	0	
39	White	0	
40	Color Add Y	0	
41	Red	0	
42	Green	0	
43	Blue	0	
44	White	0	
45	Color Add Y	0	
46	Red	0	
47	Green	0	
48	Blue	0	
49	White	0	
50	Color Add Y	0	
51	Red	0	
52	Green	0	
53	Blue	0	
54	White	0	
55	Color Add Y	0	
56	Red	0	

70 Channel (continued)

Ch	Function	Default	DMX values
57	Green	0	
58	Blue	0	
59	White	0	
60	Color Add Y	0	
61	Red	0	
62	Green	0	
63	Blue	0	
64	White	0	
65	Color Add Y	0	
66	Red	0	
67	Green	0	
68	Blue	0	
69	White	0	
70	Color Add Y	0	

76 Channel

76 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Strobe Mode Shutter	4	
3	Color Macro1	0	
4	Color Macro1Rate	0	
5	Color Effects1	0	
6	Effect Speed	0	
7	Red	0	
8	Green	0	
9	Blue	0	
10	White	0	
11	Color Add Y	0	
12	Red	0	
13	Green	0	
14	Blue	0	
15	White	0	
16	Color Add Y	0	
17	Red	0	
18	Green	0	
19	Blue	0	
20	White	0	
21	Color Add Y	0	
22	Red	0	
23	Green	0	
24	Blue	0	
25	White	0	
26	Color Add Y	0	
27	Red	0	

76 Channel (continued)

Ch	Function	Default	DMX values
28	Green	0	
29	Blue	0	
30	White	0	
31	Color Add Y	0	
32	Red	0	
33	Green	0	
34	Blue	0	
35	White	0	
36	Color Add Y	0	
37	Red	0	
38	Green	0	
39	Blue	0	
40	White	0	
41	Color Add Y	0	
42	Red	0	
43	Green	0	
44	Blue	0	
45	White	0	
46	Color Add Y	0	
47	Red	0	
48	Green	0	
49	Blue	0	
50	White	0	
51	Color Add Y	0	
52	Red	0	
53	Green	0	
54	Blue	0	
55	White	0	
56	Color Add Y	0	
57	Red	0	
58	Green	0	
59	Blue	0	
60	White	0	
61	Color Add Y	0	
62	Red	0	
63	Green	0	
64	Blue	0	
65	White	0	
66	Color Add Y	0	
67	Red	0	
68	Green	0	
69	Blue	0	
70	White	0	
71	Color Add Y	0	
72	Red	0	

76 Channel (continued)

Ch	Function	Default	DMX values
73	Green	0	
74	Blue	0	
75	White	0	
76	Color Add Y	0	