Elation

Pulse Bar L



Manufacturer	**Elation**
Type	**Strobe**
DMX modes	**9**
DMX footprint	**3, 11, 17, 22, 25, 52, 92, 132 channels**
Beam angle	**25-68°**
Heads / cells	**51**
Size (W × H × D)	**850 × 130 × 170 mm**
GDTF fixture type	**FD9098ED-6CCC-4F6B-8DA1-00…**

Controls

Extra LED colours · RGB colour mixing · Effect speed · Dimmer · Pixel control

Safety-relevant functions

Built-in effect programmes

DMX modes

Raw Mode 220CH	3 ch
Xenon Strobe 3CH	3 ch
Simple Strobe 11CH	11 ch
Pixel Focus 234CH	17 ch
Strobe FX 22CH	22 ch
Full Control 242CH	25 ch
Large Pixels 52CH	52 ch
Simple Pixel 92CH	92 ch
Basic Full Control 132CH	132 ch

Raw Mode 220CH

3 channels

Ch	Function	Default	DMX values
1	Red	0	0–62 0 % R 63–126 25 % R 127–190 50 % R 191–254 75 % R 255–255 100 % R
2	Green	0	0–62 0 % G 63–126 25 % G 127–190 50 % G 191–254 75 % G 255–255 100 % G
3	Blue	0	0–62 0 % B 63–126 25 % B 127–190 50 % B 191–254 75 % B 255–255 100 % B

Xenon Strobe 3CH

3 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–62 0 % Master 63–126 25 % Master 127–190 50 % Master 191–254 75 % Master 255–255 100 % Master
2	Strobe Duration	0	
3	Strobe Rate	0	

Simple Strobe 11CH

11 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–62 0 % CW 63–126 25 % CW 127–190 50 % CW 191–254 75 % CW 255–255 100 % CW
2	Strobe Duration	0	
3	Strobe Rate	0	
4	Strobe Mode Strobe	255	0–31 Single Strobe/Standard Mode CW 32–63 Ramp Up CW 64–95 Ramp Down CW 96–127 Ramp Up to Ramp Down CW 128–159 Random CW 160–191 Double Flash CW 192–223 Triple Flash CW 224–255 No Effect CW
5	Dimmer	0	0–62 0 % RGB 63–126 25 % RGB 127–190 50 % RGB 191–254 75 % RGB 255–255 100 % RGB
6	Strobe Duration	0	
7	Strobe Rate	0	

Simple Strobe 11CH (continued)

Ch	Function	Default	DMX values
8	Strobe Mode Strobe	255	0–31 Single Strobe/Standard Mode 32–63 Ramp Up 64–95 Ramp Down 96–127 Ramp Up to Ramp Down 128–159 Random 160–191 Double Flash 192–223 Triple Flash 224–255 No Effect
9	Red	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
10	Green	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
11	Blue	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %

Pixel Focus 234CH

17 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–62 0 % Master 63–126 25 % Master 127–190 50 % Master 191–254 75 % Master 255–255 100 % Master
2	Dimmer	0	0–62 0 % CW 63–126 25 % CW 127–190 50 % CW 191–254 75 % CW 255–255 100 % CW
3	Strobe Duration	0	
4	Strobe Rate	0	
5	Strobe Mode Strobe	255	0–31 Single Strobe/Standard Mode CW 32–63 Ramp Up CW 64–95 Ramp Down CW 96–127 Ramp Up to Ramp Down CW 128–159 Random CW 160–191 Double Flash CW 192–223 Triple Flash CW 224–255 No Effect CW
6	Dimmer	0	0–62 0 % RGB 63–126 25 % RGB 127–190 50 % RGB 191–254 75 % RGB 255–255 100 % RGB
7	Strobe Duration	0	
8	Strobe Rate	0	

Pixel Focus 234CH (continued)

Ch	Function	Default	DMX values
9	Strobe Mode Strobe	255	0–31 Single Strobe/Standard Mode 32–63 Ramp Up 64–95 Ramp Down 96–127 Ramp Up to Ramp Down 128–159 Random 160–191 Double Flash 192–223 Triple Flash 224–255 No Effect
10	Red	0	0–62 0 % ALL LED 63–126 25 % ALL LED 127–190 50 % ALL LED 191–254 75 % ALL LED 255–255 100 % ALL LED
11	Green	0	0–62 0 % ALL LED 63–126 25 % ALL LED 127–190 50 % ALL LED 191–254 75 % ALL LED 255–255 100 % ALL LED
12	Blue	0	0–62 0 % ALL LED 63–126 25 % ALL LED 127–190 50 % ALL LED 191–254 75 % ALL LED 255–255 100 % ALL LED
13	Dimmer Mode	0	
14	Function	0	
15	Red	0	0–62 0 % R 63–126 25 % R 127–190 50 % R 191–254 75 % R 255–255 100 % R
16	Green	0	0–62 0 % G 63–126 25 % G 127–190 50 % G 191–254 75 % G 255–255 100 % G
17	Blue	0	0–62 0 % B 63–126 25 % B 127–190 50 % B 191–254 75 % B 255–255 100 % B

Strobe FX 22CH

22 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–62 0 % Master 63–126 25 % Master 127–190 50 % Master 191–254 75 % Master 255–255 100 % Master
2	Dimmer	0	0–62 0 % CW 63–126 25 % CW 127–190 50 % CW 191–254 75 % CW 255–255 100 % CW
3	Strobe Duration	0	
4	Strobe Rate	0	

Strobe FX 22CH (continued)

Ch	Function	Default	DMX values
5	Strobe Mode Strobe	255	0–31 Single Strobe/Standard Mode CW 32–63 Ramp Up CW 64–95 Ramp Down CW 96–127 Ramp Up to Ramp Down CW 128–159 Random CW 160–191 Double Flash CW 192–223 Triple Flash CW 224–255 No Effect CW
6	Dimmer	0	0–62 0 % RGB 63–126 25 % RGB 127–190 50 % RGB 191–254 75 % RGB 255–255 100 % RGB
7	Strobe Duration	0	
8	Strobe Rate	0	
9	Strobe Mode Strobe	255	0–31 Single Strobe/Standard Mode 32–63 Ramp Up 64–95 Ramp Down 96–127 Ramp Up to Ramp Down 128–159 Random 160–191 Double Flash 192–223 Triple Flash 224–255 No Effect
10	Red	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
11	Green	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
12	Blue	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
13	Effect	0	
14	Effect Speed	0	0–126 Slow to Fast CW 127–128 Stop CW 129–255 Rev Fast to Slow CW
15	Effects1Adjust1	0	0–50 Idle 51–60 1 Zone CW 61–70 2 Zone CW 71–80 4 Zone CW 81–90 8 Zone CW 91–100 10 Zone CW 101–110 20 Zone CW 111–120 40 Zone CW 121–255 Idle CW
16	Effects1Fade	0	
17	Effect	0	
18	Effect Speed	0	0–126 Slow to Fast RGB 127–128 Stop RGB 129–255 Rev Fast to Slow RGB

Strobe FX 22CH (continued)

Ch	Function	Default	DMX values
19	Effects1Adjust1	0	0–50 Idle 51–60 1 Zone RGB 61–70 2 Zone RGB 71–80 3 Zone RGB 81–90 6 Zone RGB 91–100 10 Zone RGB 101–110 15 Zone RGB 111–120 20 Zone RGB 121–130 40 Zone RGB 131–140 60 Zone RGB 141–255 Idle
20	Effects1Fade	0	
21	Dimmer Mode	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theatre 101–120 Stage 2 121–121 0s 122–122 0*1s 123–123 0*2 124–124 0*3s 125–125 0*4s 126–126 0*5s 127–127 0*6s 128–128 0*7 129–129 0*8s 130–130 0*9s 131–131 1s 132–132 1*5s 133–133 2s 134–134 3s 135–135 4s 136–136 5s 137–137 6s 138–138 7s 139–139 8s 140–140 9s 141–141 10s 142–255 Idle
22	Function	0	

Full Control 242CH

25 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–62 0 % Master 63–126 25 % Master 127–190 50 % Master 191–254 75 % Master 255–255 100 % Master
2	Dimmer	0	0–62 0 % CW 63–126 25 % CW 127–190 50 % CW 191–254 75 % CW 255–255 100 % CW
3	Strobe Duration	0	
4	Strobe Rate	0	

Full Control 242CH (continued)

Ch	Function	Default	DMX values
5	Strobe Mode Strobe	255	0–31 Single Strobe/Standard Mode CW 32–63 Ramp Up CW 64–95 Ramp Down CW 96–127 Ramp Up to Ramp Down CW 128–159 Random CW 160–191 Double Flash CW 192–223 Triple Flash CW 224–255 No Effect CW
6	Dimmer	0	0–62 0 % RGB 63–126 25 % RGB 127–190 50 % RGB 191–254 75 % RGB 255–255 100 % RGB
7	Strobe Duration	0	
8	Strobe Rate	0	
9	Strobe Mode Strobe	255	0–31 Single Strobe/Standard Mode 32–63 Ramp Up 64–95 Ramp Down 96–127 Ramp Up to Ramp Down 128–159 Random 160–191 Double Flash 192–223 Triple Flash 224–255 No Effect
10	Red	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
11	Green	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
12	Blue	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
13	Effect	0	
14	Effect Speed	0	0–126 Slow to Fast CW 127–128 Stop CW 129–255 Rev Fast to Slow CW
15	Effects1Adjust1	0	0–50 Idle 51–60 1 Zone CW 61–70 2 Zone CW 71–80 4 Zone CW 81–90 6 Zone CW 91–100 8 Zone CW 101–110 12 Zone CW 111–120 16 Zone CW 121–130 24 Zone CW 131–140 48 Zone CW 141–255 Idle CW
16	Effects1Fade	0	
17	Effect	0	
18	Effect Speed	0	0–126 Slow to Fast RGB 127–128 Stop RGB 129–255 Rev Fast to Slow RGB

Full Control 242CH (continued)

Ch	Function	Default	DMX values
19	Effects1Adjust1	0	0–50 Idle 51–60 1 Zone RGB 61–70 2 Zone RGB 71–80 3 Zone RGB 81–90 6 Zone RGB 91–100 9 Zone RGB 101–110 15 Zone RGB 111–120 18 Zone RGB 121–130 36 Zone RGB 131–255 Idle
20	Effects1Fade	0	
21	Dimmer Mode	0	
22	Function	0	
23	Red	0	0–62 0 % R 63–126 25 % R 127–190 50 % R 191–254 75 % R 255–255 100 % R
24	Green	0	0–62 0 % G 63–126 25 % G 127–190 50 % G 191–254 75 % G 255–255 100 % G
25	Blue	0	0–62 0 % B 63–126 25 % B 127–190 50 % B 191–254 75 % B 255–255 100 % B

Large Pixels 52CH

52 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–62 0 % Master 63–126 25 % Master 127–190 50 % Master 191–254 75 % Master 255–255 100 % Master
2	Dimmer	0	0–62 0 % CW 63–126 25 % CW 127–190 50 % CW 191–254 75 % CW 255–255 100 % CW
3	Strobe Duration	0	
4	Strobe Rate	0	
5	Strobe Mode Strobe	255	0–31 Single Strobe/Standard Mode CW 32–63 Ramp Up CW 64–95 Ramp Down CW 96–127 Ramp Up to Ramp Down CW 128–159 Random CW 160–191 Double Flash CW 192–223 Triple Flash CW 224–255 No Effect CW
6	Dimmer	0	0–62 0 % RGB 63–126 25 % RGB 127–190 50 % RGB 191–254 75 % RGB 255–255 100 % RGB

Large Pixels 52CH (continued)

Ch	Function	Default	DMX values
7	Strobe Duration	0	
8	Strobe Rate	0	
9	Strobe Mode Strobe	255	0–31 Single Strobe/Standard Mode 32–63 Ramp Up 64–95 Ramp Down 96–127 Ramp Up to Ramp Down 128–159 Random 160–191 Double Flash 192–223 Triple Flash 224–255 No Effect
10	Red	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
11	Green	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
12	Blue	0	0–62 0 % 63–126 25 % 127–190 50 % 191–254 75 % 255–255 100 %
13	Dimmer Mode	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theatre 101–120 Stage 2 121–121 0s 122–122 0*1s 123–123 0*2 124–124 0*3s 125–125 0*4s 126–126 0*5s 127–127 0*6s 128–128 0*7 129–129 0*8s 130–130 0*9s 131–131 1s 132–132 1*5s 133–133 2s 134–134 3s 135–135 4s 136–136 5s 137–137 6s 138–138 7s 139–139 8s 140–140 9s 141–141 10s 142–255 Idle
14	Function	0	
15	Red	0	0–62 0 % R1 63–126 25 % R1 127–190 50 % R1 191–254 75 % R1 255–255 100 % R1

Large Pixels 52CH (continued)

Ch	Function	Default	DMX values
16	Green	0	0–62 0 % G1 63–126 25 % G1 127–190 50 % G1 191–254 75 % G1 255–255 100 % G1
17	Blue	0	0–62 0 % B1 63–126 25 % B1 127–190 50 % B1 191–254 75 % B1 255–255 100 % B1
18	Red	0	0–62 0 % R2 63–126 25 % R2 127–190 50 % R2 191–254 75 % R2 255–255 100 % R2
19	Green	0	0–62 0 % G2 63–126 25 % G2 127–190 50 % G2 191–254 75 % G2 255–255 100 % G2
20	Blue	0	0–62 0 % B2 63–126 25 % B2 127–190 50 % B2 191–254 75 % B2 255–255 100 % B2
21	Red	0	0–62 0 % R3 63–126 25 % R3 127–190 50 % R3 191–254 75 % R3 255–255 100 % R3
22	Green	0	0–62 0 % G3 63–126 25 % G3 127–190 50 % G3 191–254 75 % G3 255–255 100 % G3
23	Blue	0	0–62 0 % B3 63–126 25 % B3 127–190 50 % B3 191–254 75 % B3 255–255 100 % B3
24	Red	0	0–62 0 % R4 63–126 25 % R4 127–190 50 % R4 191–254 75 % R4 255–255 100 % R4
25	Green	0	0–62 0 % G4 63–126 25 % G4 127–190 50 % G4 191–254 75 % G4 255–255 100 % G4
26	Blue	0	0–62 0 % B4 63–126 25 % B4 127–190 50 % B4 191–254 75 % B4 255–255 100 % B4

Large Pixels 52CH (continued)

Ch	Function	Default	DMX values
27	Red	0	0–62 0 % R5 63–126 25 % R5 127–190 50 % R5 191–254 75 % R5 255–255 100 % R5
28	Green	0	0–62 0 % G5 63–126 25 % G5 127–190 50 % G5 191–254 75 % G5 255–255 100 % G5
29	Blue	0	0–62 0 % B5 63–126 25 % B5 127–190 50 % B5 191–254 75 % B5 255–255 100 % B5
30	Red	0	0–62 0 % R6 63–126 25 % R6 127–190 50 % R6 191–254 75 % R6 255–255 100 % R6
31	Green	0	0–62 0 % G6 63–126 25 % G6 127–190 50 % G6 191–254 75 % G6 255–255 100 % G6
32	Blue	0	0–62 0 % B6 63–126 25 % B6 127–190 50 % B6 191–254 75 % B6 255–255 100 % B6
33	Red	0	0–62 0 % R7 63–126 25 % R7 127–190 50 % R7 191–254 75 % R7 255–255 100 % R7
34	Green	0	0–62 0 % G7 63–126 25 % G7 127–190 50 % G7 191–254 75 % G7 255–255 100 % G7
35	Blue	0	0–62 0 % B7 63–126 25 % B7 127–190 50 % B7 191–254 75 % B7 255–255 100 % B7
36	Red	0	0–62 0 % R8 63–126 25 % R8 127–190 50 % R8 191–254 75 % R8 255–255 100 % R8
37	Green	0	0–62 0 % G8 63–126 25 % G8 127–190 50 % G8 191–254 75 % G8 255–255 100 % G8

Large Pixels 52CH (continued)

Ch	Function	Default	DMX values
38	Blue	0	0–62 0 % B8 63–126 25 % B8 127–190 50 % B8 191–254 75 % B8 255–255 100 % B8
39	Color Add CW	0	0–62 0 % CW1 63–126 25 % CW1 127–190 50 % CW1 191–254 75 % CW1 255–255 100 % CW1
40	Color Add CW	0	0–62 0 % CW2 63–126 25 % CW2 127–190 50 % CW2 191–254 75 % CW2 255–255 100 % CW2
41	Red	0	0–62 0 % StrobeR1 63–126 25 % StrobeR1 127–190 50 % StrobeR1 191–254 75 % StrobeR1 255–255 100 % StrobeR1
42	Green	0	0–62 0 % StrobeG1 63–126 25 % StrobeG1 127–190 50 % StrobeG1 191–254 75 % StrobeG1 255–255 100 % StrobeG1
43	Blue	0	0–62 0 % StrobeB1 63–126 25 % StrobeB1 127–190 50 % StrobeB1 191–254 75 % StrobeB1 255–255 100 % StrobeB1
44	Red	0	0–62 0 % StrobeR2 63–126 25 % StrobeR2 127–190 50 % StrobeR2 191–254 75 % StrobeR2 255–255 100 % StrobeR2
45	Green	0	0–62 0 % StrobeG2 63–126 25 % StrobeG2 127–190 50 % StrobeG2 191–254 75 % StrobeG2 255–255 100 % StrobeG2
46	Blue	0	0–62 0 % StrobeB2 63–126 25 % StrobeB2 127–190 50 % StrobeB2 191–254 75 % StrobeB2 255–255 100 % StrobeB2
47	Red	0	0–62 0 % StrobeR3 63–126 25 % StrobeR3 127–190 50 % StrobeR3 191–254 75 % StrobeR3 255–255 100 % StrobeR3
48	Green	0	0–62 0 % StrobeG3 63–126 25 % StrobeG3 127–190 50 % StrobeG3 191–254 75 % StrobeG3 255–255 100 % StrobeG3

Large Pixels 52CH (continued)

Ch	Function	Default	DMX values
49	Blue	0	0–62 0 % StrobeB3 63–126 25 % StrobeB3 127–190 50 % StrobeB3 191–254 75 % StrobeB3 255–255 100 % StrobeB3
50	Red	0	0–62 0 % StrobeR4 63–126 25 % StrobeR4 127–190 50 % StrobeR4 191–254 75 % StrobeR4 255–255 100 % StrobeR4
51	Green	0	0–62 0 % StrobeG4 63–126 25 % StrobeG4 127–190 50 % StrobeG4 191–254 75 % StrobeG4 255–255 100 % StrobeG4
52	Blue	0	0–62 0 % StrobeB4 63–126 25 % StrobeB4 127–190 50 % StrobeB4 191–254 75 % StrobeB4 255–255 100 % StrobeB4

Simple Pixel 92CH

92 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Strobe Duration	0	
3	Strobe Rate	0	
4	Strobe Mode Strobe	255	
5	Dimmer	0	
6	Strobe Duration	0	
7	Strobe Rate	0	
8	Strobe Mode Strobe	255	
9	Red	0	
10	Green	0	
11	Blue	0	
12	Function	0	
13	Red	0	
14	Green	0	
15	Blue	0	
16	Red	0	
17	Green	0	
18	Blue	0	
19	Red	0	
20	Green	0	
21	Blue	0	
22	Red	0	
23	Green	0	
24	Blue	0	
25	Red	0	
26	Green	0	

Simple Pixel 92CH (continued)

Ch	Function	Default	DMX values
27	Blue	0	
28	Red	0	
29	Green	0	
30	Blue	0	
31	Red	0	
32	Green	0	
33	Blue	0	
34	Red	0	
35	Green	0	
36	Blue	0	
37	Red	0	
38	Green	0	
39	Blue	0	
40	Red	0	
41	Green	0	
42	Blue	0	
43	Red	0	
44	Green	0	
45	Blue	0	
46	Red	0	
47	Green	0	
48	Blue	0	
49	Red	0	
50	Green	0	
51	Blue	0	
52	Red	0	
53	Green	0	
54	Blue	0	
55	Red	0	
56	Green	0	
57	Blue	0	
58	Red	0	
59	Green	0	
60	Blue	0	
61	Red	0	
62	Green	0	
63	Blue	0	
64	Red	0	
65	Green	0	
66	Blue	0	
67	Red	0	
68	Green	0	
69	Blue	0	
70	Red	0	
71	Green	0	

Simple Pixel 92CH (continued)

Ch	Function	Default	DMX values
72	Blue	0	
73	Color Add CW	0	
74	Color Add CW	0	
75	Color Add CW	0	
76	Color Add CW	0	
77	Color Add CW	0	
78	Color Add CW	0	
79	Color Add CW	0	
80	Color Add CW	0	
81	Color Add CW	0	
82	Color Add CW	0	
83	Color Add CW	0	
84	Color Add CW	0	
85	Color Add CW	0	
86	Color Add CW	0	
87	Color Add CW	0	
88	Color Add CW	0	
89	Color Add CW	0	
90	Color Add CW	0	
91	Color Add CW	0	
92	Color Add CW	0	

Basic Full Control 132CH

132 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer	0	
3	Strobe Duration	0	
4	Strobe Rate	0	
5	Strobe Mode Strobe	255	
6	Dimmer	0	
7	Strobe Duration	0	
8	Strobe Rate	0	
9	Strobe Mode Strobe	255	
10	Red	0	
11	Green	0	
12	Blue	0	
13	Effect	0	
14	Effect Speed	0	
15	Effects1Adjust1	0	
16	Effects1Fade	0	
17	Effect	0	
18	Effect Speed	0	
19	Effects1Adjust1	0	
20	Effects1Fade	0	

Basic Full Control 132CH (continued)

Ch	Function	Default	DMX values
21	Dimmer Mode	0	
22	Function	0	
23	Red	0	
24	Green	0	
25	Blue	0	
26	Red	0	
27	Green	0	
28	Blue	0	
29	Red	0	
30	Green	0	
31	Blue	0	
32	Red	0	
33	Green	0	
34	Blue	0	
35	Red	0	
36	Green	0	
37	Blue	0	
38	Red	0	
39	Green	0	
40	Blue	0	
41	Red	0	
42	Green	0	
43	Blue	0	
44	Red	0	
45	Green	0	
46	Blue	0	
47	Red	0	
48	Green	0	
49	Blue	0	
50	Red	0	
51	Green	0	
52	Blue	0	
53	Red	0	
54	Green	0	
55	Blue	0	
56	Red	0	
57	Green	0	
58	Blue	0	
59	Red	0	
60	Green	0	
61	Blue	0	
62	Red	0	
63	Green	0	
64	Blue	0	
65	Red	0	

Basic Full Control 132CH (continued)

Ch	Function	Default	DMX values
66	Green	0	
67	Blue	0	
68	Red	0	
69	Green	0	
70	Blue	0	
71	Red	0	
72	Green	0	
73	Blue	0	
74	Red	0	
75	Green	0	
76	Blue	0	
77	Red	0	
78	Green	0	
79	Blue	0	
80	Red	0	
81	Green	0	
82	Blue	0	
83	Color Add CW	0	
84	Color Add CW	0	
85	Color Add CW	0	
86	Color Add CW	0	
87	Color Add CW	0	
88	Color Add CW	0	
89	Color Add CW	0	
90	Color Add CW	0	
91	Color Add CW	0	
92	Color Add CW	0	
93	Color Add CW	0	
94	Color Add CW	0	
95	Color Add CW	0	
96	Color Add CW	0	
97	Color Add CW	0	
98	Color Add CW	0	
99	Color Add CW	0	
100	Color Add CW	0	
101	Color Add CW	0	
102	Color Add CW	0	
103	Red	0	
104	Green	0	
105	Blue	0	
106	Red	0	
107	Green	0	
108	Blue	0	
109	Red	0	
110	Green	0	

Basic Full Control 132CH (continued)

Ch	Function	Default	DMX values
111	Blue	0	
112	Red	0	
113	Green	0	
114	Blue	0	
115	Red	0	
116	Green	0	
117	Blue	0	
118	Red	0	
119	Green	0	
120	Blue	0	
121	Red	0	
122	Green	0	
123	Blue	0	
124	Red	0	
125	Green	0	
126	Blue	0	
127	Red	0	
128	Green	0	
129	Blue	0	
130	Red	0	
131	Green	0	
132	Blue	0	