Eurolite

AKKU IP UP-4 Entry QCL Spot QuickDMX



Manufacturer	**Eurolite**
Type	**Effect light**
DMX modes	**5**
DMX footprint	**3, 4, 5, 6, 9 channels**
Beam angle	**16°**
Size (W × H × D)	**155 × 232 × 155 mm**
GDTF fixture type	**28689F89-58FC-4097-A598-FA…**

Controls

Extra LED colours · RGB colour mixing · Colour wheel · Effect speed · Dimmer

Safety-relevant functions

Built-in effect programmes

DMX modes

3 Channel	3 ch
4 Channel	4 ch
5 Channel	5 ch
6 Channel	6 ch
9 Channel	9 ch

3 Channel

3 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	

4 Channel

4 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	

5 Channel

5 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Shutter1Strobe	0	0–9 Open 10–254 Slow 255–255 Fast
3	Color Wheel	0	0–9 Off (wheel slot 1) 10–19 Red (wheel slot 2) 20–29 Green (wheel slot 3) 30–39 Blue (wheel slot 4) 40–49 White (wheel slot 5) 50–59 Yellow (wheel slot 6) 60–69 Magenta (wheel slot 7) 70–79 Cyan (wheel slot 8) 80–89 Dark orange (wheel slot 9) 90–99 Green yellow (wheel slot 10) 100–109 Salmon (wheel slot 11) 110–119 Turquoise (wheel slot 12) 120–129 Light green (wheel slot 13) 130–139 Orange (wheel slot 14) 140–149 Straw (wheel slot 15) 150–159 Lavender (wheel slot 16) 160–169 Light Blue (wheel slot 17) 170–179 Dark blue (wheel slot 18) 180–189 Pink (wheel slot 19) 190–255 Full on (wheel slot 20)
4	Effect	0	0–9 Off 10–19 4 Color Fade 20–29 4 Color Change 30–39 7 Color Fade 40–49 7 Color Change 50–59 3 Color Fade 60–69 3 Color Change 70–79 Auto program 7 80–89 Auto program 8 90–255 Auto program 9
5	Effect Speed	0	0–254 Slow 255–255 Fast

6 Channel

6 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	Dimmer	0	0–254 Closed 255–255 Open
6	Shutter1Strobe	0	0–0 Open 1–5 Music 6–10 NoFeature 1 11–254 Slow 255–255 Fast

9 Channel

9 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Shutter1Strobe	0	0–9 Open 10–254 Slow 255–255 Fast
3	Red	255	
4	Green	255	
5	Blue	255	
6	White	255	
7	Color Wheel	0	0–9 Off (wheel slot 1) 10–19 Red (wheel slot 2) 20–29 Green (wheel slot 3) 30–39 Blue (wheel slot 4) 40–49 White (wheel slot 5) 50–59 Yellow (wheel slot 6) 60–69 Magenta (wheel slot 7) 70–79 Cyan (wheel slot 8) 80–89 Dark orange (wheel slot 9) 90–99 Green yellow (wheel slot 10) 100–109 Salmon (wheel slot 11) 110–119 Turquoise (wheel slot 12) 120–129 Light green (wheel slot 13) 130–139 Orange (wheel slot 14) 140–149 Straw (wheel slot 15) 150–159 Lavender (wheel slot 16) 160–169 Light Blue (wheel slot 17) 170–179 Dark blue (wheel slot 18) 180–189 Pink (wheel slot 19) 190–255 Full on (wheel slot 20)
8	Effect	0	0–9 Off 10–19 4 Color Fade 20–29 4 Color Change 30–39 7 Color Fade 40–49 7 Color Change 50–59 3 Color Fade 60–69 3 Color Change 70–79 Auto program 7 80–89 Auto program 8 90–255 Auto program 9
9	Effect Speed	0	0–254 Slow 255–255 Fast