Eurolite

LED PIX-12 HCL Bar



Manufacturer	**Eurolite**
Type	**LED bar**
DMX modes	**3**
DMX footprint	**6, 77 channels**
Beam angle	**20°**
Size (W × H × D)	**1000 × 177 × 105 mm**
GDTF fixture type	**945FE04B-2972-4640-BC64-67F…**

Controls

Extra LED colours · RGB colour mixing · Colour wheel · Strobe · Dimmer

DMX modes

6Chan	6 ch
74Chan invert	6 ch
74Chan	77 ch

6Chan

6 channels

Ch	Function	Default	DMX values
1	Red	255	0–62 0% Red 63–126 25% Red 127–190 50% Red 191–254 75% Red 255–255 100% Red
2	Green	255	0–62 0% Green 63–126 25% Green 127–190 50% Green 191–254 75% Green 255–255 100% Green
3	Blue	255	0–62 0% Blue 63–126 25% Blue 127–190 50% Blue 191–254 75% Blue 255–255 100% Blue
4	White	0	0–62 0% White 63–126 25% White 127–190 50% White 191–254 75% White 255–255 100% White
5	Color Add RY	0	0–62 0% Amber 63–126 25% Amber 127–190 50% Amber 191–254 75% Amber 255–255 100% Amber
6	UV	0	0–62 0% UV 63–126 25% UV 127–190 50% UV 191–254 75% UV 255–255 100% UV

74Chan invert

6 channels

Ch	Function	Default	DMX values
1	Dimmer	255	0–24 0% 25–50 10% 51–62 20% 63–75 25% 76–101 30% 102–126 40% 127–152 50% 153–177 60% 178–190 70% 191–203 75% 204–228 80% 229–254 90% 255–255 100%
2	Shutter / Strobe	0	0–9 Shutter Open 10–124 Strobe Slow 125–252 Strobe Medium 253–255 Strobe Fast
3	Blue	255	0–62 0% Blue 63–126 25% Blue 127–190 50% Blue 191–254 75% Blue 255–255 100% Blue

74Chan invert (continued)

Ch	Function	Default	DMX values
4	White	0	0–62 0% White 63–126 25% White 127–190 50% White 191–254 75% White 255–255 100% White
5	Color Add RY	0	0–62 0% Amber 63–126 25% Amber 127–190 50% Amber 191–254 75% Amber 255–255 100% Amber
6	UV	0	0–62 0% UV 63–126 25% UV 127–190 50% UV 191–254 75% UV 255–255 100% UV

74Chan

77 channels

Ch	Function	Default	DMX values
1	Dimmer	255	
2	Shutter / Strobe	0	0–9 Shutter Open 10–124 Strobe Slow 125–252 Strobe Medium 253–255 Strobe Fast
3	Blue	255	
4	White	0	
5	Color Add RY	0	
6	UV	0	
7	Reserved 7	0	
8	Reserved 8	0	
9	Reserved 9	0	
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	
21	Reserved 21	0	
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	

74Chan (continued)

Ch	Function	Default	DMX values
29	Reserved 29	0	
30	Reserved 30	0	
31	Reserved 31	0	
32	Reserved 32	0	
33	Reserved 33	0	
34	Reserved 34	0	
35	Reserved 35	0	
36	Reserved 36	0	
37	Reserved 37	0	
38	Reserved 38	0	
39	Reserved 39	0	
40	Reserved 40	0	
41	Reserved 41	0	
42	Reserved 42	0	
43	Reserved 43	0	
44	Reserved 44	0	
45	Reserved 45	0	
46	Reserved 46	0	
47	Reserved 47	0	
48	Reserved 48	0	
49	Reserved 49	0	
50	Reserved 50	0	
51	Reserved 51	0	
52	Reserved 52	0	
53	Reserved 53	0	
54	Reserved 54	0	
55	Reserved 55	0	
56	Reserved 56	0	
57	Reserved 57	0	
58	Reserved 58	0	
59	Reserved 59	0	
60	Reserved 60	0	
61	Reserved 61	0	
62	Reserved 62	0	
63	Reserved 63	0	
64	Reserved 64	0	
65	Reserved 65	0	
66	Reserved 66	0	
67	Reserved 67	0	
68	Reserved 68	0	
69	Reserved 69	0	
70	Reserved 70	0	
71	Reserved 71	0	
72	Reserved 72	0	
73	Reserved 73	0	

74Chan (continued)

Ch	Function	Default	DMX values
74	Reserved 74	0	
75	Color Wheel	0	
76	Color Macro1	0	
77	Color Macro1Rate	0	