Eurolite

THA-120F MK2



Manufacturer	**Eurolite**
Type	**Spot**
DMX modes	**3**
DMX footprint	**4, 6, 16 channels**
Beam angle	**15°**
Size (W × H × D)	**330 × 250 × 45 mm**
GDTF fixture type	**39000125-C54D-4C8D-ABC1-FE…**

Controls

Extra LED colours · RGB colour mixing · Colour temperature · Colour wheel · Strobe · Dimmer

Safety-relevant functions

Fixture reset · Strobe

DMX modes

4ch	4 ch
6ch	6 ch
16ch	16 ch

4ch

4 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Green	0	
3	Blue	0	
4	Color Add GY	0	

6ch

6 channels

Ch	Function	Default	DMX values
1	Dimmer	255	
2	Shutter / Strobe	255	0–31 closed 32–95 Strobe 96–159 Pulse Strobe 160–223 random Strobe 224–255 open
3	Red	0	
4	Green	0	
5	Blue	0	
6	Color Add GY	0	

16ch

16 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	Shutter / Strobe	255	0–31 closed 32–95 Strobe 96–159 Pulse Strobe 160–223 random Strobe 224–255 open
4	Red	0	
5	Red Fine	0	Fine byte of Red
6	Green	0	
7	Green Fine	0	Fine byte of Green
8	Blue	0	
9	Blue Fine	0	Fine byte of Blue
10	Color Add GY	0	
11	Color Add GY Fine	0	Fine byte of Color Add GY
12	C TC	0	

16ch (continued)

Ch	Function	Default	DMX values
13	Color Wheel	0	0–0 no function (wheel slot 1) 1–1 Pale yellow (wheel slot 2) 2–2 Straw (wheel slot 2) 3–3 Gold tint (wheel slot 2) 4–4 Spring yellow (wheel slot 2) 5–5 Medium Yellow (wheel slot 2) 6–6 Yellow (wheel slot 2) 7–7 Deep amber (wheel slot 2) 8–8 Deep straw (wheel slot 2) 9–9 Loving Amber (wheel slot 2) 10–10 Gold Amber (wheel slot 2) 11–11 Orange (wheel slot 2) 12–12 Deep orange (wheel slot 2) 13–13 Dark amber (wheel slot 2) 14–14 Millenium gold (wheel slot 2) 15–15 Deep golden amber (wheel slot 2) 16–16 Scarlet (wheel slot 2) 17–17 Primary red (wheel slot 2) 18–18 Bright red (wheel slot 2) 19–19 Medium red (wheel slot 2) 20–20 Fire (wheel slot 2) 21–21 Pink (wheel slot 2) 22–22 Medium Pink (wheel slot 2) 23–23 Dark pink (wheel slot 2) 24–24 Bright pink (wheel slot 2) 25–25 Bright rose (wheel slot 2) 26–26 Special rose pink (wheel slot 2) 27–27 Vanity fair (wheel slot 2) 28–28 Magenta (wheel slot 2) 29–29 Dark magenta (wheel slot 2) 30–30 Rose purple (wheel slot 2) 31–31 Mauve (wheel slot 2) 32–32 Medium purple (wheel slot 2) 33–33 Lavender (wheel slot 2) 34–34 Palace blue (wheel slot 2) 35–35 Dark blue (wheel slot 2) 36–36 Medium blue (wheel slot 2) 37–37 Deep blue (wheel slot 2) 38–38 Daylight blue (wheel slot 2) 39–39 Slate blue (wheel slot 2) 40–40 Light blue (wheel slot 2) 41–41 Sky blue (wheel slot 2) 42–42 Pale navy blue (wheel slot 2) 43–43 Marine blue (wheel slot 2) 44–44 Peacock blue (wheel slot 2) 45–45 Lagoon blue (wheel slot 2) 46–46 Medium blue green (wheel slot 2) 47–47 Dark yellow green (wheel slot 2) 48–48 Primary green (wheel slot 2) 49–49 Fern green (wheel slot 2) 50–50 Moss green (wheel slot 2) 51–51 Dark green (wheel slot 2) 52–52 Lime green (wheel slot 2) 53–53 Pale green (wheel slot 2) 54–179 no function (wheel slot 1) 180–201 colorchange forward (wheel slot 2) 202–207 stop (wheel slot 2) 208–229 colorchange backward (wheel slot 2) 230–234 no function (wheel slot 1) 235–239 random colors fast (wheel slot 2) 240–244 random color medium (wheel slot 2) 245–249 random color slow (wheel slot 2) 250–255 no function (wheel slot 1)

16ch (continued)

Ch	Function	Default	DMX values
14	Tint	0	0–0 no function 1–255 red to green
15	Color Macro1	0	
16	Control1	0	0–100 no function 101–120 Dimspeed LED 121–140 Dimspeed Halogen 141–160 factory reset 161–200 no function 201–210 Dimcurve linear 211–220 dimcurve square 221–230 dimcurve inverse square 231–240 dimcurve S-curve 241–255 no function