
Eurolite

X25



Manufacturer	**Eurolite**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**116 channels**
Beam angle	**25°**
Pan range	**540°**
Tilt range	**220°**
Heads / cells	**26**
Size (W × H × D)	**275 × 140 × 275 mm**
GDTF fixture type	**27E5738A-2B37-46CA-BE3B-0D…**

Controls

Colour wheel · Dimmer · Pixel control · Pan and tilt · Movement speed · Gobos

Safety-relevant functions

Fixture reset

DMX modes

Default 116 ch

Default

116 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Position MSpeed	0	
6	Shutter / Strobe	0	
7	Dimmer	0	
8	Dimmer Curve	0	
9	Color Wheel	0	
10	Gobo	0	
11	Dummy	0	
12	Red	0	
13	Green	0	
14	Blue	0	
15	White	0	
16	Fixture Global Reset	0	
17	Red	0	
18	Green	0	
19	Blue	0	
20	White	0	
21	Red	0	
22	Green	0	
23	Blue	0	
24	White	0	
25	Red	0	
26	Green	0	
27	Blue	0	
28	White	0	
29	Red	0	
30	Green	0	
31	Blue	0	
32	White	0	
33	Red	0	
34	Green	0	
35	Blue	0	
36	White	0	
37	Red	0	
38	Green	0	
39	Blue	0	
40	White	0	
41	Red	0	
42	Green	0	
43	Blue	0	
44	White	0	
45	Red	0	

Default (continued)

Ch	Function	Default	DMX values
46	Green	0	
47	Blue	0	
48	White	0	
49	Red	0	
50	Green	0	
51	Blue	0	
52	White	0	
53	Red	0	
54	Green	0	
55	Blue	0	
56	White	0	
57	Red	0	
58	Green	0	
59	Blue	0	
60	White	0	
61	Red	0	
62	Green	0	
63	Blue	0	
64	White	0	
65	Red	0	
66	Green	0	
67	Blue	0	
68	White	0	
69	Red	0	
70	Green	0	
71	Blue	0	
72	White	0	
73	Red	0	
74	Green	0	
75	Blue	0	
76	White	0	
77	Red	0	
78	Green	0	
79	Blue	0	
80	White	0	
81	Red	0	
82	Green	0	
83	Blue	0	
84	White	0	
85	Red	0	
86	Green	0	
87	Blue	0	
88	White	0	
89	Red	0	
90	Green	0	

Default (continued)

Ch	Function	Default	DMX values
91	Blue	0	
92	White	0	
93	Red	0	
94	Green	0	
95	Blue	0	
96	White	0	
97	Red	0	
98	Green	0	
99	Blue	0	
100	White	0	
101	Red	0	
102	Green	0	
103	Blue	0	
104	White	0	
105	Red	0	
106	Green	0	
107	Blue	0	
108	White	0	
109	Red	0	
110	Green	0	
111	Blue	0	
112	White	0	
113	Red	0	
114	Green	0	
115	Blue	0	
116	White	0	