Event Lighting

FXSTROBE100



Manufacturer	**Event Lighting**
Type	**Strobe**
DMX modes	**3**
DMX footprint	**8, 12, 48 channels**
Size (W × H × D)	**238 × 260 × 238 mm**
GDTF fixture type	**AA811D26-29F0-42C7-BEB3-C2…**

Controls

Extra LED colours · RGB colour mixing · Colour wheel · Dimmer

DMX modes

8 Channel Mode	8 ch
12 Channel Mode	12 ch
48 Channel Mode	48 ch

8 Channel Mode

8 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Shutter1Strobe	0	0–31 Closed 32–63 Open 64–127 Pulse Strobe Slow to Fast 128–191 Fade Strobe Slow to Fast 192–255 Random Strobe Slow to Fast
3	Dimmer	0	
4	Shutter1Strobe	0	0–31 Closed 32–63 Open 64–127 Pulse Strobe Slow to Fast 128–191 Fade Strobe Slow to Fast 192–255 Random Strobe Slow to Fast
5	Animation Wheel1Macro	0	
6	Animation System1Macro	0	0–127 Speed from Fast to Slow 128–255 Speed from Slow to Fast
7	Color Macro1	0	
8	Color Macro1Rate	0	0–127 Speed from Fast to Slow 128–255 Speed from Slow to Fast

12 Channel Mode

12 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Shutter1Strobe	0	0–31 Closed 32–63 Open 64–127 Pulse Strobe Slow to Fast 128–191 Fade Strobe Slow to Fast 192–255 Random Strobe Slow to Fast
3	Dimmer	0	
4	Shutter1Strobe	0	0–31 Closed 32–63 Open 64–127 Pulse Strobe Slow to Fast 128–191 Fade Strobe Slow to Fast 192–255 Random Strobe Slow to Fast
5	Color RGBRed	0	
6	Color RGBGreen	0	
7	Color RGBBlue	0	
8	White	0	
9	Animation Wheel1Macro	0	
10	Animation System1Macro	0	0–127 Speed from Fast to Slow 128–255 Speed from Slow to Fast
11	Color Macro1	0	
12	Color Macro1Rate	0	0–127 Speed from Fast to Slow 128–255 Speed from Slow to Fast

48 Channel Mode

48 channels

Ch	Function	Default	DMX values
1	Dimmer	0	

48 Channel Mode (continued)

Ch	Function	Default	DMX values
2	Shutter1Strobe	63	0–31 Closed 32–63 Open 64–127 Pulse Strobe Slow to Fast 128–191 Fade Strobe Slow to Fast 192–255 Random Strobe Slow to Fast
3	Dimmer	0	
4	Shutter1Strobe	63	0–31 Closed 32–63 Open 64–127 Pulse Strobe Slow to Fast 128–191 Fade Strobe Slow to Fast 192–255 Random Strobe Slow to Fast
5	Color RGBRed	0	
6	Color RGBGreen	0	
7	Color RGBBlue	0	
8	White	0	
9	Animation Wheel1Macro	0	
10	Animation System1Macro	0	0–127 Speed from Fast to Slow 128–255 Speed from Slow to Fast
11	Animation Wheel1Macro	0	
12	Animation System1Macro	0	0–127 Speed from Fast to Slow 128–255 Speed from Slow to Fast
13	Dimmer	0	
14	Dimmer	0	
15	Dimmer	0	
16	Dimmer	0	
17	Color RGBRed	0	
18	Color RGBGreen	0	
19	Color RGBBlue	0	
20	White	0	
21	Color RGBRed	0	
22	Color RGBGreen	0	
23	Color RGBBlue	0	
24	White	0	
25	Color RGBRed	0	
26	Color RGBGreen	0	
27	Color RGBBlue	0	
28	White	0	
29	Color RGBRed	0	
30	Color RGBGreen	0	
31	Color RGBBlue	0	
32	White	0	
33	Color RGBRed	0	
34	Color RGBGreen	0	
35	Color RGBBlue	0	
36	White	0	
37	Color RGBRed	0	
38	Color RGBGreen	0	
39	Color RGBBlue	0	

48 Channel Mode (continued)

Ch	Function	Default	DMX values
40	White	0	
41	Color RGBRed	0	
42	Color RGBGreen	0	
43	Color RGBBlue	0	
44	White	0	
45	Color RGBRed	0	
46	Color RGBGreen	0	
47	Color RGBBlue	0	
48	White	0	