Expolite

TourWash Mini 48 CMW



Manufacturer	**Expolite**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**12 channels**
Beam angle	**26°**
Pan range	**540°**
Tilt range	**250°**
Size (W × H × D)	**215 × 125 × 215 mm**
GDTF fixture type	**9D3AA03A-06A4-46F7-8F26-D4…**

Controls

Extra LED colours · RGB colour mixing · Colour wheel · Strobe · Dimmer · Pan and tilt

Safety-relevant functions

Fixture reset · Strobe

DMX modes

Basic 12Ch — 12 ch

Basic 12Ch

12 channels

Ch	Function	Default	DMX values
1	Shutter / Strobe	0	0–9 Shutter Open 10–124 Strobe Slow 125–252 Strobe Medium 253–255 Strobe Fast
2	Dimmer	0	0–24 0% 25–50 10% 51–62 20% 63–75 25% 76–101 30% 102–126 40% 127–152 50% 153–177 60% 178–190 70% 191–203 75% 204–228 80% 229–254 90% 255–255 100%
3	Pan	128	0–20 -270 21–41 -225 42–63 -180 64–84 -135 85–105 -90 106–127 -45 128–148 0 149–169 45 170–190 90 191–212 135 213–233 180 234–254 225 255–255 270
4	Pan Fine	128	Fine byte of Pan
5	Tilt	128	0–34 135 35–80 90 81–127 45 128–173 0 174–219 -45 220–254 -90 255–255 -135
6	Tilt Fine	128	Fine byte of Tilt
7	Function	0	0–19 No Function (1) 20–39 Pan/Tilt Black enabled 40–59 Pan/Tilt Black disabled 60–79 Fan Auto 80–99 Fan Slow 100–119 Fan Normal 120–139 Fan Fast 140–149 Auto (1) 150–159 Auto (2) 160–169 Test 170–179 Custom 180–199 No Function (2) 200–219 Reset 220–235 No Function (3) 236–239 Dim 0 240–243 Dim 1 244–247 Dim 2 248–251 Dim 3 252–255 Dim 4
8	Color Effects1	0	

Basic 12Ch (continued)

Ch	Function	Default	DMX values
9	Red	255	0–62 0% Red 63–126 25% Red 127–190 50% Red 191–254 75% Red 255–255 100% Red
10	Green	255	0–62 0% Green 63–126 25% Green 127–190 50% Green 191–254 75% Green 255–255 100% Green
11	Blue	255	0–62 0% Blue 63–126 25% Blue 127–190 50% Blue 191–254 75% Blue 255–255 100% Blue
12	White	0	0–62 0% White 63–126 25% White 127–190 50% White 191–254 75% White 255–255 100% White