Fine Art

Fine 250M Spot



Manufacturer	**Fine Art**
Type	**Moving head**
DMX modes	**2**
DMX footprint	**15, 18 channels**
Beam angle	**25°**
Pan range	**540°**
Tilt range	**220°**
Size (W × H × D)	**240 × 450 × 220 mm**
GDTF fixture type	**4219217A-C94E-4A06-B710-C0…**

Controls

Focus · Prism · Colour wheel · Strobe · Dimmer · Movement speed · Gobos · Gobo rotation

Safety-relevant functions

Fixture reset · Strobe · Built-in effect programmes

DMX modes

15 ch
18 ch

15 ch
18 ch

15 ch

15 channels

Ch	Function	Default	DMX values
1	Shutter / Strobe	20	0–19 Closed 20–49 Open 50–72 Strobe 73–79 Open 80–255 FX
2	Dimmer	0	0–254 Closed 255–255 Open
3	Color Wheel	0	0–10 White (wheel slot 1) 11–21 CTC (wheel slot 2) 22–32 Yellow (wheel slot 3) 33–43 Blue (wheel slot 4) 44–54 Pink (wheel slot 5) 55–65 Green (wheel slot 6) 66–76 Blue 1 (wheel slot 7) 77–87 Red (wheel slot 8) 88–98 Magenta (wheel slot 9) 99–109 Blue 2 (wheel slot 10) 110–120 Orange (wheel slot 11) 121–131 Dark Green (wheel slot 12) 132–142 Purple (wheel slot 13) 143–155 White (wheel slot 1) 156–255 Step
4	Gobo	0	0–4 Open (wheel slot 1) 5–10 Rot Gobo 1 (wheel slot 2) 11–15 Rot Gobo 2 (wheel slot 3) 16–20 Rot Gobo 3 (wheel slot 4) 21–25 Rot Gobo 4 (wheel slot 5) 26–30 Rot Gobo 5 (wheel slot 6) 31–35 Rot Gobo 6 (wheel slot 7) 36–42 Rot Gobo 7 (wheel slot 8) 43–50 Open (wheel slot 1) 51–58 Rot Gobo 1 (wheel slot 2) 59–65 Rot Gobo 2 (wheel slot 3) 66–73 Rot Gobo 3 (wheel slot 4) 74–81 Rot Gobo 4 (wheel slot 5) 82–89 Rot Gobo 5 (wheel slot 6) 90–96 Rot Gobo 6 (wheel slot 7) 97–104 Rot Gobo 7 (wheel slot 8) 105–209 Gobo1WheelShake 2 210–232 Gobo Scroll CW 233–255 Gobo Scroll CCW
5	Gobo Rotation	0	
6	Gobo Rotation Fine	0	Fine byte of Gobo Rotation

15 ch (continued)

Ch	Function	Default	DMX values
7	Gobo 2	0	0–7 Open (wheel slot 1) 8–15 Static Gobo 1 (wheel slot 2) 16–23 Static Gobo 2 (wheel slot 3) 24–31 Static Gobo 3 (wheel slot 4) 32–39 Static Gobo 4 (wheel slot 5) 40–47 Static Gobo 5 (wheel slot 6) 48–55 Static Gobo 6 (wheel slot 7) 56–63 Static Gobo 7 (wheel slot 8) 64–71 Static Gobo 8 (wheel slot 9) 72–79 Static Gobo 9 (wheel slot 10) 80–87 Static Gobo 10 (wheel slot 11) 88–95 Open 96–105 Static Gobo 10 Shake (wheel slot 11) 106–115 Static Gobo 9 Shake (wheel slot 10) 116–125 Static Gobo 8 Shake (wheel slot 9) 126–135 Static Gobo 7 Shake (wheel slot 8) 136–145 Static Gobo 6 Shake (wheel slot 7) 146–155 Static Gobo 5 Shake (wheel slot 6) 156–165 Static Gobo 4 Shake (wheel slot 5) 166–175 Static Gobo 3 Shake (wheel slot 4) 176–185 Static Gobo 2 Shake (wheel slot 3) 186–191 Static Gobo 1 Shake (wheel slot 2) 192–205 Open 206–230 Gobo Scroll CW 231–255 Gobo Scroll CCW
8	Focus	0	
9	Prism	0	
10	Pan	128	
11	Pan Fine	0	Fine byte of Pan
12	Tilt	128	
13	Tilt Fine	0	Fine byte of Tilt
14	Position MSpeed	0	
15	Effect	0	

18 ch

18 channels

Ch	Function	Default	DMX values
1	Shutter / Strobe	20	0–19 Closed 20–49 Open 50–72 Strobe 73–79 Open 80–255 FX
2	Dimmer	0	0–254 Closed 255–255 Open
3	Dimmer Fine	0	Fine byte of Dimmer

18 ch (continued)

Ch	Function	Default	DMX values
4	Color Wheel	0	0–10 White (wheel slot 1) 11–21 CTC (wheel slot 2) 22–32 Yellow (wheel slot 3) 33–43 Blue (wheel slot 4) 44–54 Pink (wheel slot 5) 55–65 Green (wheel slot 6) 66–76 Blue 1 (wheel slot 7) 77–87 Red (wheel slot 8) 88–98 Magenta (wheel slot 9) 99–109 Blue 2 (wheel slot 10) 110–120 Orange (wheel slot 11) 121–131 Dark Green (wheel slot 12) 132–142 Purple (wheel slot 13) 143–155 White (wheel slot 1) 156–255 Step
5	Color Wheel Fine	0	Fine byte of Color Wheel
6	Gobo	0	0–4 Open (wheel slot 1) 5–10 Rot Gobo 1 (wheel slot 2) 11–15 Rot Gobo 2 (wheel slot 3) 16–20 Rot Gobo 3 (wheel slot 4) 21–25 Rot Gobo 4 (wheel slot 5) 26–30 Rot Gobo 5 (wheel slot 6) 31–35 Rot Gobo 6 (wheel slot 7) 36–42 Rot Gobo 7 (wheel slot 8) 43–50 Open (wheel slot 1) 51–58 Rot Gobo 1 (wheel slot 2) 59–65 Rot Gobo 2 (wheel slot 3) 66–73 Rot Gobo 3 (wheel slot 4) 74–81 Rot Gobo 4 (wheel slot 5) 82–89 Rot Gobo 5 (wheel slot 6) 90–96 Rot Gobo 6 (wheel slot 7) 97–104 Rot Gobo 7 (wheel slot 8) 105–209 Gobo1WheelShake 2 210–232 Gobo Scroll CW 233–255 Gobo Scroll CCW
7	Gobo Rotation	0	
8	Gobo Rotation Fine	0	Fine byte of Gobo Rotation

18 ch (continued)

Ch	Function	Default	DMX values
9	Gobo 2	0	0–7 Open (wheel slot 1) 8–15 Static Gobo 1 (wheel slot 2) 16–23 Static Gobo 2 (wheel slot 3) 24–31 Static Gobo 3 (wheel slot 4) 32–39 Static Gobo 4 (wheel slot 5) 40–47 Static Gobo 5 (wheel slot 6) 48–55 Static Gobo 6 (wheel slot 7) 56–63 Static Gobo 7 (wheel slot 8) 64–71 Static Gobo 8 (wheel slot 9) 72–79 Static Gobo 9 (wheel slot 10) 80–87 Static Gobo 10 (wheel slot 11) 88–95 Open 96–105 Static Gobo 10 Shake (wheel slot 11) 106–115 Static Gobo 9 Shake (wheel slot 10) 116–125 Static Gobo 8 Shake (wheel slot 9) 126–135 Static Gobo 7 Shake (wheel slot 8) 136–145 Static Gobo 6 Shake (wheel slot 7) 146–155 Static Gobo 5 Shake (wheel slot 6) 156–165 Static Gobo 4 Shake (wheel slot 5) 166–175 Static Gobo 3 Shake (wheel slot 4) 176–185 Static Gobo 2 Shake (wheel slot 3) 186–191 Static Gobo 1 Shake (wheel slot 2) 192–205 Open 206–230 Gobo Scroll CW 231–255 Gobo Scroll CCW
10	Focus	0	
11	Focus Fine	0	Fine byte of Focus
12	Prism	0	
13	Pan	128	
14	Pan Fine	0	Fine byte of Pan
15	Tilt	128	
16	Tilt Fine	0	Fine byte of Tilt
17	Position MSpeed	0	
18	Effect	0	