Fine Art

FINE I 700 Beam



Manufacturer	**Fine Art**
Type	**Profile spot**
DMX modes	**1**
DMX footprint	**22 channels**
Beam angle	**25°**
Pan range	**540°**
Tilt range	**220°**
Size (W × H × D)	**240 × 450 × 220 mm**
GDTF fixture type	**F94935D6-990B-479E-9B5D-5C…**

Controls

Focus · Frost · Iris · Prism · Prism rotation · CMY colour mixing · Colour wheel · Strobe · Dimmer · Gobos · Gobo rotation

Safety-relevant functions

Lamp on and off · Fixture reset · Strobe

DMX modes

Standard 22 ch

Standard

22 channels

Ch	Function	Default	DMX values
1	Cyan	0	
2	Magenta	0	
3	Yellow	0	
4	Color1Wheel Index	0	0–14 Open (wheel slot 1) 15–28 Red (wheel slot 2) 29–42 CTB (wheel slot 3) 43–56 CTO 4000K (wheel slot 4) 57–71 CTO 2800K (wheel slot 5) 72–85 Green (wheel slot 6) 86–99 Cyan (wheel slot 7) 100–113 Amber (wheel slot 8) 114–127 Indigo (wheel slot 9) 128–255 Color1WheelSpin 2
5	Shutter / Strobe	0	0–4 Open 5–101 Strobe Slow -> Fast 102–191 Pulse Slow -> Fast 192–254 Burst Slow -> Fast 255–255 Open
6	Dimmer	0	0–254 Closed 255–255 Open
7	Dimmer Fine	0	Fine byte of Dimmer
8	Iris	127	0–126 Close 127–127 Open 128–165 Strobe Slow -> Fast 166–191 Pulse Open Slow -> Fast 192–254 Pulse Close Slow -> Fast 255–255 Open
9	Gobo 2	0	0–8 Open (wheel slot 1) 9–16 Dot S (wheel slot 2) 17–24 Dot M (wheel slot 3) 25–33 Dot L (wheel slot 4) 34–41 Star (wheel slot 5) 42–49 Dot Circles (wheel slot 6) 50–57 Circle (wheel slot 7) 58–67 Splash (wheel slot 8) 68–76 Splatter (wheel slot 9) 77–115 Spin CCW Fast -> Slow 116–153 Spin CW Slow -> Fast 154–255 Shake Slow -> Fast
10	Gobo	0	0–16 Open (wheel slot 1) 17–32 Bar (wheel slot 2) 33–48 Rectangle (wheel slot 3) 49–64 Square (wheel slot 4) 65–80 Offcenter (wheel slot 5) 81–96 Fan (wheel slot 6) 97–112 Double (wheel slot 7) 113–127 Arch (wheel slot 8) 128–255 Shake Slow -> Fast
11	Gobo Rotation	0	0–127 Index 128–191 Rotate CW Fast -> Slow 192–192 Stop 193–255 Rotate CCW Slow -> Fast
12	Prism	0	0–127 Open 128–255 5 Facet
13	Prism Rotation	0	0–127 Index 128–191 Rotate CW Fast -> Slow 192–192 Stop 193–255 Rotate CCW Slow -> Fast

Standard (continued)

Ch	Function	Default	DMX values
14	Frost1	0	0–254 Frost open 255–255 Frost full
15	Focus	0	
16	Pan	128	
17	Pan Fine	0	Fine byte of Pan
18	Tilt	128	
19	Tilt Fine	0	Fine byte of Tilt
20	Dummy	0	
21	Fixture Global Reset	0	
22	Lamp Control	0	58–79 Lamp Off 80–254 Lamp Modes 255–255 Lamp On