Flash

EVENT Moving Head 8R



Manufacturer	**Flash**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**16 channels**
Beam angle	**25°**
Pan range	**540°**
Tilt range	**220°**
Size (W × H × D)	**240 × 450 × 220 mm**
GDTF fixture type	**DC8FAD93-D7F2-47E4-99E3-0F…**

Controls

Focus · Frost · Prism · Prism rotation · Colour wheel · Strobe · Dimmer · Movement speed · Gobos

Safety-relevant functions

Lamp on and off · Fixture reset

DMX modes

16ch 16 ch

16ch

16 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Tilt	128	
3	Pan Fine	0	Fine byte of Pan
4	Tilt Fine	0	Fine byte of Tilt
5	Position MSpeed	0	0–254 Fast 255–255 Slow
6	Frost1	0	0–79 Open 80–159 Frost 160–255 7 colors
7	Shutter / Strobe	255	0–3 Closed 4–102 Shutter1Strobe 2 · Min 1–14.9 Hz 103–103 Shutter1Strobe 2 · Max 15 Hz 104–107 Open 108–250 Shutter1StrobePulse 4 · Min 1–14.9 Hz 251–251 Shutter1StrobePulse 4 · Max 15 Hz 252–255 Open
8	Dimmer	0	0–254 Closed 255–255 Open
9	Color Wheel	0	0–8 Open (wheel slot 1) 9–17 Red (wheel slot 2) 18–26 Yellow (wheel slot 3) 27–36 Cyan (wheel slot 4) 37–45 Green (wheel slot 5) 46–54 Orange (wheel slot 6) 55–63 Light green (wheel slot 7) 64–72 Light orange (wheel slot 8) 73–81 Violet (wheel slot 9) 82–90 Blue (wheel slot 10) 91–100 Yellow 2 (wheel slot 11) 101–109 CTO (wheel slot 12) 110–118 CTB (wheel slot 13) 119–127 UV (wheel slot 14) 128–191 Spin CCW 192–255 Spin CW
10	Color Effects1	0	0–127 Full step 128–255 Micro step
11	Gobo	0	0–8 Open (wheel slot 1) 9–17 Gobo 1 (wheel slot 2) 18–26 Gobo 2 (wheel slot 3) 27–36 Gobo 3 (wheel slot 4) 37–45 Gobo 4 (wheel slot 5) 46–54 Gobo 5 (wheel slot 6) 55–63 Gobo 6 (wheel slot 7) 64–72 Gobo 7 (wheel slot 8) 73–81 Gobo 8 (wheel slot 9) 82–90 Gobo 9 (wheel slot 10) 91–100 Gobo 10 (wheel slot 11) 101–109 Gobo 11 (wheel slot 12) 110–118 Gobo 12 (wheel slot 13) 119–127 Gobo 13 (wheel slot 14) 128–191 Spin CCW 192–255 Spin CW
12	Gobo1Wheel Shake	0	0–190 Min 191–191 Max 192–255 NoFeature 1
13	Focus	0	

16ch (continued)

Ch	Function	Default	DMX values
14	Prism	0	0–31 Open 32–63 Prism 1 64–127 Prism 2 128–255 Prism 1+2
15	Prism Rotation	0	0–126 Min 127–127 Max 128–191 Rot CCW 192–255 Rot CW
16	Control1	0	0–100 No function 101–200 Lamp OFF 201–205 Lamp ON 206–255 Reset