Flash

LED STROBE F9700341



Manufacturer	**Flash**
Type	**Strobe**
DMX modes	**4**
DMX footprint	**4, 11, 25, 32 channels**
Beam angle	**25°**
Size (W × H × D)	**390 × 250 × 150 mm**
GDTF fixture type	**166C7790-4A86-4519-83E1-2C…**

Controls

Extra LED colours · RGB colour mixing · Effect speed · Strobe · Dimmer

Safety-relevant functions

Strobe · Built-in effect programmes

DMX modes

4 channel	4 ch
11 channel	11 ch
32 channel	25 ch
39 channel	32 ch

4 channel

4 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Green	0	
3	Blue	0	
4	White	0	

11 channel

11 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Shutter / Strobe	0	

11 channel (continued)

Ch	Function	Default	DMX values
3	Effect	0	0–2 No function 3–5 Red (wheel slot 2) 6–8 Green (wheel slot 3) 9–11 Blue (wheel slot 4) 12–14 Yellow (wheel slot 5) 15–17 Magenta (wheel slot 6) 18–20 Cyan (wheel slot 7) 21–23 White (wheel slot 8) 24–26 Macro 27–29 Macro 2 30–32 Macro 3 33–35 Macro 4 36–38 Macro 5 39–41 Macro 6 42–44 Macro 7 45–47 Macro 8 48–50 Macro 9 51–53 Macro 10 54–56 Macro 11 57–59 Macro 12 60–62 Macro 13 63–65 Macro 14 66–68 Macro 15 69–71 Macro 16 72–74 Macro 17 75–77 Macro 18 78–80 Macro 19 81–83 Macro 20 84–86 Macro 21 87–89 Macro 22 90–92 Macro 23 93–95 Macro 24 96–98 Macro 25 99–101 Macro 26 102–104 Macro 27 105–107 Macro 28 108–110 Macro 29 111–113 Macro 30 114–116 Macro 31 117–119 Macro 32 120–122 Macro 33 123–125 Macro 34 126–128 Macro 35 129–131 Macro 36 132–134 Macro 37 135–137 Macro 38 138–140 Macro 39 141–143 Macro 40 144–146 Macro 41 147–149 Macro 42 150–152 Macro 43 153–155 Macro 44 156–158 Macro 45 159–161 Macro 46 162–164 Macro 47 165–167 Macro 48 168–170 Macro 49 171–173 Macro 50 174–176 Macro 51 177–179 Macro 52 180–182 Macro 53 183–185 Macro 54 186–188 Macro 55 189–191 Macro 56

11 channel (continued)

Ch	Function	Default	DMX values
4	Effect Speed	0	
5	Red	0	
6	Green	0	
7	Blue	0	
8	Shutter / Strobe	0	
9	Effect	0	0–5 No function 6–11 Macro 1 12–17 Macro 2 18–23 Macro 3 24–29 Macro 4 30–35 Macro 5 36–41 Macro 6 42–47 Macro 7 48–53 Macro 8 54–59 Macro 9 60–65 Macro 10 66–71 Macro 11 72–77 Macro 12 78–83 Macro 13 84–89 Macro 14 90–95 Macro 15 96–101 Macro 16 102–107 Macro 17 108–113 Macro 18 114–119 Macro 19 120–125 Macro 20 126–131 Macro 21 132–137 Macro 22 138–143 Macro 23 144–149 Macro 24 150–155 Macro 25 156–161 Macro 26 162–167 Macro 27 168–173 Macro 28 174–179 Macro 29 180–185 Macro 30 186–191 Macro 31 192–197 Macro 32 198–209 Macro 33 210–215 Macro 34 216–221 Macro 35 222–227 Macro 36 228–233 Macro 37 234–239 Macro 38 240–245 Macro 39 246–251 Macro 40 252–255 Macro 41
10	Effect Speed	0	
11	Dimmer	0	0–254 Closed 255–255 Open

32 channel

25 channels

Ch	Function	Default	DMX values
1	Red	0	
2	Green	0	
3	Blue	0	

32 channel (continued)

Ch	Function	Default	DMX values
4	Reserved 4	0	
5	Reserved 5	0	
6	Reserved 6	0	
7	Reserved 7	0	
8	Reserved 8	0	
9	Reserved 9	0	
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	
21	Reserved 21	0	
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	
25	Dimmer	0	0–254 Closed 255–255 Open

39 channel

32 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Shutter / Strobe	0	

39 channel (continued)

Ch	Function	Default	DMX values
3	Effect	0	0–2 No function 3–5 Red (wheel slot 2) 6–8 Green (wheel slot 3) 9–11 Blue (wheel slot 4) 12–14 Yellow (wheel slot 5) 15–17 Magenta (wheel slot 6) 18–20 Cyan (wheel slot 7) 21–23 White (wheel slot 8) 24–26 Macro 27–29 Macro 2 30–32 Macro 3 33–35 Macro 4 36–38 Macro 5 39–41 Macro 6 42–44 Macro 7 45–47 Macro 8 48–50 Macro 9 51–53 Macro 10 54–56 Macro 11 57–59 Macro 12 60–62 Macro 13 63–65 Macro 14 66–68 Macro 15 69–71 Macro 16 72–74 Macro 17 75–77 Macro 18 78–80 Macro 19 81–83 Macro 20 84–86 Macro 21 87–89 Macro 22 90–92 Macro 23 93–95 Macro 24 96–98 Macro 25 99–101 Macro 26 102–104 Macro 27 105–107 Macro 28 108–110 Macro 29 111–113 Macro 30 114–116 Macro 31 117–119 Macro 32 120–122 Macro 33 123–125 Macro 34 126–128 Macro 35 129–131 Macro 36 132–134 Macro 37 135–137 Macro 38 138–140 Macro 39 141–143 Macro 40 144–146 Macro 41 147–149 Macro 42 150–152 Macro 43 153–155 Macro 44 156–158 Macro 45 159–161 Macro 46 162–164 Macro 47 165–167 Macro 48 168–170 Macro 49 171–173 Macro 50 174–176 Macro 51 177–179 Macro 52 180–182 Macro 53 183–185 Macro 54 186–188 Macro 55 189–191 Macro 56

39 channel (continued)

Ch	Function	Default	DMX values
4	Effect Speed	0	
5	Red	0	
6	Green	0	
7	Blue	0	
8	Reserved 8	0	
9	Reserved 9	0	
10	Reserved 10	0	
11	Reserved 11	0	
12	Reserved 12	0	
13	Reserved 13	0	
14	Reserved 14	0	
15	Reserved 15	0	
16	Reserved 16	0	
17	Reserved 17	0	
18	Reserved 18	0	
19	Reserved 19	0	
20	Reserved 20	0	
21	Reserved 21	0	
22	Reserved 22	0	
23	Reserved 23	0	
24	Reserved 24	0	
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	
29	Shutter / Strobe	0	

39 channel (continued)

Ch	Function	Default	DMX values
30	Effect	0	0–5 No function 6–11 Macro 1 12–17 Macro 2 18–23 Macro 3 24–29 Macro 4 30–35 Macro 5 36–41 Macro 6 42–47 Macro 7 48–53 Macro 8 54–59 Macro 9 60–65 Macro 10 66–71 Macro 11 72–77 Macro 12 78–83 Macro 13 84–89 Macro 14 90–95 Macro 15 96–101 Macro 16 102–107 Macro 17 108–113 Macro 18 114–119 Macro 19 120–125 Macro 20 126–131 Macro 21 132–137 Macro 22 138–143 Macro 23 144–149 Macro 24 150–155 Macro 25 156–161 Macro 26 162–167 Macro 27 168–173 Macro 28 174–179 Macro 29 180–185 Macro 30 186–191 Macro 31 192–197 Macro 32 198–209 Macro 33 210–215 Macro 34 216–221 Macro 35 222–227 Macro 36 228–233 Macro 37 234–239 Macro 38 240–245 Macro 39 246–251 Macro 40 252–255 Macro 41
31	Effect Speed	0	
32	Dimmer	0	0–254 Closed 255–255 Open