flashPRO

FOG Machine GEIZER 6x10W 4in1 LED DMX



Manufacturer	**flashPRO**
Type	**Smoke machine**
DMX modes	**11**
DMX footprint	**1, 2, 4, 5, 7, 8, 9 channels**
Beam angle	**25°**
Size (W × H × D)	**250 × 150 × 250 mm**
GDTF fixture type	**5F9096AB-1E3B-4A6C-849A-4E…**

Controls

Haze or smoke output · Extra LED colours · RGB colour mixing · Colour wheel · Strobe · Dimmer

Safety-relevant functions

Haze or smoke output · Strobe

DMX modes

FOG	1 ch
FOG + macro	2 ch
RGB	4 ch
RGBW	5 ch
Classic-6	7 ch
Pro-6	7 ch
RGB 16bit	7 ch
Pro-7	8 ch
Classic-8	9 ch
Flash A-DMX	9 ch
RGBW 16bit	9 ch

FOG

1 channel

Ch	Function	Default	DMX values
1	Fog	0	

FOG + macro

2 channels

Ch	Function	Default	DMX values
1	Fog	0	
2	Color Macro1	0	

RGB

4 channels

Ch	Function	Default	DMX values
1	Fog	0	
2	Red	255	
3	Green	255	
4	Blue	255	

RGBW

5 channels

Ch	Function	Default	DMX values
1	Fog	0	
2	Red	255	
3	Green	255	
4	Blue	255	
5	White	0	

Classic-6

7 channels

Ch	Function	Default	DMX values
1	Fog	0	
2	Dimmer	0	0–254 Closed 255–255 Open
3	Shutter / Strobe	0	0–10 Open 11–254 Min strobe 255–255 Max strobe
4	Red	255	
5	Green	255	
6	Blue	255	
7	White	0	

Pro-6

7 channels

Ch	Function	Default	DMX values
1	Fog	0	
2	Red	255	
3	Green	255	
4	Blue	255	
5	White	0	

Pro-6 (continued)

Ch	Function	Default	DMX values
6	Dimmer	0	0–254 Closed 255–255 Open
7	Shutter / Strobe	0	0–10 Open 11–254 Min strobe 255–255 Max strobe

RGB 16bit

7 channels

Ch	Function	Default	DMX values
1	Fog	0	
2	Red	255	
3	Red Fine	255	Fine byte of Red
4	Green	255	
5	Green Fine	255	Fine byte of Green
6	Blue	255	
7	Blue Fine	255	Fine byte of Blue

Pro-7

8 channels

Ch	Function	Default	DMX values
1	Fog	0	
2	Red	255	
3	Green	255	
4	Blue	255	
5	White	0	
6	Dimmer	0	0–254 Closed 255–255 Open
7	Dimmer Fine	0	Fine byte of Dimmer
8	Shutter / Strobe	0	0–10 Open 11–254 Min strobe 255–255 Max strobe

Classic-8

9 channels

Ch	Function	Default	DMX values
1	Fog	0	
2	Dimmer	0	0–254 Closed 255–255 Open
3	Shutter / Strobe	0	0–10 Open 11–254 Min strobe 255–255 Max strobe
4	Red	255	
5	Green	255	
6	Blue	255	
7	White	0	
8	Color Macro1	0	
9	Color Macro1Rate	0	0–0 Open 1–254 Fast pulse 255–255 Slow pulse

Flash A-DMX

9 channels

Ch	Function	Default	DMX values
1	Fog	0	
2	Red	255	
3	Green	255	
4	Blue	255	
5	White	0	
6	Dimmer	0	0–254 Closed 255–255 Open
7	Reserved 7	0	
8	Shutter / Strobe	0	0–10 Open 11–254 Min strobe 255–255 Max strobe
9	Color Macro1	0	

RGBW 16bit

9 channels

Ch	Function	Default	DMX values
1	Fog	0	
2	Red	255	
3	Red Fine	255	Fine byte of Red
4	Green	255	
5	Green Fine	255	Fine byte of Green
6	Blue	255	
7	Blue Fine	255	Fine byte of Blue
8	White	0	
9	White Fine	0	Fine byte of White