GSARC

GS-PAR19



Manufacturer	**GSARC**
Type	**PAR**
DMX modes	**3**
DMX footprint	**9, 11, 18 channels**
Beam angle	**10°**
Heads / cells	**3**
Size (W × H × D)	**292 × 229 × 274 mm**
GDTF fixture type	**1E54D9AC-71A6-4FF3-9018-4F…**

Controls

Extra LED colours · RGB colour mixing · Colour temperature · Colour wheel · Strobe · Dimmer · Pixel control

Safety-relevant functions

Strobe

DMX modes

9 Channel	9 ch
11 Channel	11 ch
18 Channel	18 ch

9 Channel

9 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	No Feature	0	
6	No Feature Fine	0	Fine byte of No Feature
7	C TO	0	1–254 2700k 255–255 8000k
8	Dimmer Curve	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theatre 101–255 Default to Unit Setting
9	Control1	0	0–51 Normal 52–54 Display off 55–72 Display on 73–75 Gamma=2`0 76–78 Gamma=2`2 79–81 Gamma=2`4 82–84 Gamma=2`6 85–99 Gamma=2`8 100–119 Internal program 1 120–139 Internal program 2 140–159 Internal program 3 160–179 Internal program 4 180–199 Internal program 5 200–219 Internal program 6 220–255 Internal program 7

11 Channel

11 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	No Feature	0	
6	No Feature Fine	0	Fine byte of No Feature
7	C TO	0	1–254 2700k 255–255 8000k
8	Shutter / Strobe	0	0–31 Open 32–126 Min Strobe 127–127 Max Strobe 128–189 Min Random 190–190 Max Random 191–254 Min Pulse 255–255 Max Pulse
9	Dimmer	0	0–254 Closed 255–255 Open

11 Channel (continued)

Ch	Function	Default	DMX values
10	Dimmer Curve	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theatre 101–255 Default to Unit Setting
11	Control1	0	0–51 Normal 52–54 Display off 55–72 Display on 73–75 Gamma=2`0 76–78 Gamma=2`2 79–81 Gamma=2`4 82–84 Gamma=2`6 85–99 Gamma=2`8 100–119 Internal program 1 120–139 Internal program 2 140–159 Internal program 3 160–179 Internal program 4 180–199 Internal program 5 200–219 Internal program 6 220–255 Internal program 7

18 Channel

18 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	255	
5	Red	255	
6	Green	255	
7	Blue	255	
8	White	255	
9	Red	255	
10	Green	255	
11	Blue	255	
12	White	255	
13	Color Macro1	0	0–7 No function 8–39 Red to Yellow 40–71 Yellow to Green 72–103 Green to Cyan 104–135 Cyan to Blue 136–167 Blue to Magenta 168–199 Magenta to Red 200–231 Red to White 232–255 Color Rainbow
14	C TO	0	1–254 2700k 255–255 8000k
15	Shutter / Strobe	0	0–31 Open 32–126 Min Strobe 127–127 Max Strobe 128–189 Min Random 190–190 Max Random 191–254 Min Pulse 255–255 Max Pulse

18 Channel (continued)

Ch	Function	Default	DMX values
16	Dimmer	0	0–254 Closed 255–255 Open
17	Dimmer Curve	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theatre 101–255 Default to Unit Setting
18	Control1	0	0–51 Normal 52–54 Display off 55–72 Display on 73–75 Gamma=2`0 76–78 Gamma=2`2 79–81 Gamma=2`4 82–84 Gamma=2`6 85–99 Gamma=2`8 100–119 Internal program 1 120–139 Internal program 2 140–159 Internal program 3 160–179 Internal program 4 180–199 Internal program 5 200–219 Internal program 6 220–255 Internal program 7