LIGHT SKY

PL6103



Manufacturer	**LIGHT SKY**
Type	**Effect light**
DMX modes	**4**
DMX footprint	**5, 12 channels**
Beam angle	**10-50°**
Size (W × H × D)	**335 × 346 × 335 mm**
GDTF fixture type	**9DDDFD0B-4B8F-4BEB-BEAC-8…**

Controls

Zoom · Extra LED colours · RGB colour mixing · Colour wheel · Effect speed · Strobe · Dimmer

Safety-relevant functions

Fixture reset · Strobe · Built-in effect programmes

DMX modes

5CH(HSI)	5 ch
5CH(RGB)	5 ch
12CH(16BIT)	12 ch
12CH(Standard)	12 ch

5CH(HSI)

5 channels

Ch	Function	Default	DMX values
1	H SBHue	0	
2	H SBSaturation	0	
3	Dimmer	0	
4	Shutter / Strobe	0	0–9 Open 48–49 PulseClose 88–89 PulseOpen 118–119 StrobePulse 178–179 Random 248–249 Strobe 255–255 Open
5	Zoom	0	

5CH(RGB)

5 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	White	0	
5	Zoom	0	

12CH(16BIT)

12 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Dimmer Fine	0	Fine byte of Dimmer
3	Red	255	
4	Red Fine	255	Fine byte of Red
5	Green	255	
6	Green Fine	255	Fine byte of Green
7	Blue	255	
8	Blue Fine	255	Fine byte of Blue
9	White	0	
10	White Fine	0	Fine byte of White
11	Shutter / Strobe	0	0–9 Open 48–49 PulseClose 88–89 PulseOpen 118–119 StrobePulse 178–179 Random 248–249 Strobe 255–255 Open
12	Zoom	0	

12CH(Standard)

12 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open

12CH(Standard) (continued)

Ch	Function	Default	DMX values
2	Shutter / Strobe	0	0–9 Open 48–49 PulseClose 88–89 PulseOpen 118–119 StrobePulse 178–179 Random 248–249 Strobe 255–255 Open
3	Red	255	
4	Green	255	
5	Blue	255	
6	White	0	
7	Color Macro1	0	
8	Effect	0	0–5 NO Function 6–30 Effect 1 31–55 Effect 2 56–80 Effect 3 81–105 Effect 4 106–130 Effect 5 131–155 Effect 6 156–180 Effect 7 181–205 Effect 8 206–230 Effect 9 231–255 Effect 10
9	Effect Speed	0	
10	Function	0	0–9 NO Function 10–29 Linear Dimmer 30–69 Dimmer Speed 1 70–129 Dimmer Speed 2 130–189 Dimmer Speed 3 190–255 Dimmer Speed 4
11	Zoom	0	
12	Reset	0	0–128 No Fuction 129–255 Reset