Lotus Light

Elisium 400



Manufacturer	**Lotus Light**
Type	**Profile spot**
DMX modes	**2**
DMX footprint	**22, 26 channels**
Beam angle	**7-31°**
Pan range	**540°**
Tilt range	**270°**
Size (W × H × D)	**270 × 442 × 230 mm**
GDTF fixture type	**5694C86A-74C9-4A09-9D65-D4…**

Controls

Focus · Frost · Iris · Prism · Prism rotation · Zoom · CMY colour mixing · Colour wheel · Strobe · Dimmer · Pan and tilt · Movement speed · Gobos · Gobo rotation

Safety-relevant functions

Fixture reset · Strobe

DMX modes

22Ch Mode	22 ch
26Ch Mode	26 ch

22Ch Mode

22 channels

Ch	Function	Default	DMX values
1	Pan	127	
2	Tilt	127	
3	Position MSpeed	0	
4	Dimmer	0	
5	Shutter / Strobe	255	0–10 Closed - Shutter Closed 11–103 Strobe S > F - Strobe 104–107 Open - Shutter Open 108–207 Strobe Pulse S > F - Strobe Pulse Random 208–212 Open - Shutter Open 213–251 Strobe Random S > F - Strobe Random 252–255 Open - Shutter Open
6	Cyan	0	
7	Magenta	0	
8	Yellow	0	
9	Color Wheel	0	0–59 Open (wheel slot 1) 60–124 CTO 3200K (wheel slot 2) 125–189 CTO 4200K (wheel slot 3) 190–254 CTO 5600K (wheel slot 4) 255–255 CTO 6200K (wheel slot 5)
10	Color Wheel 2	0	0–59 Open (wheel slot 1) 60–124 Lavander (wheel slot 2) 125–254 Dark Blue (wheel slot 3) 255–255 Dark Red (wheel slot 4)
11	Color3	0	0–59 Open (wheel slot 1) 60–124 Light Green (wheel slot 2) 125–254 Pink (wheel slot 3) 255–255 Light Orange (wheel slot 4)
12	Gobo	0	0–5 Open (wheel slot 1) 6–10 Gobo 1 (wheel slot 2) 11–15 Gobo 2 (wheel slot 3) 16–20 Gobo 3 (wheel slot 4) 21–25 Gobo 4 (wheel slot 5) 26–30 Gobo 5 (wheel slot 6) 31–35 Gobo 6 (wheel slot 7) 36–40 Gobo 7 (wheel slot 8) 41–45 Gobo 8 (wheel slot 9) 46–50 Gobo 9 (wheel slot 10) 51–55 Gobo 10 (wheel slot 11) 56–62 Gobo 1 Shake - Gobo Shake (wheel slot 2) 63–69 Gobo 2 Shake - Gobo Shake (wheel slot 3) 70–76 Gobo 3 Shake - Gobo Shake (wheel slot 4) 77–83 Gobo 4 Shake - Gobo Shake (wheel slot 5) 84–90 Gobo 5 Shake - Gobo Shake (wheel slot 6) 91–97 Gobo 6 Shake - Gobo Shake (wheel slot 7) 98–104 Gobo 7 Shake - Gobo Shake (wheel slot 8) 105–111 Gobo 8 Shake - Gobo Shake (wheel slot 9) 112–118 Gobo 9 Shake - Gobo Shake (wheel slot 10) 119–125 Gobo 10 Shake - Gobo Shake (wheel slot 10) 126–190 F > S - Rotate CW 191–255 S > F - Rotate CCW

22Ch Mode (continued)

Ch	Function	Default	DMX values
13	Gobo 2	0	0–7 Open - Gobo Open (wheel slot 1) 8–15 Gobo 1 (wheel slot 2) 16–23 Gobo 2 (wheel slot 3) 24–31 Gobo 3 (wheel slot 4) 32–39 Gobo 4 (wheel slot 5) 40–47 Gobo 5 (wheel slot 6) 48–55 Gobo 6 (wheel slot 7) 56–63 Gobo 7 (wheel slot 8) 64–71 Gobo 1 Shake - Gobo Shake (wheel slot 2) 72–79 Gobo 2 Shake - Gobo Shake (wheel slot 3) 80–87 Gobo 3 Shake - Gobo Shake (wheel slot 4) 88–95 Gobo 4 Shake - Gobo Shake (wheel slot 5) 96–103 Gobo 5 Shake - Gobo Shake (wheel slot 6) 104–111 Gobo 6 Shake - Gobo Shake (wheel slot 7) 112–119 Gobo 7 Shake - Gobo Shake (wheel slot 8) 120–187 F > S - Rotate CW 188–255 S > F - Rotate CCW
14	Gobo Rotation	0	0–127 Indexing - Indexing 128–191 F > S - Rotate CW 192–255 S > F - Rotate CCW
15	Iris	0	0–127 Iris Open - Iris Open 128–192 Iris Pulse Opening S > F - Iris Open 193–255 Iris Pulse Closing S > F - Iris Closed
16	Prism	0	0–127 Open - Custom (wheel slot 1) 128–255 Prism Engage - Prism (wheel slot 2)
17	Prism Rotation	0	0–127 Indexing - Indexing 128–191 S > F - Rotate CW 192–255 S > F - Rotate CCW
18	Frost1	0	0–127 No Func - Custom 128–255 Frost - Full Frost
19	Focus	190	
20	Zoom	127	
21	Focus1Adjust	0	
22	Control1	0	0–99 No Func - Custom 100–149 P/T Reset - Reset 150–199 Motor Function Reset - Reset 200–255 All Reset - Reset

26Ch Mode

26 channels

Ch	Function	Default	DMX values
1	Pan	127	
2	Pan Fine	255	Fine byte of Pan
3	Tilt	127	
4	Tilt Fine	255	Fine byte of Tilt
5	Position MSpeed	0	
6	Dimmer	0	
7	Shutter / Strobe	255	0–10 Closed - Shutter Closed 11–103 Strobe S > F - Strobe 104–107 Open - Shutter Open 108–207 Strobe Pulse S > F - Strobe Pulse Random 208–212 Open - Shutter Open 213–251 Strobe Random S > F - Strobe Random 252–255 Open - Shutter Open
8	Cyan	0	

26Ch Mode (continued)

Ch	Function	Default	DMX values
9	Magenta	0	
10	Yellow	0	
11	Color Wheel	0	0–59 Open (wheel slot 1) 60–124 CTO 3200K (wheel slot 2) 125–189 CTO 4200K (wheel slot 3) 190–254 CTO 5600K (wheel slot 4) 255–255 CTO 6200K (wheel slot 5)
12	Color Wheel 2	0	0–59 Open (wheel slot 1) 60–124 Lavander (wheel slot 2) 125–254 Dark Blue (wheel slot 3) 255–255 Dark Red (wheel slot 4)
13	Color3	0	0–59 Open (wheel slot 1) 60–124 Light Green (wheel slot 2) 125–254 Pink (wheel slot 3) 255–255 Light Orange (wheel slot 4)
14	Gobo	0	0–5 Open (wheel slot 1) 6–10 Gobo (wheel slot 2) 11–15 Gobo 2 (wheel slot 3) 16–20 Gobo 3 (wheel slot 4) 21–25 Gobo 4 (wheel slot 5) 26–30 Gobo 5 (wheel slot 6) 31–35 Gobo 6 (wheel slot 7) 36–40 Gobo 7 (wheel slot 8) 41–45 Gobo 8 (wheel slot 9) 46–50 Gobo 9 (wheel slot 10) 51–55 Gobo 10 (wheel slot 11) 56–62 Gobo 1 Shake (wheel slot 2) 63–69 Gobo 2 Shake (wheel slot 3) 70–76 Gobo 3 Shake (wheel slot 4) 77–83 Gobo 4 Shake (wheel slot 5) 84–90 Gobo 5 Shake (wheel slot 6) 91–97 Gobo 6 Shake (wheel slot 7) 98–104 Gobo 7 Shake (wheel slot 8) 105–111 Gobo 8 Shake (wheel slot 9) 112–118 Gobo 9 Shake (wheel slot 10) 119–125 Gobo 10 Shake (wheel slot 11) 126–190 F > S - Rotate CW 191–255 S > F - Rotate CCW
15	Gobo 2	0	0–7 Open (wheel slot 1) 8–15 Gobo 1 (wheel slot 2) 16–23 Gobo 2 (wheel slot 3) 24–31 Gobo 3 (wheel slot 4) 32–39 Gobo 4 (wheel slot 5) 40–47 Gobo 5 (wheel slot 6) 48–55 Gobo 6 (wheel slot 7) 56–63 Gobo 7 (wheel slot 8) 64–71 Gobo 1 Shake (wheel slot 2) 72–79 Gobo 2 Shake - Gobo Shake (wheel slot 3) 80–87 Gobo 3 Shake (wheel slot 4) 88–95 Gobo 4 Shake (wheel slot 5) 96–103 Gobo 5 Shake (wheel slot 6) 104–111 Gobo 6 Shake (wheel slot 7) 112–119 Gobo 7 Shake (wheel slot 8) 120–187 F > S - Rotate CW 188–255 S > F - Rotate CCW
16	Gobo Rotation	0	0–127 Indexing - Indexing 128–191 F > S - Rotate CW 192–255 S > F - Rotate CCW

26Ch Mode (continued)

Ch	Function	Default	DMX values
17	Iris	0	0–127 Iris Open - Iris Open 128–192 Iris Pulse Opening S > F - Iris Open 193–255 Iris Pulse Closing S > F - Iris Closed
18	Prism	0	0–127 Open - Custom (wheel slot 1) 128–255 Prism Engage - Prism (wheel slot 2)
19	Prism Rotation	0	0–127 Indexing - Indexing 128–191 S > F - Rotate CW 192–255 S > F - Rotate CCW
20	Frost1	0	0–127 No Func - Custom 128–255 Frost - Full Frost
21	Focus	127	
22	Focus Fine	255	Fine byte of Focus
23	Zoom	127	
24	Zoom Fine	255	Fine byte of Zoom
25	Focus2	0	
26	Control1	0	0–119 No Func - Custom 120–160 P/T Reset - Reset 161–200 Motor Function Reset - Reset 201–255 All Reset - Reset