Lotus Light

SCORPION X4



Manufacturer	**Lotus Light**
Type	**Moving head**
DMX modes	**3**
DMX footprint	**20, 34, 93 channels**
Beam angle	**4-40°**
Pan range	**540°**
Tilt range	**540°**
Heads / cells	**23**
Size (W × H × D)	**198 × 210 × 198 mm**
GDTF fixture type	**9063F6F3-8CE1-4CC9-816F-EEF…**

Controls

Focus · Zoom · Extra LED colours · Colour wheel · Effect speed · Dimmer · Pixel control · Pan and tilt · Movement speed

Safety-relevant functions

Fixture reset · Built-in effect programmes

DMX modes

Mode 1 20Ch	20 ch
Mode 2 34 ch	34 ch
Mode 3 93ch	93 ch

Mode 1 20Ch

20 channels

Ch	Function	Default	DMX values
1	Pan	127	
2	Pan Fine	255	Fine byte of Pan
3	Pan Rotate	0	
4	Tilt	127	
5	Tilt Fine	255	Fine byte of Tilt
6	Tilt Rotate	0	
7	Position MSpeed	0	
8	Zoom	128	
9	Dimmer	255	0–254 Closed 255–255 Open
10	Shutter / Strobe	255	
11	Red	255	
12	Green	255	
13	Blue	255	
14	White	255	
15	White	0	
16	Red	0	
17	Green	0	
18	Blue	0	
19	White	0	
20	Fixture Global Reset	0	0–149 No Function 150–255 Reset

Mode 2 34 ch

34 channels

Ch	Function	Default	DMX values
1	Pan	127	
2	Pan Fine	255	Fine byte of Pan
3	Pan Rotate	0	
4	Tilt	127	
5	Tilt Fine	255	Fine byte of Tilt
6	Tilt Rotate	0	0–127 min 128–255 min< max
7	X YSpeed	0	
8	Focus	128	
9	Dimmer	0	0–254 Closed 255–255 Open
10	Shutter / Strobe	255	
11	Red	255	
12	Green	255	
13	Blue	255	
14	White	255	
15	Effect	0	
16	Effect Speed	0	
17	Effect Parameter1	0	
18	Effect Parameter2	0	

Mode 2 34 ch (continued)

Ch	Function	Default	DMX values
19	Shutter / Strobe	0	
20	Dimmer	0	0–254 Closed 255–255 Open
21	Effect	0	
22	Effect Speed	0	
23	Shutter / Strobe	0	
24	Red	0	
25	Green	0	
26	Blue	0	
27	White	0	
28	Effect	0	
29	Effect Speed	0	
30	Effects1Fade	0	
31	Effects1Pos	0	
32	Effect Parameter1	0	
33	Effect Parameter2	0	
34	Control1	0	0–149 No Function 150–255 Reset

Mode 3 93ch

93 channels

Ch	Function	Default	DMX values
1	Pan	127	
2	Pan Fine	255	Fine byte of Pan
3	Pan Rotate	0	
4	Tilt	127	
5	Tilt Fine	255	Fine byte of Tilt
6	Tilt Rotate	0	
7	Position MSpeed	0	
8	Focus	128	
9	Dimmer	255	
10	Shutter / Strobe	0	
11	Red	255	
12	Green	255	
13	Blue	255	
14	White	255	
15	Red	255	
16	Green	255	
17	Blue	255	
18	White	255	
19	Red	255	
20	Green	255	
21	Blue	255	
22	White	255	
23	Red	255	
24	Green	255	

Mode 3 93ch (continued)

Ch	Function	Default	DMX values
25	Blue	255	
26	White	255	
27	Color Macro1	0	
28	Color Macro1Rate	0	
29	Color Wheel	0	
30	Dimmer	0	
31	Shutter / Strobe	0	
32	White	0	
33	White	0	
34	White	0	
35	White	0	
36	White	0	
37	White	0	
38	White	0	
39	White	0	
40	White	0	
41	Color Macro1	0	
42	Color Macro1Rate	0	
43	Shutter / Strobe	0	
44	Red	0	
45	Green	0	
46	Blue	0	
47	Red	0	
48	Green	0	
49	Blue	0	
50	Red	0	
51	Green	0	
52	Blue	0	
53	Red	0	
54	Green	0	
55	Blue	0	
56	Red	0	
57	Green	0	
58	Blue	0	
59	Red	0	
60	Green	0	
61	Blue	0	
62	Red	0	
63	Green	0	
64	Blue	0	
65	Red	0	
66	Green	0	
67	Blue	0	
68	Red	0	
69	Green	0	

Mode 3 93ch (continued)

Ch	Function	Default	DMX values
70	Blue	0	
71	White	0	
72	White	0	
73	White	0	
74	White	0	
75	White	0	
76	White	0	
77	White	0	
78	White	0	
79	White	0	
80	White	0	
81	White	0	
82	White	0	
83	White	0	
84	White	0	
85	White	0	
86	White	0	
87	Color Macro1	0	
88	Color Macro1Rate	0	
89	Color Macro1	0	
90	Color Macro1Rate	0	
91	Color Wheel	0	
92	Dimmer	0	
93	Fixture Global Reset	0	