
Lupo

SUPERPANEL FULL COLOR 30 HARD



Manufacturer	**Lupo**
Type	**PAR**
DMX modes	**32**
DMX footprint	**2, 3, 4, 6, 8, 16 channels**
Beam angle	**25°**
Size (W × H × D)	**338 × 65 × 322 mm**
GDTF fixture type	**B6DFDB09-7307-4BB6-8D6F-F6…**

Controls

Extra LED colours · RGB colour mixing · Colour temperature · Colour wheel · Dimmer

DMX modes

CCT 8Bit	2 ch
DISCO 1 8bit	2 ch
DISCO 2 8bit	2 ch
EXPLOSION 8bit	2 ch
FIRE 8bit	2 ch
FIREWORKS 8bit	2 ch
PARTY 8bit	2 ch
COPCAR 8bit	3 ch
Lightning 8bit	3 ch
Paparazzi 8bit	3 ch
TelevisionBW 8bit	3 ch
TELEVISIONCO 8bit	3 ch
CCT16Bit	4 ch
DISCO 1 16bit	4 ch
DISCO 2 16bit	4 ch
EXPLOSION 16bit	4 ch
FIRE 16bit	4 ch
FIREWORKS 16bit	4 ch
HSI 8bit	4 ch
PARTY 16bit	4 ch
PRESET 8bit	4 ch
COPCAR 16 bit	6 ch
Lightning 16bit	6 ch
Paparazzi 16 bit	6 ch
Televisionbw 16bit	6 ch
TELEVISIONCO 16bit	6 ch
FRGBW 8bit	8 ch

HSI 16bit	8 ch
PRESET 16bit	8 ch
RGBW 8bit	8 ch
FRGBW 16bit	16 ch
RGBW 16bit	16 ch

CCT 8Bit

2 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	C TC	0	

DISCO 1 8bit

2 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	L EDFrequency	0	

DISCO 2 8bit

2 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	L EDFrequency	0	

EXPLOSION 8bit

2 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	L EDFrequency	0	

FIRE 8bit

2 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	L EDFrequency	0	

FIREWORKS 8bit

2 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	L EDFrequency	0	

PARTY 8bit

2 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	L EDFrequency	0	

COPCAR 8bit

3 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Color Effects1	0	
3	Lamp Control	0	

Lightning 8bit

3 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	C TC	0	
3	L EDFrequency	0	

Paparazzi 8bit

3 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	L EDFrequency	0	
3	Lamp Control	0	

TelevisionBW 8bit

3 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	C TC	0	
3	L EDFrequency	0	

TELEVISIONCO 8bit

3 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	C TC	0	
3	L EDFrequency	0	

CCT16Bit

4 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	C TC	0	
4	C TC Fine	0	Fine byte of C TC

DISCO 1 16bit

4 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	L EDFrequency	0	
4	L EDFrequency Fine	0	Fine byte of L EDFrequency

DISCO 2 16bit

4 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	L EDFrequency	0	

DISCO 2 16bit (continued)

Ch	Function	Default	DMX values
4	L EDFrequency Fine	0	Fine byte of L EDFrequency

EXPLOSION 16bit

4 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	L EDFrequency	0	
4	L EDFrequency Fine	0	Fine byte of L EDFrequency

FIRE 16bit

4 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	L EDFrequency	0	
4	L EDFrequency Fine	0	Fine byte of L EDFrequency

FIREWORKS 16bit

4 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	L EDFrequency	0	
4	L EDFrequency Fine	0	Fine byte of L EDFrequency

HSI 8bit

4 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	H SBHue	0	
3	H SBSaturation	0	
4	No Feature	0	

PARTY 16bit

4 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	L EDFrequency	0	
4	L EDFrequency Fine	0	Fine byte of L EDFrequency

PRESET 8bit

4 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	No Feature	0	

PRESET 8bit (continued)

Ch	Function	Default	DMX values
3	Preset Number	0	
4	Preset Enable	0	

COPCAR 16 bit

6 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	Color Effects1	0	
4	Color Effects1 Fine	0	Fine byte of Color Effects1
5	Lamp Control	0	
6	Lamp Control Fine	0	Fine byte of Lamp Control

Lightning 16bit

6 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	C TC	0	
4	C TC Fine	0	Fine byte of C TC
5	L EDFrequency	0	
6	L EDFrequency Fine	0	Fine byte of L EDFrequency

Paparazzi 16 bit

6 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	L EDFrequency	0	
4	L EDFrequency Fine	0	Fine byte of L EDFrequency
5	Lamp Control	0	
6	Lamp Control Fine	0	Fine byte of Lamp Control

Televisionbw 16bit

6 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	C TC	0	
4	C TC Fine	0	Fine byte of C TC
5	L EDFrequency	0	
6	L EDFrequency Fine	0	Fine byte of L EDFrequency

TELEVISIONCO 16bit

6 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	C TC	0	
4	C TC Fine	0	Fine byte of C TC
5	L EDFrequency	0	
6	L EDFrequency Fine	0	Fine byte of L EDFrequency

FRGBW 8bit

8 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Color RGBRed	0	
3	Color RGBGreen	0	
4	Color RGBBlue	0	
5	White	0	
6	C TC	0	
7	Color RGBMagenta	0	
8	No Feature	0	

HSI 16bit

8 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	H SBHue	0	
4	H SBHue Fine	0	Fine byte of H SBHue
5	H SBSaturation	0	
6	H SBSaturation Fine	0	Fine byte of H SBSaturation
7	No Feature	0	
8	No Feature Fine	0	Fine byte of No Feature

PRESET 16bit

8 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	No Feature	0	
4	No Feature Fine	0	Fine byte of No Feature
5	Preset Number	0	
6	Preset Number Fine	0	Fine byte of Preset Number
7	Preset Enable	0	
8	Preset Enable Fine	0	Fine byte of Preset Enable

RGBW 8bit

8 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Color RGBRed	0	
3	Color RGBGreen	0	
4	Color RGBBlue	0	
5	White	0	
6	C TC	0	
7	Color RGBMagenta	0	
8	No Feature	0	

FRGBW 16bit

16 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	Color RGBRed	0	
4	Color RGBRed Fine	0	Fine byte of Color RGBRed
5	Color RGBGreen	0	
6	Color RGBGreen Fine	0	Fine byte of Color RGBGreen
7	Color RGBBlue	0	
8	Color RGBBlue Fine	0	Fine byte of Color RGBBlue
9	White	0	
10	White Fine	0	Fine byte of White
11	C TC	0	
12	C TC Fine	0	Fine byte of C TC
13	Color RGBMagenta	0	
14	Color RGBMagenta Fine	0	Fine byte of Color RGBMagenta
15	No Feature	0	
16	No Feature Fine	0	Fine byte of No Feature

RGBW 16bit

16 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer Fine	0	Fine byte of Dimmer
3	Color RGBRed	0	
4	Color RGBRed Fine	0	Fine byte of Color RGBRed
5	Color RGBGreen	0	
6	Color RGBGreen Fine	0	Fine byte of Color RGBGreen
7	Color RGBBlue	0	
8	Color RGBBlue Fine	0	Fine byte of Color RGBBlue
9	White	0	
10	White Fine	0	Fine byte of White
11	C TC	0	
12	C TC Fine	0	Fine byte of C TC
13	Color RGBMagenta	0	
14	Color RGBMagenta Fine	0	Fine byte of Color RGBMagenta

RGBW 16bit (continued)

Ch	Function	Default	DMX values
15	No Feature	0	
16	No Feature Fine	0	Fine byte of No Feature