MARK

# SIDIUS LLC 368



| | |
|---|---|
| Manufacturer | **MARK** |
| Type | **Moving head** |
| DMX modes | **2** |
| DMX footprint | **15, 23 channels** |
| Beam angle | **53°** |
| Pan range | **1°** |
| Tilt range | **1°** |
| Heads / cells | **3** |
| Size (W × H × D) | **274 × 161 × 273 mm** |
| GDTF fixture type | **A7C27136-7EAA-49A8-8AAC-D…** |

## Controls

Zoom · Extra LED colours · RGB colour mixing · Effect speed · Dimmer · Pixel control · Pan and tilt · Movement speed

## Safety-relevant functions

Fixture reset · Built-in effect programmes

## DMX modes

| | |
|---|---|
| 15 CHANNELS | 15 ch |
| 23 CHANNELS | 23 ch |

## 15 CHANNELS

15 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Pan | 127 | |
| 2 | Pan Fine | 127 | Fine byte of Pan |
| 3 | Tilt | 127 | |
| 4 | Tilt Fine | 127 | Fine byte of Tilt |
| 5 | Position MSpeed | 0 | |
| 6 | Zoom | 127 | |
| 7 | Dimmer | 0 | |
| 8 | Shutter1Strobe | 0 | 0–15 Open<br>16–255 Strobe S > F |
| 9 | Effect | 0 | 0–15 No function<br>16–39 Jump Color Change<br>40–63 Circle Jump Color Change 1<br>64–87 Circle Jump Color Change 2<br>88–111 Macro Jump Circle 1<br>112–135 Macro Jump Circle 2<br>136–159 Circle Gradual Color Change<br>160–183 Macro Pulse Circle<br>184–207 Macro<br>208–231 Circle Pulse Color Change<br>232–255 Circle Jump Color Change 3 |
| 10 | Effect Speed | 0 | |
| 11 | Red | 255 | |
| 12 | Green | 255 | |
| 13 | Blue | 255 | |
| 14 | White | 0 | |
| 15 | Fixture Global Reset | 0 | 0–127 No function<br>128–255 Reset |

## 23 CHANNELS

23 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Pan | 127 | |
| 2 | Pan Fine | 127 | Fine byte of Pan |
| 3 | Tilt | 127 | |
| 4 | Tilt Fine | 127 | Fine byte of Tilt |
| 5 | Position MSpeed | 0 | |
| 6 | Zoom | 127 | |
| 7 | Dimmer | 0 | |
| 8 | Shutter1Strobe | 0 | 0–15 Open<br>16–255 Strobe S > F |
| 9 | Effect | 0 | 0–15 No function<br>16–39 Jump Color Change<br>40–63 Circle Jump Color Change 1<br>64–87 Circle Jump Color Change 2<br>88–111 Macro Jump Circle 1<br>112–135 Macro Jump Circle 2<br>136–159 Circle Gradual Color Change<br>160–183 Macro Pulse Circle<br>184–207 Macro<br>208–231 Circle Pulse Color Change<br>232–255 Circle Jump Color Change 3 |
| 10 | Effect Speed | 0 | |

## 23 CHANNELS (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **11** | Red | 255 | |
| **12** | Green | 255 | |
| **13** | Blue | 255 | |
| **14** | White | 0 | |
| **15** | Red | 255 | |
| **16** | Green | 255 | |
| **17** | Blue | 255 | |
| **18** | White | 0 | |
| **19** | Red | 255 | |
| **20** | Green | 255 | |
| **21** | Blue | 255 | |
| **22** | White | 0 | |
| **23** | Fixture Global Reset | 0 | 0–127 No function<br>128–255 Reset |