Meanreal

Aura 760 ip



Manufacturer	**Meanreal**
Type	**Moving head**
DMX modes	**2**
DMX footprint	**30, 48 channels**
Beam angle	**7-45°**
Pan range	**540°**
Tilt range	**270°**
Heads / cells	**4**
Size (W × H × D)	**228 × 200 × 238 mm**
GDTF fixture type	**617A6ABD-BD0E-8021-DA3C-D…**

Controls

Zoom · Colour wheel · Strobe · Dimmer · Pixel control · Pan and tilt · Movement speed · Gobos

Safety-relevant functions

Fixture reset

DMX modes

30ch	30 ch
78ch	48 ch

30ch

30 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	128	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	128	Fine byte of Tilt
5	Position MSpeed	0	
6	Zoom	255	
7	Beam Shaper	0	0–127 Index 128–190 <<< 191–191 Stop 192–255 >>>
8	Dimmer	0	
9	Shutter / Strobe	0	0–3 Open Shutter 4–198 Slow Strobe 199–199 Fast Strobe 200–254 Slow Random 255–255 Fast Random
10	Red	0	
11	Green	0	
12	Blue	0	
13	White	0	
14	Color Temp	0	
15	Color Macro	0	
16	Gobo	0	
17	Chase	0	
18	Chase Speed	0	
19	Red	0	
20	Green	0	
21	Blue	0	
22	White	0	
23	Dimmer	0	
24	Shutter / Strobe	0	0–3 Open Shutter 4–198 Slow Strobe 199–199 Fast Strobe 200–254 Slow Random 255–255 Fast Random
25	Red	0	
26	Green	0	
27	Blue	0	
28	Chase	0	
29	Chase Speed	0	
30	Control1	0	0–25 No Function 26–76 Effect Reset 77–129 XY Reset 130–134 Fan mute 135–139 Fan Standard 140–191 Fan Full 192–255 Full Reset

78ch

48 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Red Fine	255	Fine byte of Red
3	Green	255	
4	Green Fine	255	Fine byte of Green
5	Blue	255	
6	Blue Fine	255	Fine byte of Blue
7	White	255	
8	White Fine	255	Fine byte of White
9	Color Temp	0	
10	Color Macro	0	
11	Shutter / Strobe	104	0–3 Closed Shutter 4–102 Slow Strobe 103–103 Fast Strobe 104–104 Open Shutter 105–207 Shutter1StrobePulse 4 208–212 Open Shutter 213–251 Slow Random 252–255 Open Shutter
12	Dimmer	0	
13	Dimmer Fine	0	Fine byte of Dimmer
14	Pan	128	
15	Pan Fine	128	Fine byte of Pan
16	Tilt	128	
17	Tilt Fine	128	Fine byte of Tilt
18	Reserved 18	0	
19	Control1	0	0–25 No Function 26–76 Effect Reset 77–129 XY Reset 130–134 Fan mute 135–139 Fan Standard 140–191 Fan Full 192–255 Full Reset
20	Zoom	0	
21	Beam Shaper	0	0–127 Index 128–190 <<< 191–191 Stop 192–255 >>>
22	Red	255	
23	Green	255	
24	Blue	255	
25	Reserved 25	0	
26	Reserved 26	0	
27	Reserved 27	0	
28	Reserved 28	0	
29	Reserved 29	0	
30	Reserved 30	0	
31	Reserved 31	0	
32	Reserved 32	0	
33	Reserved 33	0	
34	Reserved 34	0	

78ch (continued)

Ch	Function	Default	DMX values
35	Reserved 35	0	
36	Reserved 36	0	
37	Reserved 37	0	
38	Reserved 38	0	
39	Reserved 39	0	
40	Reserved 40	0	
41	Reserved 41	0	
42	Reserved 42	0	
43	Red	255	
44	Green	255	
45	Blue	255	
46	Red	255	
47	Green	255	
48	Blue	255	