MegaLite

XS LED Strobe RGB



Manufacturer	**MegaLite**
Type	**Strobe**
DMX modes	**4**
DMX footprint	**3, 7, 8, 9 channels**
Beam angle	**126°**
Heads / cells	**3**
Size (W × H × D)	**346 × 165 × 70 mm**
GDTF fixture type	**F2D10BE8-EBE8-11E5-85B4-F0…**

Controls

RGB colour mixing · Strobe · Dimmer · Pixel control

Safety-relevant functions

Strobe · Built-in effect programmes

DMX modes

Mode1 3Ch	3 ch
Mode2 7Ch	7 ch
Mode3 8Ch	8 ch
Mode4 9Ch	9 ch

Mode1 3Ch

3 channels

Ch	Function	Default	DMX values
1	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
2	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
3	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max

Mode2 7Ch

7 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max
2	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
3	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
4	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
5	Strobe Duration	0	0–0 Min 1–254 Min > Max 255–255 Max
6	Shutter / Strobe	0	0–5 Open - Shutter Open 6–255 Strobe - Strobe
7	Effect	0	0–5 No Func - Custom 6–42 Ramp Up Effect S > F - Effect 43–85 Ramp Down Effect S > F - Effect 86–128 Ramp Up-Down Effect S > F - Effect 129–171 Random Effect S > F - Effect 172–214 Lightning Effect S > F - Effect 215–255 Spike Effect - Effect

Mode3 8Ch

8 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max
2	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
3	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
4	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max

Mode3 8Ch (continued)

Ch	Function	Default	DMX values
5	Strobe Duration	0	0–0 Min 1–254 Min > Max 255–255 Max
6	Shutter / Strobe	0	0–5 Open - Shutter Open 6–255 Strobe - Strobe
7	Effect	0	0–5 No Func - Custom 6–42 Ramp Up Effect S > F - Effect 43–85 Ramp Down Effect S > F - Effect 86–128 Ramp Up-Down Effect S > F - Effect 129–171 Random Effect S > F - Effect 172–214 Lightning Effect S > F - Effect 215–255 Spike Effect - Effect
8	Effect 2	0	0–1 No Func - Custom 2–25 Macro 1 - Macro 26–50 Macro 2 - Macro 51–75 Macro 3 - Macro 76–100 Macro 4 - Macro 101–125 Macro 5 - Macro 126–150 Macro 6 - Macro 151–175 Macro 7 - Macro 176–200 Macro 8 - Macro 201–225 Macro 9 - Macro 226–255 Macro 10 - Macro

Mode4 9Ch

9 channels

Ch	Function	Default	DMX values
1	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
2	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
3	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
4	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
5	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
6	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
7	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
8	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
9	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max