MegaLite

ZipStrip C40



Manufacturer	**MegaLite**
Type	**Effect light**
DMX modes	**4**
DMX footprint	**3, 9, 120, 129 channels**
Beam angle	**2.7°**
Heads / cells	**41**
Size (W × H × D)	**83 × 49 × 41 mm**
GDTF fixture type	**C0A5C8AD-638E-11EF-B1D9-52…**

Controls

RGB colour mixing · Colour wheel · Effect speed · Strobe · Dimmer · Pixel control

Safety-relevant functions

Built-in effect programmes

DMX modes

3 Channel Mode	3 ch
9 Channel Mode	9 ch
120 Channel Mode	120 ch
129 Channel Mode	129 ch

3 Channel Mode

3 channels

Ch	Function	Default	DMX values
1	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
2	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
3	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max

9 Channel Mode

9 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–0 Min 1–254 Min > Max 255–255 Max
2	Red	255	0–0 Min 1–254 Min > Max 255–255 Max
3	Green	255	0–0 Min 1–254 Min > Max 255–255 Max
4	Blue	255	0–0 Min 1–254 Min > Max 255–255 Max
5	Shutter / Strobe	0	0–9 Open - Shutter Open 10–99 Strobe S > F - Strobe 100–149 Pulse Strobe S > F - Strobe Pulse Random 150–199 Strobe Random All S > F - Strobe Random 200–255 Strobe Random Each S > F - Strobe Random
6	Effect	0	0–9 No Function - Custom 10–49 Macro 1 - Macro 50–99 Macro 2 - Macro 100–109 Macro 3 - Macro 110–119 Macro 4 - Macro 120–129 Macro 5 - Macro 130–139 Macro 6 - Macro 140–149 Macro 7 - Macro 150–159 Macro 8 - Macro 160–169 Macro 9 - Macro 170–179 Macro 10 - Macro 180–189 Macro 11 - Macro 190–199 Macro 12 - Macro 200–209 Macro 13 - Macro 210–219 Macro 14 - Macro 220–227 Macro 15 - Macro 228–255 Macro 16 - Macro
7	Effect Speed	0	0–0 Min 1–254 Min > Max 255–255 Max

9 Channel Mode (continued)

Ch	Function	Default	DMX values
8	Color Macro1	0	0–9 No Function - Custom 10–49 Color Fade All - Effect 50–99 Color Snap All - Effect 100–109 Color Effect 1 - Effect 110–119 Color Effect 2 - Effect 120–129 Color Effect 3 - Effect 130–139 Color Effect 4 - Effect 140–149 Color Effect 5 - Effect 150–159 Color Effect 6 - Effect 160–169 Color Effect 7 - Effect 170–179 Color Effect 8 - Effect 180–189 Color Effect 9 - Effect 190–199 Color Effect 10 - Effect 200–209 Color Effect 11 - Effect 210–219 Color Effect 12 - Effect 220–227 Color Random Fade Each - Effect 228–255 Color Random Snap Each - Effect
9	Color Macro1Rate	0	0–0 Min 1–254 Min > Max 255–255 Max

120 Channel Mode

120 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	Red	255	
5	Green	255	
6	Blue	255	
7	Red	255	
8	Green	255	
9	Blue	255	
10	Red	255	
11	Green	255	
12	Blue	255	
13	Red	255	
14	Green	255	
15	Blue	255	
16	Red	255	
17	Green	255	
18	Blue	255	
19	Red	255	
20	Green	255	
21	Blue	255	
22	Red	255	
23	Green	255	
24	Blue	255	
25	Red	255	
26	Green	255	
27	Blue	255	

120 Channel Mode (continued)

Ch	Function	Default	DMX values
28	Red	255	
29	Green	255	
30	Blue	255	
31	Red	255	
32	Green	255	
33	Blue	255	
34	Red	255	
35	Green	255	
36	Blue	255	
37	Red	255	
38	Green	255	
39	Blue	255	
40	Red	255	
41	Green	255	
42	Blue	255	
43	Red	255	
44	Green	255	
45	Blue	255	
46	Red	255	
47	Green	255	
48	Blue	255	
49	Red	255	
50	Green	255	
51	Blue	255	
52	Red	255	
53	Green	255	
54	Blue	255	
55	Red	255	
56	Green	255	
57	Blue	255	
58	Red	255	
59	Green	255	
60	Blue	255	
61	Red	255	
62	Green	255	
63	Blue	255	
64	Red	255	
65	Green	255	
66	Blue	255	
67	Red	255	
68	Green	255	
69	Blue	255	
70	Red	255	
71	Green	255	
72	Blue	255	

120 Channel Mode (continued)

Ch	Function	Default	DMX values
73	Red	255	
74	Green	255	
75	Blue	255	
76	Red	255	
77	Green	255	
78	Blue	255	
79	Red	255	
80	Green	255	
81	Blue	255	
82	Red	255	
83	Green	255	
84	Blue	255	
85	Red	255	
86	Green	255	
87	Blue	255	
88	Red	255	
89	Green	255	
90	Blue	255	
91	Red	255	
92	Green	255	
93	Blue	255	
94	Red	255	
95	Green	255	
96	Blue	255	
97	Red	255	
98	Green	255	
99	Blue	255	
100	Red	255	
101	Green	255	
102	Blue	255	
103	Red	255	
104	Green	255	
105	Blue	255	
106	Red	255	
107	Green	255	
108	Blue	255	
109	Red	255	
110	Green	255	
111	Blue	255	
112	Red	255	
113	Green	255	
114	Blue	255	
115	Red	255	
116	Green	255	
117	Blue	255	

120 Channel Mode (continued)

Ch	Function	Default	DMX values
118	Red	255	
119	Green	255	
120	Blue	255	

129 Channel Mode

129 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Red	255	
3	Green	255	
4	Blue	255	
5	Shutter / Strobe	0	0–9 Open - Shutter Open 10–99 Strobe S > F - Strobe 100–149 Pulse Strobe S > F - Strobe Pulse Random 150–199 Strobe Random All S > F - Strobe Random 200–255 Strobe Random Each S > F - Strobe Random
6	Effect	0	0–8 No Function - Custom 9–48 Macro 1 - Macro 49–98 Macro 2 - Macro 99–108 Macro 3 - Macro 109–118 Macro 4 - Macro 119–129 Macro 5 - Macro 130–139 Macro 6 - Macro 140–149 Macro 7 - Macro 150–159 Macro 8 - Macro 160–169 Macro 9 - Macro 170–179 Macro 10 - Macro 180–189 Macro 11 - Macro 190–199 Macro 12 - Macro 200–209 Macro 13 - Macro 210–219 Macro 14 - Macro 220–227 Macro 15 - Macro 228–255 Macro 16 - Macro
7	Effect Fine	0	Fine byte of Effect
8	Color Macro1	0	
9	Color Macro1Rate	0	
10	Red	0	
11	Green	0	
12	Blue	0	
13	Red	0	
14	Green	0	
15	Blue	0	
16	Red	0	
17	Green	0	
18	Blue	0	
19	Red	0	
20	Green	0	
21	Blue	0	
22	Red	0	
23	Green	0	
24	Blue	0	

129 Channel Mode (continued)

Ch	Function	Default	DMX values
25	Red	0	
26	Green	0	
27	Blue	0	
28	Red	0	
29	Green	0	
30	Blue	0	
31	Red	0	
32	Green	0	
33	Blue	0	
34	Red	0	
35	Green	0	
36	Blue	0	
37	Red	0	
38	Green	0	
39	Blue	0	
40	Red	0	
41	Green	0	
42	Blue	0	
43	Red	0	
44	Green	0	
45	Blue	0	
46	Red	0	
47	Green	0	
48	Blue	0	
49	Red	0	
50	Green	0	
51	Blue	0	
52	Red	0	
53	Green	0	
54	Blue	0	
55	Red	0	
56	Green	0	
57	Blue	0	
58	Red	0	
59	Green	0	
60	Blue	0	
61	Red	0	
62	Green	0	
63	Blue	0	
64	Red	0	
65	Green	0	
66	Blue	0	
67	Red	0	
68	Green	0	
69	Blue	0	

129 Channel Mode (continued)

Ch	Function	Default	DMX values
70	Red	0	
71	Green	0	
72	Blue	0	
73	Red	0	
74	Green	0	
75	Blue	0	
76	Red	0	
77	Green	0	
78	Blue	0	
79	Red	0	
80	Green	0	
81	Blue	0	
82	Red	0	
83	Green	0	
84	Blue	0	
85	Red	0	
86	Green	0	
87	Blue	0	
88	Red	0	
89	Green	0	
90	Blue	0	
91	Red	0	
92	Green	0	
93	Blue	0	
94	Red	0	
95	Green	0	
96	Blue	0	
97	Red	0	
98	Green	0	
99	Blue	0	
100	Red	0	
101	Green	0	
102	Blue	0	
103	Red	0	
104	Green	0	
105	Blue	0	
106	Red	0	
107	Green	0	
108	Blue	0	
109	Red	0	
110	Green	0	
111	Blue	0	
112	Red	0	
113	Green	0	
114	Blue	0	

129 Channel Mode (continued)

Ch	Function	Default	DMX values
115	Red	0	
116	Green	0	
117	Blue	0	
118	Red	0	
119	Green	0	
120	Blue	0	
121	Red	0	
122	Green	0	
123	Blue	0	
124	Red	0	
125	Green	0	
126	Blue	0	
127	Red	0	
128	Green	0	
129	Blue	0	