Nicols

WP300Z



Manufacturer	**Nicols**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**14 channels**
Beam angle	**25°**
Pan range	**540°**
Tilt range	**220°**
Size (W × H × D)	**240 × 450 × 220 mm**
GDTF fixture type	**A05FEF53-FB77-488E-98C9-262…**

Controls

Zoom · Extra LED colours · RGB colour mixing · Colour wheel · Strobe · Dimmer · Pan and tilt · Movement speed

Safety-relevant functions

Fixture reset · Strobe

DMX modes

14ch 14 ch

14ch

14 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Position MSpeed	0	
6	Control1	0	0–9 No Function 10–14 Reset 15–255 No Function
7	Dimmer	0	0–254 Closed 255–255 Open
8	Shutter / Strobe	20	0–19 Closed 20–24 Open 25–64 Strobe S>F 65–69 Open 70–84 Pulse Open 85–89 Open 90–104 Pulse Close 105–109 Open 110–124 Rnd Strobe S>F 125–129 Open 130–144 Pulse Rnd Open 145–149 Open 150–164 Pulse Rnd Close 165–169 Open 170–184 Burst Pulse 185–189 Open 190–204 Burst Pulse Rnd 205–209 Open 210–224 Sine Wave 225–229 Open 230–244 Burst 245–255 Open
9	Color RGBRed	255	
10	Color RGBGreen	255	
11	Color RGBBlue	255	
12	White	255	
13	Color Effects1	0	0–9 Open 10–174 Colours 175–179 Open 180–201 CW F>S 202–207 Stop 208–229 CCW S>F 230–234 Open 235–255 Rnd F>S
14	Zoom	128	0–127 Wide 128–254 Medium 255–255 Narrow