SHEHDS

LED Beam/Spot/Zoom 160W 3IN1



Manufacturer	**SHEHDS**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**16 channels**
Beam angle	**10-20°**
Pan range	**540°**
Tilt range	**190°**
Size (W × H × D)	**240 × 450 × 220 mm**
GDTF fixture type	**2794718F-0491-42E5-AA14-450…**

Controls

Focus · Frost · Prism · Zoom · Colour wheel · Dimmer · Pan and tilt · Movement speed · Gobos · Gobo rotation

Safety-relevant functions

Fixture reset

DMX modes

Standard 17ch — 16 ch

Standard 17ch

16 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Strobe Mode Strobe	0	
3	Pan	0	
4	Tilt	0	
5	Position MSpeed	0	
6	Color Wheel	0	0–4 Open (wheel slot 1) 5–9 Pink (wheel slot 2) 10–14 Lime (wheel slot 3) 15–19 Cyan (wheel slot 4) 20–24 Orange (wheel slot 5) 25–29 Magenta (wheel slot 6) 30–34 Yellow (wheel slot 7) 35–39 Blue (wheel slot 8) 40–44 Green (wheel slot 9) 45–99 Red (wheel slot 10) 100–255 Color1WheelSpin 2
7	Gobo	0	0–9 Open (wheel slot 1) 10–19 Gobo1 (wheel slot 2) 20–29 Gobo2 (wheel slot 3) 30–39 Gobo3 (wheel slot 4) 40–49 Gobo4 (wheel slot 5) 50–59 Gobo5 (wheel slot 6) 60–69 Gobo6 (wheel slot 7) 70–79 gobo7 (wheel slot 8) 80–89 gobo8 (wheel slot 9) 90–99 gobo9 (wheel slot 10) 100–210 Gobo1WheelSpin 2 211–215 Gobo1 Shake (wheel slot 2) 216–220 Gobo2 Shake (wheel slot 3) 221–225 Gobo3 Shake (wheel slot 4) 226–230 Gobo4 Shake (wheel slot 5) 231–235 Gobo5 Shake (wheel slot 6) 236–240 Gobo6 Shake (wheel slot 7) 241–245 gobo7 Shake (wheel slot 8) 246–250 gobo8 Shake (wheel slot 9) 251–255 gobo9 Shake (wheel slot 10)
8	Gobo 2	0	
9	Gobo Rotation	0	
10	Prism	0	
11	Frost1	0	
12	Zoom	0	
13	Focus	0	
14	Fixture Global Reset	0	0–129 No Reset 130–255 Reset
15	Pan Fine	0	Fine byte of Pan
16	Tilt Fine	0	Fine byte of Tilt