SHEHDS

LED Spot 60W



Manufacturer	**SHEHDS**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**11 channels**
Beam angle	**25°**
Pan range	**540°**
Tilt range	**270°**
Size (W × H × D)	**100 × 180 × 100 mm**
GDTF fixture type	**BBC6D2C5-E136-4FC0-9EDF-82…**

Controls

Colour wheel · Dimmer · Movement speed · Gobos

Safety-relevant functions

Fixture reset

DMX modes

11CH — 11 ch

11CH

11 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Color Wheel	0	0–9 White (wheel slot 1) 10–19 Red (wheel slot 2) 20–29 Orange (wheel slot 3) 30–39 Yellow (wheel slot 4) 40–49 Green (wheel slot 5) 50–59 Blue (wheel slot 6) 60–69 Pink (wheel slot 7) 70–79 Cyan (wheel slot 8) 80–89 Cyan - Pink (wheel slot 7) 90–99 Pink - Blue (wheel slot 6) 100–109 Blue - Green (wheel slot 5) 110–119 Green - Yellow (wheel slot 4) 120–129 Yellow - Orange (wheel slot 3) 130–139 Orange - Red (wheel slot 2) 140–254 Min 255–255 Max
6	Gobo	0	0–7 Open (wheel slot 1) 8–15 Rose (wheel slot 2) 16–23 Dots (wheel slot 3) 24–31 Triangle (wheel slot 4) 32–39 Star (wheel slot 5) 40–47 Swirl 1 (wheel slot 6) 48–55 Swirl 2 (wheel slot 7) 56–63 Jitter (wheel slot 8) 64–71 Open (wheel slot 1) 72–79 Shake Rose (wheel slot 2) 80–87 Shake Dots (wheel slot 3) 88–95 Shake Triangle (wheel slot 4) 96–103 Shake Star (wheel slot 5) 104–111 Shake Swirl 1 (wheel slot 6) 112–119 Shake Swirl 2 (wheel slot 7) 120–127 Shake Jigsaw (wheel slot 8) 128–254 Min 255–255 Max
7	Shutter1Strobe	0	0–0 OPEN 1–126 Min 127–254 Med 255–255 Max
8	Dimmer	0	
9	Position MSpeed	0	
10	Color Macro1	0	0–48 No Function 49–99 Auto run Mode 1 100–199 Auto run Mode 2 200–255 Sound Control
11	Function	0	0–249 No Function 250–255 RESET