SHEHDS

LEDSpot90W_GDTF



Manufacturer	**SHEHDS**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**16 channels**
Beam angle	**25°**
Pan range	**540°**
Tilt range	**180°**
Size (W × H × D)	**150 × 240 × 150 mm**
GDTF fixture type	**927847C8-FEB0-4CA5-A0D2-64…**

Controls

Focus · Prism · Colour wheel · Strobe · Dimmer · Movement speed · Gobos · Gobo rotation

Safety-relevant functions

Fixture reset · Strobe

DMX modes

Default 16 ch

Default

16 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Tilt	128	
3	Dimmer	0	0–254 closed 255–255 open
4	Shutter / Strobe	7	0–6 closed 7–9 open 16–130 min Strobe 131–255 max Strobe
5	Color Wheel	0	0–9 white (wheel slot 1) 10–19 red (wheel slot 2) 20–29 orange (wheel slot 3) 30–39 yellow (wheel slot 4) 40–49 green (wheel slot 5) 50–59 blue (wheel slot 6) 60–69 pink (wheel slot 7) 70–79 magenta (wheel slot 8) 80–89 white-pink (wheel slot 7) 90–99 pink-magenta (wheel slot 8) 100–109 magenta-blue (wheel slot 8) 110–119 blue-green (wheel slot 6) 120–129 green-yellow (wheel slot 5) 130–139 yellow-orange (wheel slot 4) 140–149 orange-red (wheel slot 3) 150–159 red-white (wheel slot 2) 160–255 Color1WheelSpin 2
6	Gobo	0	0–35 open (wheel slot 1) 36–71 blue star (wheel slot 2) 72–107 triangle (wheel slot 3) 108–143 swirl (wheel slot 4) 144–179 rose (wheel slot 5) 180–215 dot3 (wheel slot 6) 216–219 tilde (wheel slot 7) 220–255 Gobo1WheelSpin 2
7	Gobo Rotation	0	0–0 min 1–254 Empty Channel Set 255–255 max
8	Gobo1Wheel Shake	0	0–0 min 1–254 Empty Channel Set 255–255 max
9	Gobo 2	0	0–26 open (wheel slot 1) 27–53 swirl (wheel slot 2) 54–80 flower (wheel slot 3) 81–107 atom (wheel slot 4) 108–134 leaf (wheel slot 5) 135–161 stripe (wheel slot 6) 162–188 rose (wheel slot 7) 189–215 crossed (wheel slot 8) 216–219 bubble (wheel slot 9) 220–255 Gobo2WheelSpin 2
10	Gobo1Select Shake	0	
11	Focus	0	
12	Prism	0	0–49 Prism off (wheel slot 2) 50–110 Prism (wheel slot 1) 111–166 slow (wheel slot 1) 167–219 mid (wheel slot 1) 220–255 fast (wheel slot 1)
13	Position MSpeed	0	
14	Pan Fine	0	Fine byte of Pan

Default (continued)

Ch	Function	Default	DMX values
15	Tilt Fine	0	Fine byte of Tilt
16	Fixture Global Reset	0	