Snow Lighting

SnowPAR2 Pro Quad 9



Manufacturer	**Snow Lighting**
Type	**Effect light**
DMX modes	**4**
DMX footprint	**2, 4, 6, 9 channels**
Beam angle	**25°**
Size (W × H × D)	**250 × 195 × 45 mm**
GDTF fixture type	**A93C0512-5AFF-4035-B1A0-CE…**

Controls

Extra LED colours · RGB colour mixing · Colour wheel · Effect speed · Strobe · Dimmer

Safety-relevant functions

Built-in effect programmes

DMX modes

2Ch Mode	2 ch
4Ch Mode	4 ch
6Ch Mode	6 ch
9Ch mode	9 ch

2Ch Mode

2 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Color Effects1	0	0–10 Open 11–23 Red 24–36 Green 37–49 Blue 50–62 White 63–75 Amber 76–88 Orange 89–101 Yellow 102–114 Purple 115–127 Pink 128–140 Cyan 141–153 Light red 154–166 Light green 167–179 Light blue 180–192 Warm white 193–205 Cold white 206–218 2700K 219–231 3200K 232–244 4500K 245–255 5400K

4Ch Mode

4 channels

Ch	Function	Default	DMX values
1	Color RGBRed	255	
2	Color RGBGreen	255	
3	Color RGBBlue	255	
4	White	255	

6Ch Mode

6 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Color RGBRed	255	
3	Color RGBGreen	255	
4	Color RGBBlue	255	
5	White	255	
6	Shutter / Strobe	0	0–10 Open 11–129 Strobe · Slow 0–9.67 Hz 130–254 Strobe · Medium 9.75–19.9 Hz 255–255 Strobe · Fast 20 Hz

9Ch mode

9 channels

Ch	Function	Default	DMX values
1	Dimmer	0	0–254 Closed 255–255 Open
2	Color RGBRed	255	
3	Color RGBGreen	255	
4	Color RGBBlue	255	

9Ch mode (continued)

Ch	Function	Default	DMX values
5	White	255	
6	Color Effects1	0	0–10 Open 11–23 Red 24–36 Green 37–49 Blue 50–62 White 63–75 Amber 76–88 Orange 89–101 Yellow 102–114 Purple 115–127 Pink 128–140 Cyan 141–153 Light red 154–166 Light green 167–179 Light blue 180–192 Warm white 193–205 Cold white 206–218 2700K 219–231 3200K 232–244 4500K 245–255 5400K
7	Effect	0	0–10 Open 11–26 Program 1 27–42 Program 2 43–58 Program 3 59–74 Program 4 75–90 Program 5 91–106 Program 6 107–122 Program 7 123–138 Program 8 139–154 Program 9 155–170 Program 10 171–186 Program 11 187–202 Program 12 203–218 Program 13 219–234 Program 14 235–255 Sound
8	Effect Speed	0	0–128 Slow 129–255 Fast
9	Shutter / Strobe	0	0–10 Open 11–129 Strobe · Slow 0–9.67 Hz 130–254 Strobe · Medium 9.75–19.9 Hz 255–255 Strobe · Fast 20 Hz