StairVille

LED Matrix Blinder 5x5 MK-II



Manufacturer	**StairVille**
Type	**Blinder**
DMX modes	**2**
DMX footprint	**26, 28 channels**
Beam angle	**55°**
Size (W × H × D)	**450 × 115 × 450 mm**
GDTF fixture type	**7063E9BA-AAA8-44FE-AAF0-18…**

Controls

Dimmer

DMX modes

26 ch
28 ch

26 ch
28 ch

26 ch

26 channels

Ch	Function	Default	DMX values
1	Dimmer	255	0–0 Closed 1–255 Open
2	Dimmer	255	0–0 Closed 1–255 Open
3	Dimmer	255	0–0 Closed 1–255 Open
4	Dimmer	255	0–0 Closed 1–255 Open
5	Dimmer	255	0–0 Closed 1–255 Open
6	Dimmer	255	0–0 Closed 1–255 Open
7	Dimmer	255	0–0 Closed 1–255 Open
8	Dimmer	255	0–0 Closed 1–255 Open
9	Dimmer	255	0–0 Closed 1–255 Open
10	Dimmer	255	0–0 Closed 1–255 Open
11	Dimmer	255	0–0 Closed 1–255 Open
12	Dimmer	255	0–0 Closed 1–255 Open
13	Dimmer	255	0–0 Closed 1–255 Open
14	Dimmer	255	0–0 Closed 1–255 Open
15	Dimmer	255	0–0 Closed 1–255 Open
16	Dimmer	255	0–0 Closed 1–255 Open
17	Dimmer	255	0–0 Closed 1–255 Open
18	Dimmer	255	0–0 Closed 1–255 Open
19	Dimmer	255	0–0 Closed 1–255 Open
20	Dimmer	255	0–0 Closed 1–255 Open
21	Dimmer	255	0–0 Closed 1–255 Open
22	Dimmer	255	0–0 Closed 1–255 Open
23	Dimmer	255	0–0 Closed 1–255 Open
24	Dimmer	255	0–0 Closed 1–255 Open
25	Dimmer	255	0–0 Closed 1–255 Open
26	Dimmer	255	0–0 Closed 1–255 Open

28 ch

28 channels

Ch	Function	Default	DMX values
1	Dimmer	255	0–0 Closed 1–255 Open
2	Dimmer	255	0–0 Closed 1–255 Open
3	Dimmer	255	0–0 Closed 1–255 Open
4	Dimmer	255	0–0 Closed 1–255 Open
5	Dimmer	255	0–0 Closed 1–255 Open
6	Dimmer	255	0–0 Closed 1–255 Open
7	Dimmer	255	0–0 Closed 1–255 Open
8	Dimmer	255	0–0 Closed 1–255 Open
9	Dimmer	255	0–0 Closed 1–255 Open
10	Dimmer	255	0–0 Closed 1–255 Open
11	Dimmer	255	0–0 Closed 1–255 Open
12	Dimmer	255	0–0 Closed 1–255 Open
13	Dimmer	255	0–0 Closed 1–255 Open
14	Dimmer	255	0–0 Closed 1–255 Open
15	Dimmer	255	0–0 Closed 1–255 Open
16	Dimmer	255	0–0 Closed 1–255 Open
17	Dimmer	255	0–0 Closed 1–255 Open
18	Dimmer	255	0–0 Closed 1–255 Open
19	Dimmer	255	0–0 Closed 1–255 Open
20	Dimmer	255	0–0 Closed 1–255 Open
21	Dimmer	255	0–0 Closed 1–255 Open
22	Dimmer	255	0–0 Closed 1–255 Open
23	Dimmer	255	0–0 Closed 1–255 Open
24	Dimmer	255	0–0 Closed 1–255 Open
25	Dimmer	255	0–0 Closed 1–255 Open
26	Dimmer	255	0–0 Closed 1–255 Open

28 ch (continued)

Ch	Function	Default	DMX values
27	Operating Mode	9	0–0 Closed 1–9 Open 10–19 Letter Display (selected trough ch 28) 20–29 Number Display Mode (selected trough ch 28) 30–39 Preprogrammed Show 1 40–49 Preprogrammed Show 2 50–59 Preprogrammed Show 3 60–69 Preprogrammed Show 4 70–79 Preprogrammed Show 5 80–89 Preprogrammed Show 6 90–99 Preprogrammed Show 7 100–109 Preprogrammed Show 8 110–119 Preprogrammed Show 9 120–129 Preprogrammed Show 10 130–139 Preprogrammed Show 11 140–149 Preprogrammed Show 12 150–159 Preprogrammed Show 13 160–169 Preprogrammed Show 14 170–179 Preprogrammed Show 15 180–189 Preprogrammed Show 16 190–199 Preprogrammed Show 17 200–209 Preprogrammed Show 18 210–219 Preprogrammed Show 19 220–229 Preprogrammed Show 20 230–239 Preprogrammed Show 21 240–255 Sound Controlled Show
28	Display Mode	0	10–19 Letter Display Mode 20–29 Number Display Mode 30–255 Speed Adjustment