Terbly

# OVAL7D



| | |
|---|---|
| Manufacturer | **Terbly** |
| Type | **Effect light** |
| DMX modes | **6** |
| DMX footprint | **4, 5, 6, 8 channels** |
| Beam angle | **10°** |
| Size (W × H × D) | **269 × 283 × 195 mm** |
| GDTF fixture type | **A9B22276-CFF7-427D-AAF1-3F…** |

## Controls

Extra LED colours · RGB colour mixing · Effect speed · Strobe · Dimmer

## Safety-relevant functions

Built-in effect programmes

## DMX modes

| | |
|---|---|
| 28Channel | 4 ch |
| 4Channel | 4 ch |
| 5Channel | 5 ch |
| Pixel | 5 ch |
| 6Channel | 6 ch |
| 8Channel | 8 ch |

## 28Channel

4 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Red | 255 | |
| 2 | Green | 255 | |
| 3 | Blue | 255 | |
| 4 | White | 0 | |

## 4Channel

4 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Red | 255 | |
| 2 | Green | 255 | |
| 3 | Blue | 255 | |
| 4 | White | 0 | |

## 5Channel

5 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Red | 255 | |
| 2 | Green | 255 | |
| 3 | Blue | 255 | |
| 4 | White | 0 | |
| 5 | Dimmer | 0 | 0–254 Closed<br>255–255 Open |

## Pixel

5 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Red | 255 | |
| 2 | Green | 255 | |
| 3 | Blue | 255 | |
| 4 | White | 0 | |
| 5 | Dimmer | 0 | 0–254 Closed<br>255–255 Open |

## 6Channel

6 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Red | 255 | |
| 2 | Green | 255 | |
| 3 | Blue | 255 | |
| 4 | White | 0 | |

### 6Channel (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 5 | Shutter / Strobe | 63 | 0–31 Closed<br>32–63 Open<br>64–94 min Strobe<br>95–95 max Strobe<br>96–127 Open 2<br>128–158 min Pulse<br>159–159 max Pulse<br>160–191 Open 3<br>192–222 Random · min Rnd 1–24.2 Hz<br>223–223 Random · maxRnd 25 Hz<br>224–255 Open 4 |
| 6 | Dimmer | 0 | 0–254 Closed<br>255–255 Open |

## 8Channel

8 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Red | 255 | |
| 2 | Green | 255 | |
| 3 | Blue | 255 | |
| 4 | White | 0 | |
| 5 | Shutter / Strobe | 63 | 0–31 Closed<br>32–63 Open<br>64–94 min Strobe<br>95–95 max Strobe<br>96–127 Open 2<br>128–158 min Pulse<br>159–159 max Pulse<br>160–191 Open 3<br>192–222 Random · min Rnd 1–24.2 Hz<br>223–223 Random · maxRnd 25 Hz<br>224–255 Open 4 |
| 6 | Dimmer | 0 | 0–254 Closed<br>255–255 Open |
| 7 | Effect | 0 | 0–10 No function<br>11–40 Chase 1<br>41–70 Chase 2<br>71–100 Chase 3<br>101–130 Chase 4<br>131–160 Chase 5<br>161–190 Chase 6<br>191–220 Chase 7<br>221–255 Chase 8 |
| 8 | Effect Speed | 0 | |