Terbly

T400C



Manufacturer	**Terbly**
Type	**PAR**
DMX modes	**2**
DMX footprint	**13, 19 channels**
Beam angle	**25°**
Size (W × H × D)	**208 × 786 × 214 mm**
GDTF fixture type	**7E905C6B-DACC-402F-B1A5-E7…**

Controls

Extra LED colours · RGB colour mixing · Colour temperature · Colour wheel · Strobe · Dimmer

Safety-relevant functions

Service functions

DMX modes

13 Ch	13 ch
19 Ch	19 ch

13 Ch

13 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	Color Add GY	0	
5	Color Add RY	0	
6	C TO	0	0–4 No function 5–9 White 2200K 10–14 White 3200K 15–19 White 4200K 20–24 White 5600K 25–29 White 6500K 30–34 White 8000K 35–255 2200K--8000K
7	Shutter / Strobe	31	0–31 Open 32–126 min Strobe 127–127 max Strobe 128–189 min Pulse 190–190 max Pulse 191–254 Random · min Rnd 1–24.6 Hz 255–255 Random · max Rnd 25 Hz
8	Dimmer	0	0–254 Closed 255–255 Open
9	Color Calibration Mode	0	0–254 Color Calibration closed 255–255 Color Calibration open
10	Dimmer Curve	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theatre 101–255 Default to Unit Setting
11	Fan Mode	0	0–20 unused 21–40 Auto 41–60 Full 61–255 Theatre
12	Color Macro1	0	

13 Ch (continued)

Ch	Function	Default	DMX values
13	Color Presets	0	0–15 unused 16–23 104 China Red 24–31 114 Ling Xiao 32–39 120 Begonia Red 40–47 203 Golden Orange 48–55 208 Realgar 56–63 212 Light Wheat Yellow 64–71 302 Imperial Yellow 72–79 308 Light Yellow 80–87 311 Moon White 88–95 401 Willow Green 96–103 405 Green Mustard 104–111 410 Pale Cyan 112–119 502 Parrot Green 120–127 508 Grass Green 128–135 517 Cold Blue 136–143 602 Sparkling Cove 144–151 608 Light Green 152–159 618 Light Pale Cyan 160–167 703 Ultramarine Blue 168–175 709 Emerald Blue 176–183 715 Cyan Cloud 184–191 803 Dark lavender 192–199 808 Dusk Purple 200–207 812 Light Wind Chime 208–215 901 Ravishing Purple 216–223 909 Plum Sauce Purple 224–231 916 Kao Mauve 232–239 1004 Magenta 240–247 1013 Wild Rose Pink 248–255 1022 Sakura Pink

19 Ch

19 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Red Fine	255	Fine byte of Red
3	Green	255	
4	Green Fine	255	Fine byte of Green
5	Blue	255	
6	Blue Fine	255	Fine byte of Blue
7	Color Add GY	0	
8	Color Add GY Fine	0	Fine byte of Color Add GY
9	Color Add RY	0	
10	Color Add RY Fine	0	Fine byte of Color Add RY
11	C TO	0	0–4 No function 5–9 White 2200K 10–14 White 3200K 15–19 White 4200K 20–24 White 5600K 25–29 White 6500K 30–34 White 8000K 35–255 2200K--8000K

19 Ch (continued)

Ch	Function	Default	DMX values
12	Shutter / Strobe	31	0–31 Open 32–126 min Strobe 127–127 max Strobe 128–189 min Pulse 190–190 max Pulse 191–254 Random · min Rnd 1–24.6 Hz 255–255 Random · max Rnd 25 Hz
13	Dimmer	0	0–254 Closed 255–255 Open
14	Dimmer Fine	0	Fine byte of Dimmer
15	Color Calibration Mode	0	0–254 Color Calibration closed 255–255 Color Calibration open
16	Dimmer Curve	0	0–20 Standard 21–40 Stage 41–60 TV 61–80 Architectural 81–100 Theatre 101–255 Default to Unit Setting
17	Fan Mode	0	0–20 unused 21–40 Auto 41–60 Full 61–255 Theatre
18	Color Macro1	0	
19	Color Presets	0	0–15 unused 16–23 104 China Red 24–31 114 Ling Xiao 32–39 120 Begonia Red 40–47 203 Golden Orange 48–55 208 Realgar 56–63 212 Light Wheat Yellow 64–71 302 Imperial Yellow 72–79 308 Light Yellow 80–87 311 Moon White 88–95 401 Willow Green 96–103 405 Green Mustard 104–111 410 Pale Cyan 112–119 502 Parrot Green 120–127 508 Grass Green 128–135 517 Cold Blue 136–143 602 Sparkling Cove 144–151 608 Light Green 152–159 618 Light Pale Cyan 160–167 703 Ultramarine Blue 168–175 709 Emerald Blue 176–183 715 Cyan Cloud 184–191 803 Dark lavender 192–199 808 Dusk Purple 200–207 812 Light Wind Chime 208–215 901 Ravishing Purple 216–223 909 Plum Sauce Purple 224–231 916 Kao Mauve 232–239 1004 Magenta 240–247 1013 Wild Rose Pink 248–255 1022 Sakura Pink