UKing

ZQ02314 WATERPROOF BEAM



Manufacturer	**UKing**
Type	**Moving head**
DMX modes	**1**
DMX footprint	**14 channels**
Beam angle	**2°**
Pan range	**540°**
Tilt range	**228°**
Size (W × H × D)	**240 × 450 × 220 mm**
GDTF fixture type	**61D10B1A-EC9D-4E49-96E7-9C…**

Controls

Focus · Prism · Prism rotation · Colour wheel · Strobe · Dimmer · Movement speed · Gobos

Safety-relevant functions

Fixture reset

DMX modes

14Ch — 14 ch

14Ch

14 channels

Ch	Function	Default	DMX values
1	Pan	128	
2	Pan Fine	0	Fine byte of Pan
3	Tilt	128	
4	Tilt Fine	0	Fine byte of Tilt
5	Position MSpeed	0	
6	Dimmer	0	0–254 Closed 255–255 Open
7	Shutter / Strobe	0	0–3 None 4–99 Simultaneous strobe 0.1–10 Hz 100–149 Shutter1StrobePulseOpen 150–199 Sharp-flash 200–249 Random strobe 250–255 Open
8	Color Wheel	0	0–6 White (wheel slot 1) 7–11 Red (wheel slot 2) 12–16 Green (wheel slot 3) 17–21 Cyan (wheel slot 4) 22–26 Yellow (wheel slot 5) 27–31 Violet (wheel slot 6) 32–36 Fern Green (wheel slot 7) 37–41 Blue (wheel slot 8) 42–46 Magenta (wheel slot 9) 47–51 Orange (wheel slot 10) 52–56 Lavander (wheel slot 11) 57–61 1/2 CTB (wheel slot 12) 62–66 CTB (wheel slot 13) 67–71 CTO (wheel slot 14) 72–75 White + Red (wheel slot 1) 76–79 Red + Green (wheel slot 2) 80–83 Green + Cyan (wheel slot 3) 84–87 Cyan + Yellow (wheel slot 4) 88–91 Yellow + Violet (wheel slot 5) 92–95 Violet + Green (wheel slot 6) 96–99 Fern Green + Blue (wheel slot 7) 100–103 Blue + Magenta (wheel slot 8) 104–107 Magenta + Orange (wheel slot 9) 108–111 Orange + lavander (wheel slot 10) 112–115 lavander + 1/2 CTB (wheel slot 11) 116–119 1/2 CTB + CTB (wheel slot 12) 120–123 CTB + CTO (wheel slot 13) 124–127 CTO + White (wheel slot 14) 128–128 CCW Fast 129–188 CCW Fast2Slow 189–189 CCW Slow 190–193 STOP 194–194 CW Slow 195–254 CW Slow2Fast 255–255 CW Fast

14Ch (continued)

Ch	Function	Default	DMX values
9	Gobo	0	0–2 Open 3–6 Gobo 1 7–10 Gobo 2 11–14 Gobo 3 15–18 Gobo 4 19–22 Gobo 5 23–26 Gobo 6 27–30 Gobo 7 31–34 Gobo 8 35–38 Gobo 9 39–42 Gobo 10 43–46 Gobo 11 47–50 Gobo 12 51–54 Gobo 13 55–58 Gobo 14 59–62 Gobo 15 63–66 Gobo 16 67–70 Gobo 17 71–77 Gobo 1 Slow2Fast 78–84 Gobo 2 Slow2Fast 85–91 Gobo 3 Slow2Fast 92–98 Gobo 4 Slow2Fast 99–105 Gobo 5 Slow2Fast 106–112 Gobo 6 Slow2Fast 113–119 Gobo 7 Slow2Fast 120–126 Gobo 8 Slow2Fast 127–133 Gobo 9 Slow2Fast 134–140 Gobo 10 Slow2Fast 141–147 Gobo 11 Slow2Fast 148–154 Gobo 12 Slow2Fast 155–161 Gobo 13 Slow2Fast 162–168 Gobo 14 Slow2Fast 169–175 Gobo 15 Slow2Fast 176–182 Gobo 16 Slow2Fast 183–189 Gobo 17 Slow2Fast 190–190 CCW Fast 191–220 CCW Fast2Slow 221–221 CCW Slow 222–223 STOP 224–224 CW Slow 225–254 CW Slow2Fast 255–255 CW Fast
10	Color Effects1	0	0–127 Colorful cut out 128–255 Colorful cut in
11	Prism	0	0–127 Open (wheel slot 1) 128–255 Prism (wheel slot 2)
12	Prism Rotation	0	0–127 Empty Channel Set 128–128 CW Fast 129–189 CW Fast2Slow 190–190 CW Slow 191–192 STOP 193–193 CCW Slow 194–254 CCW Slow2Fast 255–255 CCW Fast
13	Focus	0	0–0 Min 1–254 Min2Max 255–255 Max
14	Control1	0	0–199 No feature 200–205 All motor reset 206–255 No feature