Varytec

Blitz Bar 240



Manufacturer	**Varytec**
Type	**Effect light**
DMX modes	**3**
DMX footprint	**8, 14, 232 channels**
Beam angle	**60-120°**
Size (W × H × D)	**1000 × 30 × 69 mm**
GDTF fixture type	**83EF74C7-87ED-48E2-A313-75…**

Controls

Extra LED colours · RGB colour mixing · Colour wheel · Effect speed · Strobe · Dimmer

Safety-relevant functions

Strobe · Built-in effect programmes

DMX modes

Mode 1 / 8 CH	8 ch
Mode 2 / 14 CH	14 ch
Mode 3 232 CH	232 ch

Mode 1 / 8 CH

8 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	Shutter / Strobe	0	
5	Effect	0	0–7 Open 8–19 Strobe Show 1 20–31 Strobe Show 2 32–43 Strobe Show 3 44–55 Strobe Show 4 56–67 Strobe Show 5 68–79 Strobe Show 6 80–91 Strobe Show 7 92–103 Strobe Show 8 104–115 Strobe Show 9 116–127 Strobe Show 10 128–139 Strobe Show 11 140–151 Strobe Show 12 152–163 Strobe Show 13 164–175 Strobe Show 14 176–187 Strobe Show 15 188–199 Strobe Show 16 200–211 Strobe Show 17 212–223 Strobe Show 18 224–235 Strobe Show 19 236–255 Strobe Show 20
6	Effect Speed	0	
7	Color Effects1	0	
8	Color Mix MSpeed	0	

Mode 2 / 14 CH

14 channels

Ch	Function	Default	DMX values
1	Red	255	
2	Green	255	
3	Blue	255	
4	Dimmer	0	
5	Effect	0	0–7 no Function 8–19 Strobe Show 1 20–31 Strobe Show 2 32–43 Strobe Show 3 44–55 Strobe Show 4 56–67 Strobe Show 5 68–79 Strobe Show 6 80–91 Strobe Show 7 92–103 Strobe Show 8 104–115 Strobe Show 9 116–127 Strobe Show 10 128–139 Strobe Show 11 140–151 Strobe Show 12 152–163 Strobe Show 13 164–175 Strobe Show 14 176–187 Strobe Show 15 188–199 Strobe Show 16 200–211 Strobe Show 17 212–223 Strobe Show 18 224–235 Strobe Show 19 236–255 Strobe Show 20

Mode 2 / 14 CH (continued)

Ch	Function	Default	DMX values
6	Effect Speed	0	
7	Shutter / Strobe	0	0–8 no Function 9–255 Strobe 0 to 100 %
8	Color Effects1	0	
9	Color Mix MSpeed	0	
10	Shutter / Strobe	0	0–15 Open 16–255 Strobe 0 to 100%
11	Color RGBRed	0	
12	Color RGBGreen	0	
13	Color RGBBlue	0	
14	Effects1Adjust1	0	0–127 Normal Direction 128–255 Reversd

Mode 3 232 CH

232 channels

Ch	Function	Default	DMX values
1	Dimmer	0	
2	Dimmer	0	
3	Dimmer	0	
4	Dimmer	0	
5	Dimmer	0	
6	Dimmer	0	
7	Dimmer	0	
8	Dimmer	0	
9	Dimmer	0	
10	Dimmer	0	
11	Dimmer	0	
12	Dimmer	0	
13	Dimmer	0	
14	Dimmer	0	
15	Dimmer	0	
16	Dimmer	0	
17	Dimmer	0	
18	Dimmer	0	
19	Dimmer	0	
20	Dimmer	0	
21	Dimmer	0	
22	Dimmer	0	
23	Dimmer	0	
24	Dimmer	0	
25	Dimmer	0	
26	Dimmer	0	
27	Dimmer	0	
28	Dimmer	0	
29	Dimmer	0	
30	Dimmer	0	

Mode 3 232 CH (continued)

Ch	Function	Default	DMX values
31	Dimmer	0	
32	Dimmer	0	
33	Dimmer	0	
34	Dimmer	0	
35	Dimmer	0	
36	Dimmer	0	
37	Dimmer	0	
38	Dimmer	0	
39	Dimmer	0	
40	Dimmer	0	
41	Color RGBRed	0	
42	Color RGBGreen	0	
43	Color RGBBlue	0	
44	Color RGBRed	0	
45	Color RGBGreen	0	
46	Color RGBBlue	0	
47	Color RGBRed	0	
48	Color RGBGreen	0	
49	Color RGBBlue	0	
50	Color RGBRed	0	
51	Color RGBGreen	0	
52	Color RGBBlue	0	
53	Color RGBRed	0	
54	Color RGBGreen	0	
55	Color RGBBlue	0	
56	Color RGBRed	0	
57	Color RGBGreen	0	
58	Color RGBBlue	0	
59	Color RGBRed	0	
60	Color RGBGreen	0	
61	Color RGBBlue	0	
62	Color RGBRed	0	
63	Color RGBGreen	0	
64	Color RGBBlue	0	
65	Color RGBRed	0	
66	Color RGBGreen	0	
67	Color RGBBlue	0	
68	Color RGBRed	0	
69	Color RGBGreen	0	
70	Color RGBBlue	0	
71	Color RGBRed	0	
72	Color RGBGreen	0	
73	Color RGBBlue	0	
74	Color RGBRed	0	
75	Color RGBGreen	0	

Mode 3 232 CH (continued)

Ch	Function	Default	DMX values
76	Color RGBBlue	0	
77	Color RGBRed	0	
78	Color RGBGreen	0	
79	Color RGBBlue	0	
80	Color RGBRed	0	
81	Color RGBGreen	0	
82	Color RGBBlue	0	
83	Color RGBRed	0	
84	Color RGBGreen	0	
85	Color RGBBlue	0	
86	Color RGBRed	0	
87	Color RGBGreen	0	
88	Color RGBBlue	0	
89	Color RGBRed	0	
90	Color RGBGreen	0	
91	Color RGBBlue	0	
92	Color RGBRed	0	
93	Color RGBGreen	0	
94	Color RGBBlue	0	
95	Color RGBRed	0	
96	Color RGBGreen	0	
97	Color RGBBlue	0	
98	Color RGBRed	0	
99	Color RGBGreen	0	
100	Color RGBBlue	0	
101	Color RGBRed	0	
102	Color RGBGreen	0	
103	Color RGBBlue	0	
104	Color RGBRed	0	
105	Color RGBGreen	0	
106	Color RGBBlue	0	
107	Color RGBRed	0	
108	Color RGBGreen	0	
109	Color RGBBlue	0	
110	Color RGBRed	0	
111	Color RGBGreen	0	
112	Color RGBBlue	0	
113	Color RGBRed	0	
114	Color RGBGreen	0	
115	Color RGBBlue	0	
116	Color RGBRed	0	
117	Color RGBGreen	0	
118	Color RGBBlue	0	
119	Color RGBRed	0	
120	Color RGBGreen	0	

Mode 3 232 CH (continued)

Ch	Function	Default	DMX values
121	Color RGBBlue	0	
122	Color RGBRed	0	
123	Color RGBGreen	0	
124	Color RGBBlue	0	
125	Color RGBRed	0	
126	Color RGBGreen	0	
127	Color RGBBlue	0	
128	Color RGBRed	0	
129	Color RGBGreen	0	
130	Color RGBBlue	0	
131	Color RGBRed	0	
132	Color RGBGreen	0	
133	Color RGBBlue	0	
134	Color RGBRed	0	
135	Color RGBGreen	0	
136	Color RGBBlue	0	
137	Color RGBRed	0	
138	Color RGBGreen	0	
139	Color RGBBlue	0	
140	Color RGBRed	0	
141	Color RGBGreen	0	
142	Color RGBBlue	0	
143	Color RGBRed	0	
144	Color RGBGreen	0	
145	Color RGBBlue	0	
146	Color RGBRed	0	
147	Color RGBGreen	0	
148	Color RGBBlue	0	
149	Color RGBRed	0	
150	Color RGBGreen	0	
151	Color RGBBlue	0	
152	Color RGBRed	0	
153	Color RGBGreen	0	
154	Color RGBBlue	0	
155	Color RGBRed	0	
156	Color RGBGreen	0	
157	Color RGBBlue	0	
158	Color RGBRed	0	
159	Color RGBGreen	0	
160	Color RGBBlue	0	
161	Color RGBRed	0	
162	Color RGBGreen	0	
163	Color RGBBlue	0	
164	Color RGBRed	0	
165	Color RGBGreen	0	

Mode 3 232 CH (continued)

Ch	Function	Default	DMX values
166	Color RGBBlue	0	
167	Color RGBRed	0	
168	Color RGBGreen	0	
169	Color RGBBlue	0	
170	Color RGBRed	0	
171	Color RGBGreen	0	
172	Color RGBBlue	0	
173	Color RGBRed	0	
174	Color RGBGreen	0	
175	Color RGBBlue	0	
176	Color RGBRed	0	
177	Color RGBGreen	0	
178	Color RGBBlue	0	
179	Color RGBRed	0	
180	Color RGBGreen	0	
181	Color RGBBlue	0	
182	Color RGBRed	0	
183	Color RGBGreen	0	
184	Color RGBBlue	0	
185	Color RGBRed	0	
186	Color RGBGreen	0	
187	Color RGBBlue	0	
188	Color RGBRed	0	
189	Color RGBGreen	0	
190	Color RGBBlue	0	
191	Color RGBRed	0	
192	Color RGBGreen	0	
193	Color RGBBlue	0	
194	Color RGBRed	0	
195	Color RGBGreen	0	
196	Color RGBBlue	0	
197	Color RGBRed	0	
198	Color RGBGreen	0	
199	Color RGBBlue	0	
200	Color RGBRed	0	
201	Color RGBGreen	0	
202	Color RGBBlue	0	
203	Color RGBRed	0	
204	Color RGBGreen	0	
205	Color RGBBlue	0	
206	Color RGBRed	0	
207	Color RGBGreen	0	
208	Color RGBBlue	0	
209	Color RGBRed	0	
210	Color RGBGreen	0	

Mode 3 232 CH (continued)

Ch	Function	Default	DMX values
211	Color RGBBlue	0	
212	Color RGBRed	0	
213	Color RGBGreen	0	
214	Color RGBBlue	0	
215	Color RGBRed	0	
216	Color RGBGreen	0	
217	Color RGBBlue	0	
218	Color RGBRed	0	
219	Color RGBGreen	0	
220	Color RGBBlue	0	
221	Color RGBRed	0	
222	Color RGBGreen	0	
223	Color RGBBlue	0	
224	Color RGBRed	0	
225	Color RGBGreen	0	
226	Color RGBBlue	0	
227	Color RGBRed	0	
228	Color RGBGreen	0	
229	Color RGBBlue	0	
230	Color RGBRed	0	
231	Color RGBGreen	0	
232	Color RGBBlue	0	