
ZZIPP

# ZZEN400STR



| | |
|---|---|
| Manufacturer | **ZZIPP** |
| Type | **PAR** |
| DMX modes | **2** |
| DMX footprint | **12, 59 channels** |
| Beam angle | **25°** |
| Size (W × H × D) | **546 × 131 × 257 mm** |
| GDTF fixture type | **E5BE06F0-35F6-4579-8328-265…** |

## Controls

Colour wheel · Strobe · Dimmer · Pixel control

## DMX modes

| | |
|---|---|
| 12 CH | 12 ch |
| 59 CH | 59 ch |

## 12 CH

12 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Dimmer | 0 | |
| 2 | Shutter / Strobe | 0 | 0–5 No<br>6–255 Strobe |
| 3 | Red | 0 | |
| 4 | Green | 0 | |
| 5 | Blue | 0 | |
| 6 | Shutter / Strobe | 0 | 0–5 NO<br>6–255 Strobe |
| 7 | Dimmer | 0 | |
| 8 | Color Macro | 0 | |
| 9 | Color Macro2 | 0 | |
| 10 | Macro Speed | 0 | |
| 11 | Color Macro | 0 | |
| 12 | Macro Speed | 0 | |

## 59 CH

59 channels

| Ch | Function | Default | DMX values |
|---|---|---|---|
| 1 | Dimmer | 0 | |
| 2 | Green | 255 | |
| 3 | Blue | 255 | |
| 4 | Reserved 4 | 0 | |
| 5 | Reserved 5 | 0 | |
| 6 | Reserved 6 | 0 | |
| 7 | Reserved 7 | 0 | |
| 8 | Reserved 8 | 0 | |
| 9 | Reserved 9 | 0 | |
| 10 | Shutter / Strobe | 0 | 0–5 NO<br>6–255 Shutter1Strobe 2 |
| 11 | Reserved 11 | 0 | |
| 12 | Reserved 12 | 0 | |
| 13 | Reserved 13 | 0 | |
| 14 | Reserved 14 | 0 | |
| 15 | Reserved 15 | 0 | |
| 16 | Reserved 16 | 0 | |
| 17 | Reserved 17 | 0 | |
| 18 | Reserved 18 | 0 | |
| 19 | Reserved 19 | 0 | |
| 20 | Reserved 20 | 0 | |
| 21 | Reserved 21 | 0 | |
| 22 | Reserved 22 | 0 | |
| 23 | Reserved 23 | 0 | |
| 24 | Reserved 24 | 0 | |
| 25 | Reserved 25 | 0 | |
| 26 | Reserved 26 | 0 | |
| 27 | Reserved 27 | 0 | |

## 59 CH (continued)

| Ch | Function | Default | DMX values |
|---|---|---|---|
| **28** | Reserved 28 | 0 | |
| **29** | Reserved 29 | 0 | |
| **30** | Reserved 30 | 0 | |
| **31** | Reserved 31 | 0 | |
| **32** | Reserved 32 | 0 | |
| **33** | Reserved 33 | 0 | |
| **34** | Reserved 34 | 0 | |
| **35** | Reserved 35 | 0 | |
| **36** | Reserved 36 | 0 | |
| **37** | Reserved 37 | 0 | |
| **38** | Reserved 38 | 0 | |
| **39** | Reserved 39 | 0 | |
| **40** | Reserved 40 | 0 | |
| **41** | Reserved 41 | 0 | |
| **42** | Reserved 42 | 0 | |
| **43** | Reserved 43 | 0 | |
| **44** | Reserved 44 | 0 | |
| **45** | Reserved 45 | 0 | |
| **46** | Reserved 46 | 0 | |
| **47** | Reserved 47 | 0 | |
| **48** | Reserved 48 | 0 | |
| **49** | Reserved 49 | 0 | |
| **50** | Reserved 50 | 0 | |
| **51** | Reserved 51 | 0 | |
| **52** | Reserved 52 | 0 | |
| **53** | Reserved 53 | 0 | |
| **54** | Reserved 54 | 0 | |
| **55** | Reserved 55 | 0 | |
| **56** | Reserved 56 | 0 | |
| **57** | Reserved 57 | 0 | |
| **58** | Reserved 58 | 0 | |
| **59** | Shutter / Strobe | 0 | 0–5 NO<br>6–255 Strobo |